




Website: www.veryfocal.com
Support: support@veryfocal.com

IP Camera User Guide




Content

1. How the camera works	1
2. Camera parts	1
3. How to set up the camera	2
3.1 Install App and create App account	2
3.2 Plug camera to power	2
3.3 Add camera to App	3
4. App - Camera List	5
5. App - Live Footage	6
6. App - Video Playback	7
7. Camera Settings	8
8. Set a Password	9
9. Motion Detection Management	11
10. Record Schedule	12
11. PTZ Control	12
12. Presets	13
13. Camera Light Control	13
14. Me - APP Overall Settings	14
15. App Setting	14
16. Pair the camera to a WiFi NVR (optional)	15
17. PTZ Camera Auto-tracking	16
18. Set Return Home Point for PTZ Cameras	17
18.1. Set camera home point with #58 command	17
18.2. Set camera home point with preset point	18



1. How the camera works



3. How to set up the camera

3.1 Download [WallPixel App](#). Spend a few minutes to register an user account and login.

You can scan below QR code to find the Apps.



WallPixel



iOS



Android

3.2 Bring the camera close to your Wi-Fi router, plug it to power.

2. Camera Parts






3.3.1 Plug camera to router for setup



Use an Ethernet cable to plug the camera to your router's LAN port, and plug camera to power. In App, tap + and **Scan the LAN**. Then tap camera's ID to add it to App. Leave the admin password **empty**.

Then enter camera's **Device setting - Device WiFi**. Connect the camera to your WiFi and then you can unplug the camera from router.





3.3.2 Setup camera wirelessly


In App, tap + to add camera, select your camera type.




Choose **NO** while asked whether camera has an Ethernet port. Then follow on-screen guide to setup camera.



In your phone's WLAN setting, connect to camera's WiFi IPCxxx. The default WiFi password is 11111111.



Configuration done




Swipe up and return to WallPixel App. Select your WiFi and provide password to connect the camera to your home WiFi.

If the camera was not added successfully, hold the reset button for 10seconds and do it again. Make sure to provide CORRECT WiFi hotspot and password (2.4G WiFi only).




4.App - Camera List

- ① Group. With group, you can group multiple cameras to a quad view or multiple view. Then you can view multiple cameras simultaneously with one tap.
- ② Camera name, network status
- ③ Quick menu to recorded photos & videos, edit/delete camera.
- ④ Cloud storage
- ⑤ Share device with families or friends
- ⑥ Alarm messages
- ⑦ Video playback




5.App - Live Footage





6. App - Video Playback

In camera list, tap Playback to play camera's recorded videos. Make sure you have Micro SD card in the camera.




12. Take a snapshot to App library



7. Camera Settings

In camera list, tap Setting to enter camera settings.



- 1 Set the camera's WiFi connection
- 2 Audio ON/ OFF
- 3 Voice instruction – voice guide settings
- 4 Change the volume of the device
- 5 Motion detection settings
- 6 Record schedule settings
- 7 Firmware update for camera
- 8 Enable/ disable Alexa view
- 9 Camera storage status, SD card format
- 10 Sync camera time with your mobile
- 11 Set device timezone
- 12 Daylight saving time ON/ OFF
- 13 Reverse image to fit mount type
- 14 Reverse PTZ control direction
- 15 Set video color, style, clarity
- 16 Set privacy areas and cover them from the videos
- 17 Set username and password of the camera.

● Important tips: please set your password to secure your camera



8. Set a Password

Setting a password is very important to secure your camera. We suggest you to set your password while setting up the camera.

In [Camera's Setting - Set password - Password](#), provide your original password and new password. Leave the original password [empty](#) if you have not set any.





After you set a password, you will be currently locked out like anyone else. Edit your camera information so you have access to the camera.


In Camera List - [3-dot menu - Edit](#), provide your new password and save. You will be viewing your camera through a secured channel.




9. Motion Detection Management



10. Record Schedule




11. PTZ Control






12. Presets



Tap + to record preset points. Tap Go to to view the point.

13. Camera Light Control



This works only for cameras with floodlight.


IR: IR LEDs light up automatically at night. Night vision is in B/W.

Floodlight: Floodlights stay up at night. Night vision is in color.

AUTO/Smart (recommended): At night IR LEDs turn up for night vision; when motion detected, the camera turns on floodlight to deter intruders away and image turns color.




14. Me - APP Overall Settings



- ① Tap profile photo to enter your App account settings.
- ② Check App system notifications.
- ③ App-related settings.
- ④ Manage device sharing status.
- ⑤ Help center and feedbacks.
- ⑥ App permission settings from your mobile.
- ⑦ App privacy policies.
- ⑧ App version number.

15. App Setting




- ① Mobile data traffic situations.
- ② Switch live view mode among Fluent & Live.
- ③ Turn App messages ON/ OFF.
- ④ Report App crashes to developer.
- ⑤ Clean App cache.
- ⑥ Auto screen brightness ON/ OFF
- ⑦ Logout your App account.



16. Pair the camera to a WiFi NVR (optional)


1. Bring the camera close to your WiFi NVR.



2. Plug the camera to power, hold reset button 10 seconds to bring camera to pairing mode.



3. On the NVR screen, right click menu - Add Cam by WiFi. The camera will be paired to the NVR within a minute.



Tips: make sure your NVR has an empty channel for the new camera.



17. PTZ Camera Auto-tracking



To enable a PTZ camera's Auto-tracking, in App tap the 3-dot menu - [Device setting](#) - [Smart Detection](#) - enable the "Motion detection tracking" and save.


The camera will track people when activities detected.



18. Set Return Home Point for PTZ Cameras


18.1. From the App, while viewing a PTZ camera with mobile App, tap **PTZ**, use the joystick to move camera to your favorite point. Then tap **Preset Point - Shortcut mode**, type in "58" and tap **Setting**.

This will set the point as your camera's home point. It will return to this point after auto tracking. (works for most cameras)





18.2. If the #58 command does not work, please follow below steps to set home point.

In App while viewing the camera, tap **PTZ - Preset point**, use the joystick to move camera to your favorite point, tap **"Add preset point"**.

Behind the preset point you shall see icon , tap the icon to set this point as home point.

The camera will automatically return to this point after each auto-tracking.



Note: While using the product, please comply with your local laws and regulations of audio & video devices.

If you have further questions, please refer to help center at, www.veryfocal.com

or contact us at support@veryfocal.com

Thank you!