




## Set up




- 1 Remove chair from carry bag.
- 2 Grab the chair at the back and seat, then push outward to unfold.  
Tip: Please lock the bottom fixed buckle while pressing the armrest.

## How to use the heating function?



1. Lithium-ion batteries with USB-A slots can power the heated seat.
2. The controller controls the heating on three levels(140° F, 122° F, and 104° F).  
Note: Battery not included.

## To fold:



- 1 Unlock the bottom fixed buckle first.
- 2 Hold the chair at the upper back tube and the lower seat tube.
- 3 Binding Velcro the chair.
- 4 A storage bag is included.

**DESIGNED, BUILT AND TESTED  
IN THE WILD,  
FOR THE WILD.**

### Warranty

Your Portal table is covered by a 12-month quality warranty.

### Questions? Talk to Us

Email : [Info@portaloutdoors.com](mailto:Info@portaloutdoors.com)  
[www.portaloutdoors.com](http://www.portaloutdoors.com)

@PortalOutdoorsGear  
 @portaloutdoorsusa

### Safety Tips

- 1.This folding chair holds a maximum weight of 400 lbs. (Do Not Exceed)
- 2.No leaning on/over the chair's armrest.
- 3.Care should be taken to avoid tipping chair while in the act of sitting or while seated.
- 4.Use folding chair only on level ground.
- 5.To avoid injuries to fingers, use care when folding the chair.