


Top lumbar adjustment



1. Top lumbar support is connected by adjustable hook-and-loop tabs.



2. Pull and tighten the strap outward to adjust lumbar support. Release the buckle to return to normal.

To fold:



1. Unlock the bottom fixed buckle first.

2. Hold the chair at the upper back tube and the lower seat tube.

3. Binding Velcro the chair.

4. A storage bag is included.



**DESIGNED, BUILT AND TESTED
IN THE WILD,
FOR THE WILD.**

Warranty

Your Portal table is covered by a 12-month quality warranty.

Questions? Talk to Us

Email : Info@portaloutdoors.com
www.portaloutdoors.com

@PortalOutdoorsGear
 @portaloutdoorsusa

Safety Tips

1. This folding chair holds a maximum weight of 400 lbs. (Do Not Exceed)
2. No leaning on/over the chair's armrest.
3. Care should be taken to avoid tipping chair while in the act of sitting or while seated.
4. Use folding chair only on level ground.
5. To avoid injuries to fingers, use care when folding the chair.