




INSTRUCTIONS | Camping Cot (189106)





- 1** Take out the cot and lay it flat on the ground




- 2** Lift up and extend the frame as shown above.


- 3** Fully open the cot.



- 4** Make sure legs and side frames are completely extended



- 5** Buckle in the security strap in the middle and around the frame.



- 6** Press in all two side locks to secure the frame.

**DESIGNED, BUILT AND TESTED
IN THE WILD,
FOR THE WILD.**

Warranty

Your Portal cot is covered by a 12-month quality warranty.

Questions? Talk to Us

Email : Info@portaloutdoors.com
www.portaloutdoors.com

@PortalOutdoorsGear
 @portaloutdoorsusa

Safety Tips

- Set up your cot on even surface.
- When unfolding, do not drop the legs.
- Care shall be taken to avoid finger jamming or sudden drop of heavy frame
- Suggested Maximum Weight Capacity 300lbs/136kg