



1




- Ensure the locking levers on both sides are pointing back, in unlock position.
- Stand behind chair and hold upright.
- Place one hand on top of the armrest, and the other hand on top of backrest.

2




Open the chair fully from the side. If opening from the back, then push the chair open and watch your toes.

3



- Lay back relaxed and legs on the footpad. Give a gentle kick down to initiate the Zero Gravity experience, and you will start to recline.
*Note: Do not tense up or try to get up during reclining.
- When you are at a comfortable position and wish to stay, push forward the locking nobles to the "LOCK" position.
*Note: Return to unlock position before "landing".

4



Pull out side table from under the chair, rotate, and lock securely on front leg pin. Store table in reverse sequence.

**DESIGNED, BUILT AND TESTED
IN THE WILD,
FOR THE WILD.**

Warranty

Your Portal chair is covered by a 12-month quality warranty.

Questions? Talk to us

Email : Info@portaloutdoors.com
www.portaloutdoors.com

@PortalOutdoorsGear
 @portaloutdoorsusa

Safety Tips

- Do not put your fingers under the arm adjustment area at any time.
- Always keep hands and fingers on the top surface of the arm.
- Do not attempt to adjust positions if your fingers are under the arm.
- Always engage the Locking Levers when sitting in the Lounger.