




To Unfold:


- 1 Place folded rock on a surface and lift up the chair part.




- 2 Place one hand on the headrest and other on the seating area to push down simultaneously.



- 3 Press down both armrests until properly locked onto the rocking tube.

To Fold:


- 1 Step on the rocking tube and lift up the seat to unlock.



- 2 To fold, pull on the headrest and the seating area simultaneously.



- 3 Lay down the seat and fold into the rocking tube



**DESIGNED, BUILT AND TESTED
IN THE WILD,
FOR THE WILD.**

Warranty

Your Portal chair is covered by a 12-month quality warranty.

Questions? Talk to us

Email : Info@portaloutdoors.com
www.portaloutdoors.com

@PortalOutdoorsGear
 @portaloutdoorsusa

Safety Tips

- This chair holds a maximum of 300lbs/136kg. Exceeding this limit will damage the chair and may cause personal injury.
- Possibility of serious injury if the chair is used improperly (not for standing on, not to be used if any leg(s) is / are not on ground, not used on level ground).
- Failure to follow warnings could result in serious injury.