

INSTRUCTIONS | HAMMOCK CHAIR (047)







 Unfasten the carry bag take out all component parts. Lift the main frame off the ground and open it as shown by the arrows until it automatically locks. Make sure the button is fully locked like in figure 2. Adjust the feet so they're flat on the ground.



4 Make sure legs and side frames are completely extended

DESIGNED, BUILT AND TESTED

IN THE WILD.

FOR THE WILD.



5 Buckle in the security strap in the middle and around the frame.

How to fold



Remove the chair and cup holder.



Press in the upper part of the button and push the frame in until it's fully closed.



3 Adjust the feet from status A to B to save more space and protect the plastic feet.



Wrap the chair on the outside of the stand and put it into the backpack together.



Warranty

Your Portal cot is covered by a 12-month quality warranty.

Questions? Talk to Us

Email : Info@portaloutdoors.com www.portaloutdoors.com

- @PortalOutdoorsGear
- @portaloutdoorsusa

Safety Tips

- This folding chair holds a maximum weight of 350 lbs.
 - No leaning on/over the chair's armrest. Care should be taken to avoid tipping chair while in the act of sitting or while seated.
- Use folding chair only on level ground To avoid injuries to fingers,use care when folding the chair