Car Multimedia Player

User Manual

Preface

In order to make sure the product fits for the car 100%, customers need to take the measurement of dashboard installation before purchase, mainly the length and height of panel.

In order to prevent injuries and fires, please pay attention to following instruction:

Please check the car horn line carefully before installation, if it is grounded or collided, you need to rewire the car horn line and connect the product, otherwise the machine will be burned.

In order to prevent short circuit and so on, do not drop the metal object in the device.

If there is smoke or peculiar smell the device, please turn of the power at once.

Please do not make the device falling or strong collision. In order to prevent device failure, please observe the following note:

Please do not install the device in the place of strong sunlight, high temperature, high humidity or dusty.

Please replace the fuse which is the same specification. If you are using different specification of the fuse, may cause failure of the device.

In order to prevent short circuit, please pull out the power wire when you replace the fuse.

In order to be able at any time to deal with road and traffic conditions change, please lower the volume when driving.

Please do not get the device wet when washing car, this may cause short circuit, then fire or failure will be caused.

Warning

- 1. Only connect the unit to a DC 12V power supply with negative grounding.
 - If you connected to the car of 24V, it'll be burned.

(Note: Only the panel label with 24V, then it can be used in the car of 24V power supply.)

- 2. When the machine is in a state of abnormal during the operation, you need to use a pointed object to press the key of "RES" (on the panel), then it will be reset and in factory state.
- 3. Never install the unit where the operation for safety driving is restrained.
- 4. Never use the video display function in the front when driving to prevent the violation of laws regulation and also to reduce the risk of traffic accident except using for rear view video camera.
- Never expose the unit, amplifier, speakers to moisture or water to prevent electronic sparks or fires.
- 6. Please do not change the fuse in the power cord without professional guidance; improper fuse may cause damage to this using unit or even cause fire.
- 7. When the temperature is too high or too low in the car, please adjust the temperature firstly, and then use this machine.

Installation

The unit installs for security, please install it refer to the following diagram description:

- Please make the unit in proper place, connect the unit refer to the diagram, and test it works well or not.
- Please wrapped the connection line with insulation tape to ensure complete wiring after testing well.
- Please bend the hook of metal 1, and insert the metal to instrument panel then fixed it.
- 4. Put the unit into metal hook unit it lock.

General Features

TFT HD Touch Screen BT/FM/USB MP5 Rearview Camera

- Digital TFT Touch Screen
- Front USB 2.0 port
- Support 1080P Video Format
- Support the Audio playback format of MP3/FLAC/OGG/APE
- Support the Video playback format of RM/RMVB/VOB/DAT/MOV/MPG /MP4/FLV/3GP/AVI etc
- FM Range: 87.5MHz~108.0MHz(Europe)
- Power-off with auto-memory store function under radio or USB mode
- EQ / Clock / Mute Function
- BT Function
- Rear View Camera Function
- Support Steering Wheel Control
- 1 Way Video input
- 2 Way Audio input
- 2 Way Video output
- 2 Way Audio output
- Phone Link
- Support Subwoofer Output

Basic Operation

- When use reversing rear view function, reversing video signal from the corresponding port input connection back line, when reversing will automatically switch to reversing visual state.
- 2. Audio / Video input

Select AUX Mode, plug in Audio input lines to rear AUX Port and plug in Video Wire to the rear Video input Port.

3. Operation of BT Function

Firstly, open BT function of your phone, and then search BT name to the machine, pairing, enter the **password "0000"**, after pairing successfully, the BT symbol will be turn green, that'll be ok.

When calls come in, it will enter the interface of BT automatically, press to answering the phone, press to hanging the phone.

4 Operation of Phone Link

Android Phone

- Click the AutoLink icon of the MP5, scan the QR code, download and install the APK to your phone.
- Open your Phone' Bluetooth, search the device name of the MP5, pairing, enter the pin code "0000", when connected successful, the voice of your phone will transmit to the MP5.
- Open the android phone "Setting", find the Option of "Developer options", enter this option, turn on the option "USB Debugging".
- Connect your Phone to MP5 by USB Cable, then the image of phone' will display on the MP5 screen, your can operate your phone on the MP5 screen.

iOS Phone:

Connect your IOS Phone to the MP5 by USB cable, when phone pop-up a permission window, select "Trust", it will be success connect to the phone. (Note: IOS phone can not be operated by touch the MP5 screen.)

Steering Wheel Control Learning



- After connecting the wires, please open the UI, choose the button which you need, eg: , the icon will flicker.
- Long press the same function key of the wheel, if it is success, the icon will turn bright, and not flicker.
- 3. Then press the icon to save the setting.
- 4. If you want to set more function key, press the icon to reset the setting, and repeat the 2 step, finally execute the 3 step to save.

Front Panel



1. **b** : When the Power is Off, short press is turn on Power,
When the Power is On, short press is Mute, long press is
turn off the Power.

2 💍 : Return to Home Page.

Seturn to previous page.


4. ☐+ : Turn up the volume.

5. r1- : Turn down the volume.

6. USB : USB Slot.

7. MIC : Microphone.

Wire Diagram





Please check the speaker line carefully before installation.

If any grounding or touching, please connection again, otherwise the unit will be burned.

FAQ

1. The machine couldn't boot

Please check whether the connection of the power of positive and negative is right, on the other hand, check whether the fuse is burned, it's better send us photos to show in order to solve the problem.

2. Black screen or shutdown automatically.

It may lost software, so please check the date of production on the PK board, we can provide the right software to update after know the date of production.

3. No sound.

Check wiring diagram, make sure the connection is right.

4. The button doesn't work.

Check whether the keys have stuck.

5. The radio doesn't work.

Check whether the connection of radio antenna is right.

6. Search station automatically and couldn't stop.

The local radio signal may be too weak, try to search the station hardly.

CEAD

Specification

CNID

SINK	
Frequency response	20Hz~20KHz
Loudspeaker impedance	4Ω~8Ω
Tone Control	Bass+/-7dB(100Hz)
	Treble+/-7dB(100Hz)
FM	
FM frequency	87.5MHz~108.0MHz
Sensitivity	25dB
Selectivity	60dB
Separation	35dB