

正面

Instructions

ZA68 PRO

Mechanical keyboard manual


01. Product basis

02. Function introduction

1 Product basis

Essential information

Work Voltage: 5V	Interface type: USB/2.4G/Bluetooth
Work Current: <150mA	Key Type: Mechanical Switch
Key Life: 50 million times	Lighting Effects: key light-22 types
Backlight: Colorful	side light-11 types
Size: 327mm(L)*114mm(W)*43mm(H)+/-2mm	Compatible system:
N-key Rollover	MAC/Vista/Win7/Win8/Win10
	Android



2 FN-Key Combination

Adjustment of lighting effects

FN+ — Lighting Switch	FN+← — Speed -
FN+↓ — Brightness -	FN+→ — Speed +
FN+↑ — Brightness +	

Key Functions

FN+Left CTRL=ESC to += becomes ~to F12, you can use the multimedia function key combination.


FN+Esc	`~	FN+Left CTRL triggers multimedia functions	FN+Z	Win system	side light effect left and right side light brightness. Press and hold for 3 seconds, the lowest light of the middle three indicators Flash three times turn to press down mute, turn the volume left and right, loud Small four stop brightness.
FN+1	F1	FN+1	Music	FN+X	
FN+2	F2	FN+2	Brightness+	FN+Y	
FN+3	F3	FN+3	Brightness-	FN+W	
FN+4	F4	FN+4	Mute	FN+Tab	Adjust the backlight
FN+5	F5	FN+5	Pause	CAPS	Indicator
FN+F6	F6	FN+F6	Previous	WIN	Lock Indicator
FN+7	F7	FN+7	Play/Pause		Reposition
FN+8	F8	FN+8	Nest	FN+space	Press and hold the 3s keyboard to restore the factory Clear all settings
FN+9	F9	FN+9	Mailbox		
FN+0	F10	FN+0	Hmoe page		
FN+~_	F11	FN+~_	My computer		
FN+=	F12	FN+=	Calculator		

Knob status indicator:
By default, press down to adjust the

1 产品基础

基本信息

工作电压: 5V	接口类型: USB/2.4G/蓝牙
工作电流: <150mA	按键类型: 机械轴
按键寿命: 5000万次	灯光效果: 主灯效22种
背光: RGB	侧光11种灯效
尺寸: 327mm(L)*114mm(W)*43mm(H)+/-2mm	系统兼容:
支持全键无冲	WinXP/Vista/Win7/Win8/Win10
	Android



2 FN-发光组合

灯效模式调整

FN+ — 切换灯效	FN+← — 速度减
FN+↓ — 亮度减	FN+→ — 速度加
FN+↑ — 亮度加	

按键功能介绍

FN+Esc	`~	FN+左CTRL触发多媒体功能	FN+Z	Win 系统	按键指示灯闪烁, 连接后停止闪烁
FN+1	F1	FN+1	音乐	FN+Y	
FN+2	F2	FN+2	音量加	FN+W	
FN+3	F3	FN+3	音量减	FN+X	
FN+4	F4	FN+4	静音	FN+Tab	调背光颜色
FN+5	F5	FN+5	暂停	CAPS	指示灯
FN+F6	F6	FN+F6	上一首	WIN	锁指示灯
FN+7	F7	FN+7	播放/暂停		
FN+8	F8	FN+8	下一首	FN+空格	复位
FN+9	F9	FN+9	邮箱		长按 3s 键盘恢复出厂清除所有设置
FN+0	F10	FN+0	主页	FN+Q:	
FN+~_	F11	FN+~_	我的电脑		短按, 切换到2.4G通道, 需要搭配2.4G无线接收器Dongle使用长按3秒重新进入配对状态, 断开连接时
FN+=	F12	FN+=	计算器		

Instructions

Are there any problems with our products?

Please contact us and we will reply
as soon as possible to ensure that all your needs can be solved

Mechanical keyboard manual

...

底面

说明书，三折页，双面印刷，3000份