


QUICK USER GUIDE



ATLI T100 Lite



www.atlitimelapse.com


In the Box



T100 Lite



Battery*2





Charging Cable



Quick User Guide


Camera Parts




- 1 Power Button
- 2 External Flash Interface
- 3 USB Type C (For Power Only)
- 4 Status LED
- 5 Focus Ring
- 6 Focus Mark
- 7 MicroSD Card Slot
- 8 Battery Cover Opening Slot
- 9 Tripod Mount (Size: 1/4"-20)

Removing the insulating tab

Open the battery cover and remove the insulating tab from the terminals of the battery.



Insulating tab



Pull away

Installing the ATLI Cam app

Please download and install ATLI Cam app before using the camera. Scan this QR or search "ATLI Cam" on APP Store or Google Play.



ATLI Cam



ATLI Cam QR Code

Camera QR code


Every camera has a unique QR code. Launch ATLI Cam app and use this QR code to register the camera.



A backup QR code is attached in the battery compartment.


Before the first use

- a. Download ATLI Cam app on your smart phone or tablet.
- b. Press and hold the power button for 4 to 5 seconds to turn on the camera and wait approx. 30 secs until the status LED turns **GREEN**.
- c. Open this guide and find out the camera QR code.




Registering the camera

- a. Open ATLI Cam app, press "Add Camera".
- b. Scan the camera QR code.



Quick start

- a. Set up your camera steadily and rotate the focus ring manually until the image is sharp.
- b. Once it's ready, press the record button to proceed.
- c. Choose an appropriate interval and start recording.



Search #atlitimelapse to find us on:



Please visit www.atlitimelapse.com for more information.

2023.05.11

Warranty

This limited warranty applies to physical goods purchased from authorized ATLI retailers.

The warranty period is 365 days from the date of purchase.

During the warranty period, ATLI will repair or replace, products or parts of a product that proves defective because of improper material or workmanship, under normal use and maintenance.

To obtain warranty service, please contact us at email shown below.

Email us: service@atliview.com
More details on our website: www.atlitimelapse.com/warranty

Photo / Video

Photo Format : JPEG
Video Format : MP4
Playback Frame Rate : 25fps
Exposure Compensation : ±4EV
ISO : 100 - 4000
Shooting Mode : Time Lapse/Photo

Battery / Charging

Battery Type : Li-ion
Capacity : 2050 mAh
Voltage : 3.7V
Charging Limited Voltage : 4.2V
Charging Method : USB-C Cable (Type A-C only)
Operational Environment : 0°C - 40°C

Design

Weight : 125g (With battery)
84g (Without battery)
Dimension : 54*70*50mm

Specifications

Basics

Lens : 4 Glass Elements
Aperture : F2.8
Field of View : 72°±5%
Photo Resolution : 2688*1520
Video Resolution : 1920*1080
Pixel Size : 2µm*2µm
Focus Mode : Manual
Focus Range : 7cm to Infinity
Exposure Metering : Center-Weighted/Partial-Weighted
Shutter Speed : 1/20000 - 1.4s
Language : English/中文
App : iOS/Android

Storage and Connectivity

Storage: 16GB MicroSD card pre-installed
(Support up to 128GB, Class10 or above)
Wi-Fi : 802.11a/b/g/n (Approx. range 5 meters radius)

Important Notes

- ⚠ This product is not waterproof and shall not be used under water nor in the rain.
- ⚠ Do not remove the microSD card from camera during recording. This may corrupt the file or damage the card.
- ⚠ Do not disassemble the camera as this will void the warranty. We are not liable for any problems caused by unauthorized modifications or attempted repair.
- 🔧 Update the camera with the latest firmware when the app prompts "New Firmware Available" and follow the onscreen procedures.
- 🔧 Please clean the lens with dust blower or micro fiber cloth occasionally.
- 🔧 Plug the camera into a stable power source to enjoy long-term shooting.

Resolving Known Errors

Error	Root Cause	Workaround
Connection failed	-App permission is off -Auto connection failed -Error in microSD card	→Allow app permission on your phone →Connect wi-fi manually (find instruction in app) →Backup and format the microSD card on PC and reinsert
Video/photo cannot be found in album	-Corruption during saving process	→Pull out and reinsert the microSD card


Status LED Indication

Status LED provides important information on what is going on with the camera. Learn below what the different variations of LED mean.

Blinking Mode	Status
● SOLID GREEN	Ready to connect, Fully charged
✳ BLINKING GREEN	Recording
● SOLID RED	Charging
✳ BLINKING RED	Ready to connect, Power low : battery below 20%
● ORANGE	Booting
✳ BLINKING ORANGE	Power saving mode
● OFF	Power off


⚠ If the LED stays solid orange and the camera is not working properly, please contact us for tech support.

b. By turning the focus ring anti-clockwise and previewing the image via the ATLI Cam app, you can set the camera focus for objects ranging in between 7 to 80cm away.



How to do manual focus

a. Turn the focus ring fully clockwise to set the camera focus for objects at distances ranging from 80cm to infinity. This is the factory preset focus setting.



The focus ring is in the preset position when the green focus marker aligns with the LED, as shown. When the focus ring reaches this position, you will feel it click into place.