

Please read this user manual thoroughly and completely before using the product.



CONTENTS

I.IMPORTANT SAFETY INSTRUCTIONS

1.CONTRAINDICATION

6 VOLUME ADJUSTMENT

2 WARNINGS

3.NOTICE 03

II.DO NOT USE IF ANY OF THE FOLLOWING APPLY TO YOU 06

III.MATTERS NEEDING ATTENTION, WARNINGS AND TIPS 07

IV.HOW TO USE YOUR DEVICE 07

1.QUICK GUIDE 08

3.LEFT & RIGHT HEARING AMPLIFIER MARKINGS

4.WEARING/REMOVE HEARING AMPLIFIER 11
5.TURN ON/TURN OFF 13

-1-

7 HEARING AMPLIFIER CHARGING 8.HOW TO USE THE CHARGING CASE 9.CLEANING V MAINTENANCE AND CLEAN VII.HEARING AMPLIFIER CARE VII TROUBLESHOOTING GUIDE VIII.TIPS FOR BETTER COMMUNICATIO IX.TECHNICAL SPECIFICATION X ACCESSORIES LIST

XI.NORMALIZED SYMBOLS

XIII.WARRANTY

XII.MAINTENANCE, STORAGE, AND DISPOSAL

LIMPORTANT SAFFTY INSTRUCTIONS Read all the information in this instruction manual and any other

literature included in the box before using the device. 1 CONTRAINDICATION

- - The device should not be used in the following situations: - Patients with chronic suppurative otitis media (CSOM),congenital
- ear atresia, or any type of ear discharge

remove and consult a doctor.

- Anvone under 6 vears old
- 2. WARNINGS A Warning
- Keep small parts (hearing instrument, ear domes, battery or other
- detachable parts) that can be swallowed out of children's reach.

Remove devices prior to any type of X-ray, MRI, or CT scan. If parts

- Dropping, immersing in liquid, exposure to strong electromagnetic fields or excessive heat will damage the hearing amplifiers.
- become stuck in the ear canal, seek medical assistance do not attempt to remove by yourself.
- 3. Notice **A** Warning
- Do not use at high volume for extended periods of time ear injury can result.

- Do not store or use the product in environments of high humidity or temperature (such as sauna room), to avoid damage. - Batteries should be properly recycled and not disposed in the

- Routine maintenance to keep the device clean is required.

Ensure that ear domes are free of debris and moisture at all times.

- trash - Keep the devices away from small children. Injury or damage may
 - result. - Do not set volume levels too high. Listening with high-output devices for extended periods at high volume levels can cause
 - further hearing damage. - Do not share your hearing amplifiers with others. Using a hearing

- Avoid shocks or dropping the product.

- amplifier configured for someone else can result in hearing damage or injury. - Monitor for any unusual skin reaction. If you notice any allergic reaction (itchiness, swelling, or rash), stop wearing the hearing
- amplifiers and consult a medical specialist. - Do not touch the hearing amplifiers to any type magnet or magnetized object. Your hearing amplifiers are delicate electronic
- instruments and may be damaged by contact with strong magnetic - If you experience any pain or strong discomfort using the devices, fields - Do not attempt to open or repair the devices yourself. Damage

- can result and will void the warranty.
- Do not store your devices in a hot/humid locations. You should never leave your hearing amplifiers near heating appliances or in direct sunlight.
- Do not leave your hearing amplifiers in the car as inside temperatures can reach dangerous levels which could damage the devices.
- Do not use the hearing amplifiers together with a cell phone earpiece directly excessive noise and distortion may result. Instead, use via Bluetooth pairing with your cell phone. Radio wave emissions from mobile phones can cause noise in the
- For assistance, if needed, in setting up, using or maintaining vour devices or
 - To report any unexpected operation or events

hearing amplifiers or result in reduced volume.

- Please contact the MANUFACTURER:

Specific warnings / statements

Keep small parts away from and out of children's reach to avoid

accidental ingestion

Warning not to use in explosive or oxygen-enriched atmospheres, as

doing so may damage the device

Warning that it should only be used by intended person as using hearing amplifiers designed for someone else may result in hearing damage

-5-

II. DO NOT USE IF ANY OF THE FOLLOWING APPLY TO YOU:

- Congenital atresia of external ear or deformity of any part of the ear canal
- 2) Deafness is unstable, and the degree of hearing loss often fluctuates3) Persistent headaches, dizziness, earaches, tinnitus or other
- symptoms that are not suitable for adaptation
 4) Sudden onset of hearing loss within the past 3 months; rapid progressive deafness; unilateral hearing loss or other acute ear
- disease;
 5) Effusion (secretions/discharge) in the ear and/or frequent purulence (pus)
 6) Central deafness (central nervous system) or non-organic
- deafness


 7) Patients with agute etitic externs and tympopitics
- 7) Patients with acute otitis externa and tympanitis
- 8) Patients with acute and chronic suppurative otitis media (in the period of purulent infection)9) Patients who are allergic to the materials of this product


-6

III. Matters needing attention, warnings and tips

- Do not immerse the hearing amplifier in any liquid. Remove the hearing amplifier before swimming or bathing. After swimming or washing, wait for the ear canal to dry before wearing the hearing amplifier.
- After removing the hearing amplifier at night, it should be placed in a case with a desiccant if possible, protected from light, high temperature and high humidity environment.
- The external surfaces of the hearing amplifier should be kept clean, and earwax in the ear domes should be cleaned out daily
- 4. Applicable objects: Suitable for people with air-conducting hearing loss of about 30-50dB
- When you do not use hearing amplifiers, please charge the product regularly to avoid battery damage; the recommended charging time interval of hearing amplifiers is ≤28 days

IV.HOW TO USE YOUR DEVICE





- 1. Volume Control
- 2. Microphone
- 3. Ear Dome4. Charging Contacts
- 5 In Far Detection Sensor
- 5. III Ear Detection Senso

1. 【QUICK GUIDE】

- 1. Charging your hearing amplifiers.
- * Before using your hearing amplifier for the first time, it is recommended to charging when it light in green and the light turn off in dicates charging is complete.



After placing your hearing amplifier in the charger, the indicator will show the charging status of the battery until the hearing amplifier is fully charged. When fully charged the indicator will be constantly on, i.e. solid green light.

Turn ON/OFF

Turn ON: Take the hearing amplifier out of the charging case, it will enter the standby status. The hearing amplifier will turn on automatically in 3 seconds when you wear the hearing amplifier correctly in the ears.

Turn OFF: Place back to charger case to turn off.





2. Volume adjustment

To increase the volume, turn the volume control towards the "+" direction (forwards). To decrease the volume, turn the volume control towards the "-" direction (backwards).




2. 【HOW TO APPLY DOMES】

Please follow these steps to mount domes, because Incorrect dome replacement could result in the dome being left in the ear when you remove the hearing amplifier.


Step 1: Choose a suitable size ear dome.



Step 2: Push the ear dome rim membrane outward.



Step 3: Hold on to the end of the hearing amplifier and push firmly to ensure that the dome is fastened securely.





-9-

Notes:

After the ear dome is installed, pull the ear dome gently to see if it is firmly installed and ensure the ear dome does not fall off easily.

3. 【LEFT & RIGHT HEARING AMPLIFIER MARKINGS】

There is a L or R marking on the hearing amplifier. This will tell you if it is a left or a right hearing amplifier.



L marking for left hearing amplifier.



R marking for right hearing amplifier.

4. **[WEARING/REMOVE HEARING AMPLIFIER]**

For comfort, your hearing amplifier always automatically when you remove them.

The in ear detection sensor will carry out real-time intelligent detection on the operation status of the hearing amplifier. When the hearing amplifier is removed, it will automatically enter the standby status. When you place the hearing amplifier in the ear, it will automatically turn on.

4.1 Wearing hearing amplifier

Step 1: Hold the hearing amplifier body (hard part), place in the ear (Make sure it is in right direction like picture).

Step 2: Move the body slightly into auricle for holding.





4.2 Removing the hearing amplifier
Step 1: Grasp the protruding hearing amplifier and remove it.



Notes:

1. It may be in few circumstances that the ear dome remain attached to the auditory meatus after the hearing amplifier is taken out.

In that case, please ask a professional doctor to take the ear dome out.

2. Before the hearing amplifier is appropriately secured, it may give out

the creak sound, which is a normal phenomenon. The creak sound can be used as a reference to determine whether the hearing amplifier

is secured. If the hearing amplifier gives out squeaking, please check if

it is taken on correctly; if so, but the squeaking remains, please replace with the other set of ear dome. When the hearing amplifier is not in use, please turn it off without delay.

3. When the hearing amplifier is not functioning properly, please check the "Troubleshooting Guide". If none of the solutions work, please contact our after-sales service team.

5. 【TURN ON/TURN OFF】

Turn On: Take the hearing amplifier out of the charging case, the hearing amplifier will enter the standby status. The hearing amplifier will turn on automatically in 3 seconds when you wear the hearing amplifier correctly in the ears.



Turn Off: The hearing amplifier will automatically enter the standby status when you have remove it from your ear. Put the hearing amplifier back into the correct slot of the charging case , they will automatically turn off and start charging.






Note: The hearing amplifier built in with 'delay turn on' function, after placing correctly in the ear canal, automatically turn on after 3 seconds delay from the 'beep' tone.

6. **VOLUME ADJUSTMENT**

To increase the volume, turn the volume control towards the "+" direction (forwards). To decrease the volume, turn the volume control towards the "-" direction (backwards).



-14-





- 1. Lip
- 2. hearing amplifier charging inserts with left/right indicators
- 3. Left-side hearing amplifier charging indicator
- 4. Charging case charging indicator
- 5. Right-side hearing amplifier charging indicator
- 6. Battery check button
- 7. Micro USB connection to external power supply

7. **[HEARING AMPLIFIER CHARGING]**

Put the hearing amplifier back into the correct slot of the charging case, they will automatically turn off and start charging. Orange light will indicate hearing amplifiers are charging. After fully charged, they will light in green and the light turn off in dicates charging is complete.

(See details in table for Charging Indicator Changes of the Charging Case)

*Note: hearing amplifier Low Power: You will hear the notification sound when the hearing amplifier battery drops below 25%, and when the battery below 10%, you will hear the notification sound again.





8. [HOW TO USE THE CHARGING CASE]

8.1 Plug the small Micro-USB cable tip into the USB charging port of the Case. Plug the large USB-A end into a USB-A power source such as a wall charger or your computer.



8.2 The indicator light will show the charging status of the battery until the hearing amplifier is fully charged. When the case is charging, the indicator shows a orange solid light, and fully charged the indicator light will shows a solid green light will be constant and the light turning off indicates charging is complete.



8.3 With the hearing amplifiers in the case, all charging will automatically turn off when the case and hearing amplifiers are fully charged. The case will continue charging with or without the case lid closed but it is recommended to close the lid when charging overnight to keep out dust and moisture.

8.4 The charging process will automatically stop when the case and hearing amplifiers are fully charged, so the hearing amplifiers can be safely left in the charger. Place it on a flat even surface away from exposure to moisture, dust, or extreme temperatures.

*The fully charged case offers 3 full charging cycles for a pair of hearing amplifiers.

Orange Light Flashing Indicator off Solid Green Light Solid Orange Light				
001				
	Power	Left hearing aid charging indicator	Charging indicator of the charging case	Right hearing aid charging indicator
	100%			
Hearing aid	≥ 25%			
Charging	≤ 25% (Charging Case battery below 25%)		Flash	
Charging Case Charging	≤ 25%			
	≥ 25%			
	100%			
Discharging				

Charging Indicator Changes of the Charging Case

8.5 Charging case Turn ON/OFF

Press and hold the lower part of button for 5 seconds until the solid orange light indicates the charging case is off.

• • •	Indicator will flash in green once a second, flashing by 1 second alternately and lasting by 3 times	Charging case is turn on
• • •	Indicator will flash in orange once a second, flashing by 1 second alternately and lasting by 3 times	Charging case is turn off

*Note:

- 1.To check the remaining battery status of the charging case, press the battery check button. The indicator will show the status.
- 2.Charging case Low Power: The charging case indicator will flash orange when the charging case battery drops below 25%, please charge the case.
- 3.When the case is fully charged, the indicator will show a solid green light will be constant and the light turn off indicates charging is complete.

4.When the hearing amplifier and case is not functioning properly, please check the "troubleshooting guide". If none of the solutions work, please contact our after-sales service team.

9. 【CLEANING】

9.1.Cleaning the ear domes

Remove any earwax buildup using the enclosed tool. Wipe clean with a tissue or soft cloth.

9.2.Cleaning Tool

Use a soft cloth or tissue to wipe any moisture, perspiration, or debris from the surface of the tool.

Note: Do not use alcohol or other cleaning solvents to clean the tool as this could damage the protective covering.

9.3.Daily maintenance

It is important to keep your devices clean and dry. On a daily basis, wipe them clean using a soft cloth or tissue. To avoid potential damage from excess humidity or perspiration, the use of a drying kit is also recommended.



continuous working time, and charging times are derived from our internal laboratory testing and meant for reference purposes only. Your exact usage and times may differ depending on various conditions and use patterns. It is a normal phenomenon to hear some high-pitched whistling or buzzing when the hearing amplifier is at a high volume level and not fitted well into the ear as a result of mic feedback. If this occurs, lower the volume and adjust the hearing amplifier within the ear. Also check to make sure you are

wearing the best size ear domes to ensure a proper fit in the ear

canal, as this may also induce some minor feedback if not snug in

All data in this manual, such as service time, charging time,

V. MAINTENANCE AND CLEANING

the ear

bathroom.

- 1. Daily maintenance
- basis, wipe them clean using a soft cloth or tissue. To avoid potential damage from excess humidity or perspiration, the use of a drving kit is also recommended. 2. Care and maintenance

It is important to keep your devices clean and dry. On a daily

- When not in use, store in a secure area away from small children and pets.
- Do not place hearing amplifiers or charging case near high-tem-
- perature areas such as stoves or direct sunlight. Do not leave the devices in a humid place for a long time, such as

enclosed tool. Wipe clean with a tissue or soft cloth. 2) Cleaning Tool

3. Cleaning

to avoid damage.

1) Cleaning the ear tips Remove any earwax buildup using the

will void vour warranty.

Use a soft cloth or tissue to wipe any moisture, perspiration, or dehris from the surface of the tool Note: Do not use alcohol or other cleaning solvents to clean the

VI HEARING AMPLIFIERS CARE

- Keep your hearing amplifiers clean. Extreme temperatures (heat or cold), moisture, and foreign substances can result in poor perfor-

hook as this could damage the protective covering.

Take care not to poke the microphone holes with any sharp objects

Do not disassemble or attempt any repairs by yourself. Doing so

mance. - Use the cleaning brush tool or soft cloth to clean debris from around the buttons, microphones, and charging contacts; inspect

the receiver, ear tips, and charging case regularly. - Never use water, solvents, cleaning fluids or oils to clean your

- hearing amplifiers. - Charging contacts should always be kept clean and dry.
 - Always store your hearing amplifiers in the charging case when not in use or cleaning.

-21-

Charging Case Care

- Keep your charger clean. Heat, moisture and foreign materials can result in poor performance.
- Using the provided cleaning brush keep the charging ports clear of debris.
- Do not use water, solvents or cleaning fluids to clean the charging ports.
- Keep lid closed as much as possible to avoid dust and debris build up.
- Store your charger in a clean and dry location, i.e. a dresser or shelf rather than the bathroom or kitchen.
- To ensure the longest life of your rechargeable hearing amplifiers batteries and the batteries in the charger:
- Fully charge hearing amplifiers batteries every night.

Service and Repair

If, for any reason, your hearing amplifiers and charger do not operate properly, do NOT attempt to fix it yourself. Besides possibly causing further damage, you are likely to violate any applicable warranties or insurance. Should your hearing amplifiers and charger fail or perform poorly, check the Troubleshooting Guide section for possible solutions. If problems persist, contact us for assistance

VII.TROUBLESHOOTING GUIDE

SYMPTOM	POSSIBLE CAUSES	SOLUTIONS
No Sound	Incorrect wearing, the in ear detection sensor failure	Remove the hearing amplifier, wear it correctly
	Volume too low	Increase volume if volume control available
	Device is not charged	Place charging the hearing amplifier until the indicator is lighted in green color.
	Microphones are clogged	Clean out any debris from the mid holes
	Ear Domes or speaker tip are clogged	Clean out any debris from the ear domes and receiver area with the cleaning brush
	Low battery	Place the aids into the Charging Case for at least 1.5 hours
	Volume is set too low	Increase volume if volume control available
Voices are low,	Ear Domes are too loose	hearing amplifier not inserted correctly into ear , wear it correctly
very weak, or unclear	Earwax in ear dome	Clean out any debris from the ear domes and receiver area with the cleaning brush
	Hearing has changed	Contact your physician to report any sudden drop in hearing

			I			
Inconsistent performance Distorted sound	Restart required	Place aids in charger until charging begins and remove-this will power cycle your hearing amplifiers		The voice is very weak and unclear	Low battery	Connect the hearing amplifier to the charging case for charging
	Incorrect orientation En	Ensure the USB cable is connected to the Charging Case plugged into			Volume is set too low	Increase volume if volume control available
hearing amplifiers		power. The Case power status lights will flash orange to indicate charging.			Ear Domes are too loose	hearing amplifier not inserted correctly into ear , wear it correctly
After the hearing aid is connected, aid is connected, charging case	Charger battery depleted Reposition your hearing amplifiers in their slots, ensuring the contact		hearing amplifier plays notification sound	Indication for low battery	Charge hearing amplifier	
		points are touching the charge points in the case.		Indicator light on	hearing amplifier not inserted correctly into charger	Insert hearing amplifier correctly into charger
	hearing amplifier and	Reinsert the hearing amplifier into the charging case	hearing amplifier does not light up when hearing	Charger not connected to power source	Connect charger to external power supply	
	hearing amplifier reverse	Check to see if the hearing amplifier is reversed		amplifier placed in charging inserts	Battery fully discharged	Wait three hours after placing hearing amplifier in charger, regardless of LED behavior
				hearing amplifier failure	self-checking table	
[Fault self-check] project	Possible Causes	Solution		[Fault self-check] project	Possible Causes	Solution
hearing amplifier	Plugging out the mouth or	Clean the sound port or				

[Fault self-check] project	Possible Causes	Solution
hearing amplifier has no sound	Plugging out the mouth or microphone	Clean the sound port or microphone port

Poor contact between After the hearing Reinsert the hearing amplifier into hearing amplifier and charging case aid is connected, the charging case the hearing hearing amplifier reverse Check to see if the hearing amplifier indicator amplifier is reversed is not lit

hearing amplifier		· ·
indicator lights are dark or dim	Dirty charging contacts	Clean the contacts of the hearing aid and the charger
not start	hearing amplifier not inserted correctly into charger	Insert hearing amplifier correctly into charger

Charging case fault self-checking table

*Note: If the problem persists, contact your hearing care professional for assistance

VIII TIPS FOR BETTER COMMUNICATION

It will take practice, time, and patience for your brain to adapt to the new sounds that your hearing amplifiers provide. Hearing is only part of how we share thoughts, ideas and feelings. Reading lips, facial expressions, and gestures can help the learning process and add to what amplification alone may miss.

Please review the following simple communication tips:

For You

- Move closer to and look at the speaker
- Sit face-to-face in a quiet room if possible

- Try out different locations to find the optimal places to listen
- Minimize distractions
- Background noises may be frustrating at first: remember, you have not heard them for a while
- Let others know what you need; keep in mind that people cannot "see" your hearing loss
- Develop realistic expectations of what your hearing amplifiers can and cannot do
- Better hearing with hearing amplifiers is a learned skill combining desire, practice, and patience. You will learn and adjust, it just takes a little time. Remember to be patient with yourself.

For Your Family and Friends Your family and friends are also affected by your hearing loss.

- Request that they: - Get your full attention before beginning to speak
- Look at you or sit face-to-face
- Speak clearly and at a normal rate and level: shouting can actually make understanding more difficult
- Rephrase rather than repeat the same words: different words may be easier to understand
- Minimize distractions while speaking

IX.TECHNICAL SPECIFICATION

Model	JH-A610	
Output. OSPL90 Max.	≤120dB+3dB	
Sound Gain (FOG)	<40dB	
EQ Input Noise	≤29dB+3dB	
Frequency Range(Not narrower than)	450Hz~4000Hz	
Working Current	5mA	
Total Harmonic Distortion	≤7%+3%	
Working voltage	d.c.3.7V	

Item	Charging Case
Charging case Input voltage	d.c.5.0V
Charging case Input current	300mA
Charging case Output current	35mA X2
Charging case Output voltage	d.c.4.2 V

X.Accessories List

Hearing amplifiers: 2 EarDome: 6
Cleanning Tools: 1 Manual: 1
USB Cable: 1

Adapte: 1 Input: 100-240V~50/60Hz 0.2A Output: 5V --- 1A 5W

* Optional accessories list:

XI. NORMALIZED SYMBOLS

(Follow operating instructions
^	B type applied part
<u> </u>	Disposal in accordance with Directive 2002/96/EC (WEEE)
C€	CE Labeling This product satisfies the requirements of the applicable European andnational directives
444	Manufacturer information: The manufacturer is: Huizhou Jinghao Medical Technology Co.,Ltd.
~	Date of manufacture
SN	Serial number
<u> </u>	Warning/ Danger: Improper use might cause serious injuries.
IP21	IP code of the device: this device's grade of against ingress of solid foreign objects – the access probe of $\geq \emptyset$ 12.5mm shall not penetrate; the grade of waterproof is vertically falling drops shall have no harmful effects.

-29-

XII. MAINTENANCE, STORAGE, AND DISPOSAL

Maintenance

- 1) We do not authorize any institution or individual to maintain and/or repair the product. If you suspect that the products may be in question, please contact us immediately.
- 2) The user must not attempt any repairs to the device or any of its accessories. Please contact us for any repair needs.
- 3) Opening of the equipment by unauthorized agencies is not allowed and will terminate any claim to warranty. Warning: No modification of this equipment is permitted.

Storage

- 1) Always store your devices in the Charging Case when not in use.
- 2) Do not store or expose the devices and/or case to extreme hot/cold temperatures, moist/humid environments, or shock/vibration.
- 3) Keep the devices and case in following environmental ranges:
- -10 C ∼55 C, 10%-90%RH, 700-1060 hPa

Disposal

Please dispose of the device in accordance with the directive 2002/96/EC – WEEE (Waste Electrical and Electronic Equipment). If you have any questions, please refer to your local authority responsible for waste disposal.

This limited warra

XIII WARRANTY

This limited warranty covers defects in material and workmanship for a period of two (2) years from the date of purchase, which includes the hearing devices, charger case, and cord within the warranty period.

Any damage caused by improper handling and care, exposure to elements or chemicals, or unauthorized service will not be covered by the warranty. All other damage claims excluded. A warranty claim must be submitted with the purchase receipt.

Web: leelpro.com Email: support@leelpro.com