



LincPlus Guide

With Special keys fuction

Published: April 2020


Version 1.0

About this guide

This guide is designed to describe the function of the special keys on Lincplus. For more info, see the content as below in this guide.

Special keys and function keys





Here are special keyboard shortcuts that use Fn keys:






Key	What it does
Fn + 	Lock or unlock touchpad
Fn + F1	F1
Fn + F2	F2
Fn + F3	F3
Fn + F4	F4
Fn + F5	F5
Fn + F6	F6

Fn + F7	F7
Fn + F8	F8
Fn + F9	F9
Fn + F10	F10
Fn + F11	F11
Fn + F12	F12
Fn + NumLk	Lock or unlock number keyboard



Here are special keyboard shortcuts that not use Fn keys:

Key	What it does
ESC	Escape
	Turn the LCD on /off
	Toggles audio muting on/off.
	Decreases the volume
	Increases the volume

	Opens Search
	Dims the screen
	Brightens the screen
	Previous
	Next
Pause	Plays or pauses audio or video
Insert	Insert
PrtSc	Print Screen
Delete	Delete