

Instruction

The controller can control two devices at the same time, and the third knob is used to adjust the arc length of the second device.



Adjustment of arc length
(clockwise screwing growth arc)

Adjust the lightning frequency
(clockwise twist to speed up the frequency)

Dial up audio mode
(Audio cable input audio required)

Dial to the middle to close
Dial down to normal mode


Controller upgraded to rechargeable version, please be sure to pay attention to the positive and negative poles when installing the battery, do not reverse connection!



Attention.


- 1, the first time you use please last connected to the host power cable, so as not to connect the process of sudden start.
- 2, The items in the dotted box are not included!
- 3, Normal music does not work well. You can download it from the download section of this website

Product List




All schematics in this guide are not drawn according to the actual scale, please prevail in kind!

一分钟上手指南



产品清单



本指南内所有示意图均未按照实际比例绘制，请以实物为准！！