


Instruction


Light up neon bubble



④

Turn on power switch


Toggle left to turn off
Toggle right to turn on




①

Put on the steel ball


(Put the top wire all inserted partially into the steel ball's hole)




Replacement of lighter




Press



Plug in




Hold Press



Loose

②

Plug in Host power connector




③

Plug in the Plug into the power outlet


Notes:

Please do not touch the lighter while working, turn off the power and wait for the lighter to cool completely before replacing it.

Product List




Main machine (L195mm W95mm H70mm)



9V/3A Power adapter



neon bubblex2




Flint lighterx3
(one of which is already installed on the device)





metal ball
(Diameter 38mm)

快速上手指南




更换打火机




注：

请不要在工作时触碰打火机，关闭电源后，待打火机完全冷却再更换。

产品清单



主机（长195mm宽95mm高70mm）



9V/3A 电源适配器



氖泡x2



打火机x3
(其中一个已安装在设备上)



开孔金属球
(直径38mm)