

2. When the power is cut off, the lamp will restart, calculating the previous timing. Such as, if it is timed for 6 hours, it will start counting again for 6 hours after the power is turned on.

3. Please remove the film before use.

4. ATTENTION:

- $\sqrt{\ }$ Please read the manual carefully before using it and follow all instructions.
- $\sqrt{}$ Please keep the switch away from water, which is not waterproof.
- $\sqrt{}$ You might void the warranty if the lamp body is accidentally dropped in the water.
- $\sqrt{}$ Please keep the light away from flammable items.
- $\sqrt{}$ Please unplug the power and contact the seller if the light is not working correctly, *For your safety,
- breaker that supplies power to the light. Then unplug and examine for the presence of water in the receptacle. 3.Close supervision is necessary when the light is used near children.

C.To avoid the possibility of the light plug getting wet, position the aquarium stand and tank to one side of a

in the figure below, should be arranged by the user for each cord connecting the light to the receptacle.

The "drip loop" is the part of the cord below the level of the receptacle or the connector. Suppose an

extension cord is used to prevent water from traveling along the cord and coming in contact with the

wall-mounted receptacle to prevent water from dripping onto the receptacle or plug. A "drip loop," shown

receptacle. If the plug or receptacle does get wet, DO NOT unplug the cord. Disconnect the fuse to the circuit

the light should be discarded.

\sqrt{P} Please remember that the temperature range for the light is 23~113°F. 5. PACKAGE INCLUDES:	 4.To avoid injury, do not touch or move hot parts. 5.Make sure the light is securely installed before operating it. 6.Read and observe all the important notices on the light. 7.If an extension cord is necessary, a cord with a proper rating should be used. A cord rated 	POWER CORD
●1x Led Light ●1xAC/DC power adaptor ●2xMetal brackets ●1xUser manual ①6. WARNING: Do not immerse the switch and the lamp in water to avoid possible electrical shock. If the switch falls into the water or becomes wet, do not touch it until you have unplugged it. Basic safety precautions should be observed, including the following:	for fewer amperes or watts than the appliance rating may overheat. Care should be taken to arrange the cord so it will not be tripped over or pulled. 8. The light is intended FOR HOUSEHOLD USE ONLY. 9. SAVE THIS USER MANUAL.	DRIP LOOP
 Read and follow this user manual strictly. 3 — 3 — 	7. WARRANTY:1.1-year free warranty.2.1-month free return.3. Free replacement for three month	ns. — 4 —

8. DISPOSAL

Do not dispose of this product as unsorted municipal waste. This product must not be disposed of together with domestic waste. It must be disposed of at an authorized place for recycling electrical

and electronic appliances.

By collecting and recycling waste, you help save natural resources and ensure the product is disposed of in an environmentally friendly way.



ct at a time.