

MUG & COFFEE WARMER

OA20013 Quick User Manual



OA20013-98-A1

In case of slight changes in the product, please refer to the real product.



life at any time.

Warm up your busy

Table of Contents +				
Operating Instructions	_/	02	~05	
Q&A	/	06		
Your MINI Hot Drink Bar Coun	teı	r	+	
Jasmine green tea		/	08	
Ear-hanging coffee		/	09	
Milk powder		/	10	
Honeybee and passion fruit black tea		/	11	
Warranty and Service Instructions	/	12-	~13	

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed including the following:

- 1. Read all instructions.
- 2. Do not touch hot surfaces. Use handles or knobs.
- 3. To protect against electrical shock do not immerse cord, plugs, or the appliance in water or other liquid.
- 4. Close supervision is necessary when any appliance is used by or near children.
- 5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- 6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- 7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- 8. Do not use outdoors.
- 9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
- 10. Do not place on or near a hot gas or electric burner, or in a heated oven.
- 11. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- 12. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- 13. Do not use appliance for other than intended use.
- 14. use only adapter # SK03T-1200200U.
- 15. Household use only.

Save these Instructions.

Power-on

Plug the power interface into the product; the light turns on in white color while the machine sends out a "Beep" and light turns off after 1 second, which indicates that the machine has been powered on normally.

In order to ensure electricity safety, please be sure to use BUYDEEM's original charger.



2-temperature settings

Touch the button to turn on the machine. Press the button for one time, the light turns on in yellow color, namely high temperature setting; Press the button for second time, the light turns on in white color, namely medium temperature setting; Press the button again to turn off the light, namely in a shutdown state.

During the temperature-rise process of the machine, the indicator light will be in a (breathing light) state. After the panel reaches the maximum temperature of 2-temperature settings, the light will be in a normally-on state.





Yellow light, namely high temperature, is suitable for tea, coffee and so on, and the beverage temperature is about 131°F.



White light, namely medium temperature, is suitable for milk powder and so on, and the beverage temperature is about 113°F.

^{*} The water temperature data is only for reference. According to the different cups used, there will be a certain deviation.

Automatic shut off



After turn-on, regardless of high and medium temperature switchover, the machine will automatically shut off as long as the continuous heating time reaches 12 hours.



【 Cancel automatic shut-off 】 within 10s after machine power-on, long press the switch for 3 seconds to cancel the automatic shut-off function; at the moment, hear a "Beep" and see that the yellow breathing light is on once.



If automatic shut-off is required to be restored, just re-power on and repeat the previous steps. When the white indicator light on, the breathing light is on once.

Fault feedback

Fault reason	Machine feedback	
NTC short circuit/open circuit	The yellow and white lights alternately flash with beeps.	
Heating system fault	The yellow light flashes with beeps.	

Stop the above fault feedback by clicking the switch, then contact the customer service as soon as possible and refer to "Warranty Service Instructions" on the page 14 for details.

Product model	OA20013	
Product name	BUYDEEM Mug & Coffee Warmer	
Rated input	DC 12V/24W	

Q&A / 06

Q: How to get a better heat preservation effect?

A: It is suggested to use thin-walled, flat, or slightly concave-bottomed mug for the best results, and use the cup with the cup lid so as to get a better heat preservation effect. In case of too low ambient temperature or too much water, the heat preservation effect will also be affected.

Q: Can the cold drink or the room temperature water be put on it?

A: BUYDEEM's Mug & Coffee Warmer is designed for heat preservation, not for heating drinks. If the room temperature water or the cold drink is put on it, the longer heating time is required. It is suggested to put the warm drink on it for better use experience.

Q: How to clean it if the drink spills out?

A: If the machine surface is dirty, please dip the soft wet cloth in the baking soda solution and then wipe it. Do not soak it to avoid that the internal electronic circuit is damaged.

If you have any other questions, please consult the customer service for answers.

Your MINI Hot Drink Bar Counter



The above cups are available for sale in BUYDEEM.



01 Put a bag of jasmine tea bag into the tea cup and pour hot water of $176\sim194^{\circ}F$ to brew for 3 minutes.

02 Remove the tea bag and then enjoy the fragrant hot tea.



Ear-banging coffee
You will feel warm and fragrant
from the first sip to the last sip.

Steps:

01 Put the ear-hanging bag on the cup and prepare water with a suitable temperature.

02 Pour a small amount of water to steam for 30 seconds and then pour the rest of the water.



Steps:

01 Pour half of the water of about 122°F firstly and then add an appropriate amount of milk powder to stir.

02 Pour the rest of the warm water and re-stir uniformly.



drink is still warm and delicious chat all afternoon, passion fruit black tea the

/ 11

Steps:

01 Put 10 g of black tea into the tea basket and pour the hot water of 185~203°F to brew for 2 minutes.

02 Add the passion fruit juice and your favorite fruit.

03 After the water is not too hot, add the honey and uniformly stir to enjoy.

If the product is obviously damaged, please contact the after-sales center of purchase channel and fill in the relevant information. The after-sales customer service personnel from will give you a satisfactory answer within 24 hours (except holidays).

- * The warranty is only limited to production defects and damages caused by correct use according to the user manual. If the damages are caused by improper use or other non-product quality problems, the maintenance fee will be charged.
- * If you need to buy product parts, please contact the after-sales center of purchase channel, or visit BUYDEEM website: buydeemglobal.com.

No free maintenance is allowed under the following circumstances:

- * No three-guarantee certificate and no valid invoice
- * Fault caused by failure to operate according to the user manual
- A. Damage caused by improper use, storage and maintenance
- B. Damage caused by assembly, disassembly and repair by our company's non-designated maintenance department
- C. Damage caused by force majeure

In order to protect the customers' interests, BUYDEEM reserves the right to modify the product features and the components so as to ensure the normal use of the product.

If you need more information and services or have any question, please visit BUYDEEM website: buydeemglobal.com.

ı	warranty card	BUYDEEM
		e product comes with a ONE-YEAR warranty. e the following information handy when
	Product Model No.:	Product Name :
	Factory Serial No.:	Purchase Date :
	Customer Name :	Customer Phone :
	Please feel free to contact us if you have a	ny questions or concerns.

If need more information, please visit BUYDEEM website: buydeemglobal.com