# Scan Dictionary Pen X7

**User Manual** 

# 

Introduction Description:

Translation scanner pen is an AI

product that integrates multiple

technologies such as image stitching.

OCR, translation dictionary, and

intelligent voice. In K12 learning.

overseas travel, business office and

other scenarios, the efficiency of

problem solving has been greatly

- ①:Power button
- ②:Voice button /volume+-
- ③:Type-C

improved.

- 4: Touch screen
- ⑤:TF card socket⑥:Voice button
- ⑦:Pentip

## Power button:

- 1. Power on/off: Press and hold the power button for more than 3 seconds, and you can choose to power on/off or restart.
- 2. Standby: Short press the power button to wake up or standby operation.

**Volume button:** Adjust the volume.

**Return button:** Short press or touch the return icon "<" to return.

**Touch screen:** Support tap, slide, touch the screen to select the desired function.

**Voice translation key:** It is the voice input button of the voice translation function, which can be used for Chinese and English translation.

### **Quick Guide:**

First of all, thank you very much for using our AI products!

## Work preparation before use:

1. Charge the device: Before using the device, please check whether the device has sufficient power. If the device cannot be turned on or the battery is insufficient, please use the dedicated charging cable to charge the device first. It is best to charge the device for 1 hour or the battery is sufficient before turning on the device. When charging the device when it is off. the screen will display the charging logo and battery percentage in about 8-10 seconds. When the device is turned on, the battery is marked with "lightning" in the upper right corner of the screen

**2. Network connection:** After turning on the device, connect to the network in the Settings-WLAN interface. This product works better when connected to the Internet. It can be connected to WIFI or mobile phone hotspots.

# 3. Scan operation

(1) Due to the high technical requirements of this product, during scanning operation, the equipment

should be inclined 70-90 degrees with the plane, and the front sight should be aligned with the center line of the text; (2) Press the pen tip and when the light starts to turn on, drag to the right to scan at a constant speed. During the scanning process, keep the pen tip light always on:

- (3) Sight the front sight at the blank space before the first text and start scanning. After the front sight has passed the last text, raise the tip of the pen again;
- (4) View the results and click on the screen to perform corresponding operations;

#### 4.Offline use

This product supports offline use, the function of Dictionary and off-line scanning translation can be used normally if you are not connected to the Internet; it is recommended that you use the Internet first for better results.

**5.** The top of the device screen displays some status information about the device, such as WIFI, power, and charging status.

Main function introduction: (In the home screen, if you directly press the pen tip to scan, the function of Dictionary is automatically used by default)

#### Scan Translation

Supports multi-language scanning, this function is suitable for students, business people and other people to use.

(1) Before scanning, you can select the language that needs to be scanned and that needs to be translated:



(2) After scanning, the screen will automatically display the results. Click on a word to view the details. Click will play the scanned content, and the second voice sign will play the translated content. Click to proceed Favorites, click to follow along.



## Voice Translation

Supports 112 languages online voice translation (with the software upgrade, the supported languages will increase). (1) In the voice translation interface, first select the corresponding language, you can choose the blue language for the main voice or the red language for the auxiliary voice;



(2) Long press the button on the device interface near the pen tip, the screen will display a blue microphone logo; on the contrary, press and hold

the other side button, the screen will display a red microphone logo, that is, the secondary language voice, release the button after speaking the corresponding language, the screen will Display the result and play.






#### **Photo Translation**

Support multi-language photo translation, suitable for one-time translation of paragraph text.

(1) Before taking a picture, you can choose the text language of the picture, and at the same time choose the language that needs to be translated:



(2) After the photo is translated, the result will be displayed on the screen, with the photo taken on the left and the translated text on the right.



## Dictionary

The dictionary function includes 6 dictionaries including Chinese to English, English to Chinese, English to Japanese, Chinese, idioms, and Tang poetry.

(1) Enter the word that needs to be queried, click Search to translate it directly, and to bookmark the word at the same time.



## Text Excerpt

 Select the text excerpt function, the screen will prompt you whether you need to synchronize;



(2) Select the synchronization function, click "Yes", the screen will display a QR code (mobile phone scan code instant synchronization) and web address (PC end enter the URL instant synchronization), otherwise click "No";



(3) The text will be displayed on the screen after scanning.

Smart Recording

Support up to 100 languages of recording to text.


(1) Click "Build record" in the upper right corner to add a recording



(2) Click the "microphone" to record



(3) Save the recording, view the recording



(4) Click the recording file to play the recording





#### vocabulary

Vocabulary functions include Primary school, junior high school, high school, CET-4, CET-6, Graduate, IELTS, TOEFL, SAT, GRE.

#### **Favorites**

View favorite words.

**Tools:** Including music, video, audio recorder, etc.

#### System settings

- 1. WLAN: Configure the WIFI network of the device. Please use this device first, and the effect will be better.
- 2. Bluetooth: Connect audio equipment such as Bluetooth headsets and Bluetooth speakers.
- 3. Volume adjustment: adjust the volume.
- 4. Brightness adjustment: adjust the brightness of the screen.
- 5. Date and time: View the date and time and set the time zone.
- 6. System update: check whether there is a newer software version and update it.
- 7. About this machine: Check the current device model, SN number, software version and other information.
- 8. The direction of holding the pen: You can choose the left/right hand to hold the pen according to your habit.

## **Precautions**

1. When upgrading, do not perform any operations during the program download and automatic program installation and restart.

- 2. Please connect to network first, the effect is better; the quality of the network will affect the use of the equipment, try to keep the network unblocked.
- 3. When scanning, keep the device inclined at 70-90 degrees, aim the front sight at the center of the text, and drag at a constant speed; if the recognition is inaccurate, you can try again.
- 4. Point the front sight to the blank space before the first letter and start scanning. After the front sight has passed the last letter, lift the pen.
- 5. During voice translation, the best effect is when the distance between the mouth and the MIC of the device is within 30CM.
- 6. Please speak coherently at a normal speed, and do not pause multiple times during the speech. The above situations may easily cause inaccurate translation.
- 7. Please make your pronunciation as standard as possible, and don't use mantras or slang.
- 8. The recognition result can be verified by displaying text on the screen, and if there is an error, it can be manually input and edited.
- If the words you say are recognized correctly, but the translation is not accurate, please change the way of expression.

## **Exception handling**

Forced shutdown: When the device cannot be shut down normally or crashes, press and hold the power button for more than 15 seconds to force shutdown and restart.

## **Product parameter**

	Name	Dictionary Scanner Pen	Type	Х7
	Size	156*43*14mm	N.W	93 g
	DC	5V/1A	Stand-by	7-10 day
	Charge interface	Type-C	Screen size	3.5"
	电池容量	1500mAh	Material	Metal

#### Caveat

- 1. Do not use this equipment in gas stations, fuel depots and other places where the use of electronic equipment is prohibited, otherwise it may cause an explosion or fire.
- 2. Please do not use unapproved or incompatible power supplies, chargers, which may cause fire, explosion or other hazards.
- 3. When charging is complete or not charging, please disconnect the charger from the device, and unplug the charger from the power socket.
- 4. It is strictly forbidden to place the device in an environment with excessively high or low temperature to avoid fire, explosion or product failure; it is strictly forbidden to put the device near heat sources such as ovens, electric heaters, etc., and do not put into fire; lithium batteries shall not be exposed to such as sunlight, Fire roasting or similar overheated environment.
- 5. It is strictly forbidden to allow children or pets to swallow the device or its accessories to avoid harm to it.

#### Disclaimer

- 1. Please read the product manual carefully before use, and operate strictly in accordance with the content of the manual.
- 2. This product is not responsible for the translation results.
- 3. This product is not waterproof, and the user is responsible for the damage to the machine caused by water ingress.

## **Warranty regulations**

- 1. The free warranty period of this product is 12 months.
- 2. During the warranty period, the faults caused by normal use in accordance with the manual (determined by our after-sales

personnel or our authorized service personnel) will be repaired free.

- 3. During the warranty period, the following conditions are not covered by the free warranty:
- Cannot provide warranty certificate and valid purchase certificate.
- 2) Unauthorized maintenance, misuse, collision, negligence, abuse, accident, incorrect use of this product, etc.
- 3) Because of prolonged exposure to strong light, fire or similar overheating environment.
- 4) Machine damage or performance failure caused by human factors such as water ingress.
- 5) Loss caused by the use of unqualified power supplies and adapters above 5V/2A.
- 4. The company is not responsible for any special, accidental or indirect loss and damage.

## Warranty certificate

Seller's name:

Where to buy:

Customer Name:

Phone number:

Address:

Product SN:

Date	Failure phenomenon	Maintenance records	Dealer