# How to start a meeting on Zoom?

After connecting your eMeet HS100 to the computer, start your meeting in Zoom with the following steps.

1. Click the settings icon

2. Select the "Audio" option, then set the microphone and speaker to "Echo cancellation speakerphone eMeet HS100".

Output Level:

Volume: 🔈 ▬▬▬▬▬▬▬▬▬●🔊

Microphone   Test Mic   Headset Microphone (eMeet M1) ⌄

Microphone (eMeet HS100)

Input Level: Same as system

Volume: Echo cancellation speakerphone (eMeet Luna)

Echo cancellation speakerphone (eMeet M0)

Echo cancellation speakerphone (eMeet M2)

◯ Use separate audio device to play ringtone

◯ Automatically join audio by computer when joining a meeting

◯ Always mute microphone when joining meeting

☑ Press and hold SPACE key to temporarily unmute yourself

☑ Sync buttons on headset

Settings   ✕

- General
- Video
- **Audio**
- Chat
- Virtual Background
- Recording
- Advanced Features
- Statistics
- Accessibility

Speaker   Test Speaker   Speakers (eMeet M1) ⌄

Speaker (eMeet HS100)

Output Level: Same as system

Volume: Echo cancellation speakerphone (eMeet Luna)

Intel® Display Audio HDMI2 (intel® Display)

Microphone   Test Mic   Echo cancellation speakerphone (eMeet M2)

Input Level: Echo cancellation speakerphone (eMeet M0)

Volume: 🔈 ▬▬▬▬▬▬●▬▬🔊

☑ Automatically adjust volume

◯ Use separate audio device to play ringtone

◯ Automatically join audio by computer when joining a meeting

◯ Always mute microphone when joining meeting

☑ Press and hold SPACE key to temporarily unmute yourself

☑ Sync buttons on headset