



How to start a meeting on Skype for Business?

After connecting your eMeet HS100 to the computer, start your meeting on Skype for Business as the following steps.

1. Click the lower left button to **select your primary device**.
2. Or click the **audio device settings** to enter the setting interface.



3. Select the "Audio Device" option, set the microphone and speaker to “Echo cancellation speakerphone eMeet HS100” .

- General
- Personal
- Contacts List
- Status
- My Picture
- Phones
- Alerts
- IM
- Ringtones and Sounds
- Audio Device**
- Video Device
- File Saving
- Recording
- Skype Meetings

Audio device

Select the device you want to use for audio calls: [Learn More](#)

Custom Device (Device specified below)

Customize your device (changes will apply to your next call):

Speaker Speaker (eMeet HS100)
Echo cancellation speakerphone (eMeet Luna)
Speaker (eMeet HS100)
Microphone Array (HD Webcam eMeet C980 Pro)
Speaker (Senary Audio)
耳机 (eMeet HS100 sample Hands-Free AG Audio)

Microphone

Ringer 耳机 (eMeet HS100 sample Hands-Free AG Audio)

Secondary ringer

Also ring: 耳机 (eMeet HS100 Stereo)

Unmute when my phone rings

Stereo audio playback

Allow stereo audio playback when available

OK Cancel Help

- General
- Personal
- Contacts List
- Status
- My Picture
- Phones
- Alerts
- IM
- Ringtones and Sounds
- Audio Device**
- Video Device
- File Saving
- Recording
- Skype Meetings

Audio device
Select the device you want to use for audio calls: [Learn More](#)

Custom Device
(Device specified below)

Customize your device (changes will apply to your next call):

Speaker Speaker (eMeet HS100)

Microphone Speaker (eMeet HS100)
Microphone Array (HD Webcam eMeet C980 Pro)
Speaker (eMeet HS100)
Microphone Array (Senary Audio)

Ringer 耳机 (eMeet HS100 sample Hands-Free AG Audio)

Secondary ringer

Also ring: 耳机 (eMeet HS100 Stereo)

Unmute when my phone rings

Stereo audio playback

Allow stereo audio playback when available

OK Cancel Help