


How to set up my device on the Mac system?

Select System Preferences > Sound

1. Setting Default Microphone


Under the Sound tab, click Input, and then select **EMEET CXXX** as the default microphone.



2. Set Default Speaker

Kindly remind: Only C980 Pro, C990, Jupiter has the speaker, which can be selected as the output device.

Under the Sound tab, click Output, and then select **EMEET CXXX** as the default speaker.



3. Camera Switching

—"Photo Booth" software as an example

- Open the "Photo Booth" software
- Click the "camera" option in the menu bar.
- Select "HD Webcam eMeet CXX"

