# How to start a meeting on Skype for Business?

After connecting your eMeet CXXX to the computer, start your meeting on Skype for Business as the following steps:

1. Click the lower left button to **select your primary device**.
2. Or click the **audio device settings** to enter the setting interface.

3. Select the **"Video Device"** option, then set the camera to "**HD Webcam eMeet CXXX**".

4. Select the **"Audio Device"** option, then set the microphone and speaker to "**HD Webcam eMeet CXXX**".

Kindly rremind: Only C980 Pro, C990, Jupiter has the speaker, which can be selected as the output device.

Skype for Business - Options ✕

Audio device

Select the device you want to use for audio calls: Learn More

| 🎤 | Custom Device |
| | (Device specified below) ⌄ |

Customize your device (changes will apply to your next call):

🔊 Speaker

HD Webcam eMeet C980 Pro ⌄
Echo cancellation speakerphone (eMeet Luna)
HD Webcam eMeet CXX
Speaker (eMeet HS100)
Speaker (Senary Audio)

🎙 Microphone   耳机 (eMeet HS100 sample Hands-Free AG Audio) ⌄

🔔 Ringer   耳机 (eMeet HS100 sample Hands-Free AG Audio)

▶

Secondary ringer

☐ Also ring: 耳机 (eMeet HS100 Stereo) ⌄

☐ Unmute when my phone rings

Stereo audio playback

☑ Allow stereo audio playback when available

OK   Cancel   Help

Skype for Business - Options

General
Personal
Contacts List
Status
My Picture
Phones
Alerts
IM
Ringtones and Sounds
Audio Device
Video Device
File Saving
Recording
Skype Meetings

Audio device

Select the device you want to use for audio calls:

Custom Device
(Device specified below)

Customize your device (changes will apply to your next call):

🔊 **Speaker**   HD Webcam eMeet C980 Pro   ▶

🎤 **Microphone**   HD Webcam eMeet C980 Pro
Speaker (eMeet HS100)
HD Webcam eMeet CXXX
Microphone Array (Senary Audio)

🔔 **Ringer**   耳机 (eMeet HS100 sample Hands-Free AG Audio)   ▶

Secondary ringer

☐ Also ring: 耳机 (eMeet HS100 Stereo)

☐ Unmute when my phone rings

Stereo audio playback

☑ Allow stereo audio playback when available

[OK]   [Cancel]   [Help]