

🥻 @EZTATTOO OFFICAL



# **OVERVIEW**







# **BASIC OPERATION**

### Power ON/ OFF

Press and Hold the power button (b) for two seconds to turn P2 DotFree.

### **Power START/STOP**

Clik power button to power the P2 DotFree Start or Stop.

### Adjust Voltage

Press or to adjust in 0.1V increments.

Press and Hold or to quickly adjust the voltage in 0.5V increments.

### Start/ Stop Built-in Timer

Press button to active your machine ON, the timing mode start.

Note: timer mode record in minutes, the maximum recording time is 23h 59mis.

The time is counting only when machine is running. The timer will reset the count when the P2 DotFree is being restarted.

## **Two Working Modes**

The P2 DotFree allows artists working in two type of operation modes.

- Normal Working Mode
- FM(frequency modulation) Dot Working Mode

Double-click power button to switch between Normal Working Mode.





#### 1. Normal Working Mode

1.1. If screen no status indicator display,The P2 DotFree in normal working mode.Working mode LED Indicator On.





#### 1.2. Push Mode

Press button at the same time,
Screen status indicator solid,

the machine active the push mode.

Note: In push mode the initial voltage output is 10V lasts for 1 second and then returns to normal voltage after.

### 2.FM Dot Working Mode

- 2.1. If screen status indicator flashes, The P2 DotFree.
- 2.2. P2 DotFree allows artist working for 5-speed frequency modulation, click Adjustment Ring.







# **OVERVIEW**



# **SPECIFICATIONS**

Motor	EZ Customized Swiss Motor
Material	Aircraft Aluminum
Stroken Length	3.5mm
Operating Voltage	5- 12V DC
Rpm	10000rpm±10%
Switch Frequency	60 - 160Hz
Needle Protrusion	0 - 4.5 mm
Dimensions(ΦX L)	32 x 158 mm
Weight	8oz(227g) with power pack



**Battery Capacity** 



Recharging Time



Powerpack Working Time