HIGH FEATURE

- Die-cast aluminum lighting body
- Frosted PC lens
- ETL listed
- Design for standard United States junction box
- ORB colors body finishing
- 3000K/4000K/5000K optional
- Suitable for Wet location Easy Installation
- Save energy



PRODUCT DIMENSIONS




customersupport@coloer.com / (626) 699-4666 -

1

SPECIFICATIONS

Model No	COS804/
Wattage	3.5W
Voltage	120VAC/60Hz
LED Type	SMD2835
Lumens	200lm(ORB)
Color Temp	3000K/4000K/5000K
CRI	>90
Product weight	0.43lbs
Beam Angle	30°
Lifespan	50,000hrs
Working temp	-4°F~104°F
Body Material	Aluminum
Lens Material	PC
Cable Material	Copper
Wet Location	IP65



customersupport@coloer.com / (626) 699-4666

2

UNPACKING CHECK

PLEASE check and make sure that there are no signs of physical damage to the product when unpacking. DO NOT use damagedproducts.

- All electrical connections must be made in accordance withocal and National Electrical Code(N. E. C.)standards.
- ONLY use UL or IEC approved wires for the input/output connections.
- Due to the risk of fire or electrical shock, the installation of thisproduct requires the knowledge of the electrical systems. If NO qualified. DO NOT attempt the installation and contact aqualified electrician.
- TURN OFF THE POWER before beginning the installation inspection or removal.
- Use ALL necessary precautions while performing this procedure.
- IT IS IMPERATIVE THAT THE OUTLET BOX IS PROPERLY

GROUNDED

- DO NOT REVERSE THE LIVE AND NEUTRAL CONNECTIONS, OTHERWISE SAFETY WILL BE COMPROMISED
- The outlet box must be recessed in the wall and cannot be protruding from the wall.

NOTE: This is an integrated LED fixture, there are nobulbs to replace.







customersupport@coloer.com / (626) 699-4666

3

PRODUCT DIAGRAM

1. Outlet box(NOT INCLUDED)

3. Mounting bracket

4. White fixture wire

5. Black fixture wire

6. Fixture ground wire


2. Mounting screws

9. House ground wire

8. Face plate 10. white supply wire 11. Black supply wire

7 Wire nuts

12. 3CCT switch



Step 1. Pull the power supply wires (7) out from the outlet box (1). Mount the mounting bracket (3) to the outlet box (1) using the mounting screws (2).

Step 2. Use the wire nuts(4)to connect the fixture wires (6)to the power supply wires(7). (white-neutral, Black-live). Carefully tuck the wires inside the outlet box(1)

Step 3. Select the color temperature from 3000K, 4000K, and 5000K with the toggle switch.

Step 4 Span the face plate(5)onto the fixture

Step 5. Use sealant (not include), to fill the gap between the face plate (5)and the outlet box (1) to improve the water resistance

customersupport@coloer.com / (626) 699-4666 -

This product is compatible with most common residential typedimmers. Dimming performance will depend upon dimmer dimmer settings (dimmers with adjustments to brightnessrange), wiring method, and the number of LED modules.

For best results, set dimmer position at maximum before adjusting to a lower light level. The following dimmers are recommended:

Center luminance Spot diameter

Lutron DV-600P, Lutron PD-6WCL, Lutron MACL-153M, Lutron-603p; Leviton DSL06,Leviton RNL06

Height Average illumination

TROUBLE SHOOTING

- If the fixture does not light: · Check the power to see if it is on.
- Check STEP2 of the fixture installation, and make sure that all wire connections are connected properly.
- · Check to see if the fixture is properly grounded.
- Check the switch to ensure that there aren't any defects.
- Check the fuse/circuit breaker for trips.

CLEANING AND MAINTENANCE

Ensure that the fixture's temperature is cool enough to touch.DO NOT clean or perform maintenance while the fisture is energized

- · Clean the lens and fixture with a non-abrasive cleaning solution.
- DO NOT open the fixture to clean the LED bulb.DON NOT TOUCH THE LED BULB
- DO NOT SPRAY LIQUID DIRECTLY ON TO THE LEDs, LED driver or he wiring.

WARRANTY

5 vears warranty

We warrants this light fixture against defects in material and workmanship for lifetime from the date purchase. If within this period the product is found to be defective in material or workmanship, the product must be returned with a copy of receipt as a proof purchase to the original place of purchase. The retailer will, at its option, repair, replace, or refund the purchase the price to the original purchaser. Warranty does not include damages due to misuse,accidents, improper handling and /or installation, incidental, or consequential damages. As some states do not allow exclusions or limitations on the implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights and you may also have other rights that vary from state to state.

> customersupport@coloer.com / (626) 699-4666 -6

OLCER **USER MANUAL**

> COS804A DIMMABLE LED

Indoor&Outdoor Step Light

www.coloer.com



Call us! (626) 699-4666

3979 East Guasti Rd Unit A, Ontario, CA 91761

THANK YOU FOR CHOOSING COLCER

Please do not hesitate to contact us: □ customersupport@coloer.com

If you have any installation problems or need help

customersupport@coloer.com / (626) 699-4666 -

5

Beam Angle:6.6