

GiveBest[®]

MINI PLUG-IN CERAMIC HEATER


Model: MH-04

INSTRUCTION MANUAL
READ AND SAVE THIS INSTRUCTION



Please read these Instructions carefully and keep for future reference

FEATURES



OPERATING INSTRUCTIONS

1. Find an open wall plug that is clear of any obstructions such as curtains or hanging wall panels.
2. Remove your heater from the box and plug into the wall outlet.
3. Flip the Power switch on the side of the heater to turn on the heater.
4. The heater will emit heat from the Heater Front. Ensure there are no obstructions blocking the heat flow for best results.
5. Press the Power button to turn off the heater.


NOTE:

Turning off the heater will stop the heating process only. The fan will continue to work for 1 minute to allow for the internal ceramic heating element to cool. After 1 minute, the heater will shut down automatically.

CAUTION:

Do NOT plug this heater into a surge protector. This heater must be plugged in upright. Do NOT use this heater plugged in lying down.

CONTROL PANEL



SYMBOL	FUNCTION
"Power"	On/Standby
"Temp. +"	Increase temperature
"Temp. -"	Decrease temperature
"Timer"	Timer

On/ Standby

Ensure your heater is turned on by flipping the Power switch located on the side of your heater.

Press the "Power" button to have the heater remain on.

Press the "Power" button again to have the heater switch to standby mode. In standby mode, the heater will not operate until you press the "Power" button again to activate the heater.

Temperature

Adjust the heater to your desired temperature setting by pressing the "Temp + / -" buttons. The temperature will be displayed on the LED display.

Timer - Auto Shut-off

To use this heater's auto shut-off timer, ensure your heater is turned on. Press the "Timer" button, and the LED display show the number of hours you want the heater to run before turning off automatically. Keep pressing the "Timer" button until you reach your desired set time. Once the LED display shows the desired number of hours, wait 3 seconds without pressing any buttons. The heater will set a timer, and shut of automatically after the set time.

Pressing the "Timer" button allows you to scroll through 1 and 12 hours, in 1 hour increments.

To turn off the auto shut-off timer, press the "Timer" button until the LED display shows "0."

Timer - Auto Power-on

To use this heater's auto power-on timer, ensure your heater is turned off. Press the "Timer" button, and the LED display show the number of hours you want the heater to wait before turning on automatically. Keep pressing the "Timer" button until you reach your desired set time. Once the LED display shows the desired number of hours, wait 3 seconds without pressing any buttons. The heater will set a timer, and shut of automatically after the set time.

CAUTION: Do NOT use the Auto Power-On function on this heater if you are not at home. This feature should not be used without an adult present.

CLEANING

1. Flip the Power switch to turn off the heater.
2. Unplug the unit and let it cool completely
3. To keep the heater clean, the outer shell may be cleaned with a soft, damp cloth. You may use a mild detergent if necessary. After cleaning, dry the unit with a soft cloth. **CAUTION: DO NOT** let liquid enter the heater.
4. **DO NOT** use alcohol, gasoline, abrasive powders, furniture polish, or rough brushes to clean the heater. This may cause damage or deterioration to the surface of the heater.
5. **DO NOT** immerse the heater in water.
6. Wait until the unit is completely dry before use.

OVERHEAT SAFETY FEATURE

This heater is equipped with an internal overheat safety feature. When the heater's internal components reach a certain temperature that may cause overheating and possible fire, the heater will automatically shut off.

WARNING: It is normal for the rear of the heater to feel warm to the touch; however, a loose fit between the outlet and the plug may cause overheating of the plug. If this occurs, try inserting the plug into a different outlet. Contact a qualified electrician to inspect the original outlet for damage.

STORAGE

Store the heater in a cool, dry location when not in use. To prevent dust and dirt build-up, use the original packaging to repack the unit.

BASIC TROUBLESHOOTING

If the heater will not operate, please check the following before seeking repair advice:

1. Check if the plug is plugged into an electrical outlet, if not, plug in.
2. Check if electricity to the electrical outlet is working.

SAFETY INSTRUCTIONS

WARNING

READ ALL INSTRUCTIONS BEFORE USING THIS FAN.
TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY:

- Read ALL instructions before using this unit.
 - CAUTION: Risk of Electric Shock. DO NOT open or try to repair the heater yourself.
 - This heater may get hot when in use. To avoid burns, DO NOT let bare skin touch hot surfaces. If provided, use handles when moving this heater.
 - Keep combustible materials, such as furniture, pillows, bedding, paper, clothes, and curtains at least 3 ft from the front of the heater and keep them away from the sides, top, and rear. DO NOT place towels or other objects on the heater.
 - Extreme caution is necessary when any heater is used by or near children or the disabled, or when the heater is left operating and unattended.
 - DO NOT operate any heater with a damaged cord or after the heater malfunctions, has been dropped or damaged in any manner. Return heater to authorized service facility for examination, electrical or mechanical adjustment, or repair.
 - This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. NEVER locate heater where it may fall into a bathtub or other water container. To protect against electrical hazards, DO NOT immerse in water or other liquids.
 - DO NOT touch the power button, heater front, or plug with a wet hand.
 - DO NOT insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
 - To prevent a possible fire, DO NOT block the air intakes or exhaust in any manner. DO NOT use on soft surfaces, like a bed, where openings may become blocked.
 - A heater has hot and arcing or sparking parts inside. DO NOT use in areas where gasoline, paint, explosive and/or flammable liquids are used or stored. Keep unit away from heated surfaces and open flames.
 - Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
 - To avoid fire or shock hazard, plug the unit directly into a 220 V AC electrical outlet.
 - To disconnect heater, press the Power button to turn the heater off, then remove plug from outlet.
 - Always unplug the unit before moving or cleaning, or whenever the heater is not in use.
 - Use only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons. The use of attachments not recommended or sold by unauthorized dealers may cause hazards.
 - DO NOT use outdoors.
- WARNING: To reduce the risk of fire or electric shock, DO NOT use this unit with any solid-state speed control device.
- DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. Qualified personnel should perform all servicing only.
 - Connect to properly grounded outlets only.
 - Save these instructions.

SERVICE INSTRUCTIONS:

- Do NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void the warranty.
- If you have any questions regarding this unit's operation or believe any repair is necessary.
- please write to us at sales@brighttownstore.com.
- If you have any other question or comments, feel free to write to us:

For customer service and warranty, contact us here

✉ support@brighttown.com

☎ US +1 (888) 550 1319
Mon-Fri 8AM-10PM(EST)

Brand family: Brighttown, Givebest

