Quick Guide and Tips for ETOE ТO A1191 Projector

If it's your first time using the projector, please follow below instructions:

- · Pull off the protective film of the lens.
- · Adjust the focus by pressing button 5 & 6 to get a clear & sharp picture.
- Keystone Function: Press button 3&40to adjust the trapezoid picture.
- · Focus Adjustment: Adjust the focus with button 6 & 6
- If you move the projector, adjust the focus and keystone again for the best picture.



If the projector need to be placed center-off, ETOE projector provide keystone function to correct it.

CASE 1 Place the projector toward the wall/screen, but not flatly



- ETOE projector will adjust the picture automatically back to square picture.
- · You can also press the left & right arrow button(3&4) of the remote to adjust it manually.

CASE 2 Place the projector in a tilted angle towards the wall/screen



- Apply the 4-point correction function on the "Setting>Projection setting" of the homepage.
 - Step 1: Press "OK" 10 of the remote to choose the corner of the projected image that you want to correct, as showed on the image 3.1



- Step 2: Press the same arrow of the remote 9 that showed on the screen to adjust the angle of the corner, as showed on the image 3.2

There are two wireless ways to share the screen of iPhone/iPad Macbook:

iOS AP Mirroring Mode

- 1. Turn on the Wi-Fi on your iPhone/iPad/Macbook and connect to the mentioned Wi-Fi on the screen;
- 2. Tap Screen Mirrorring in the control center of the iOS device or Macbook, and then choose ETOE_Projector model that showed on the projected screen.
- 3. The Mode should be chosen firstly whenever you mirror your device through this mode.

iOS Wi-Fi Mirroring Mode

- 1. Go back to the Home Page to "choose Settings>Network", and connect it to your Wi-Fi.
- 2. Turn on the Wi-Fi on your iPhone/iPad/Macbook, and connect it to the same Wi-Fi network.
- 3. Tap Screen Mirroring _____, and then choose ETOE_Projector model that showed on the projected screen.

ETOE projector supports firestick connection.

Step1 : Insert the HDMI of the firestick to the HDMI port 7 ot the projector ;

Step2 : ETOE projector can supply power for the firestick. Just connect the charging cable of the firestick to the USB port 6 of the projector



Frequently Asked Questions

Q: I fail to use the iOS Wi-Fi Mirroring Mode with my iphone. What should I do?

A: Please check your Wi-Fi network to see if it's stable. If your Wi-Fi network is not stable, the Wi-Fi Mirroring Mode won't work well. Here's the way to fix it.

- 1. Try to disconnect & connect the Wi-Fi with your device and the ETOE projector.
- 2. Relaunch your Wi-Fi router.

Q: Can I use it without power cable?

A: ETOE A1171 projector doesn't include battery inside so it can only be powerd by power cable.

Q: I can't watch videos on youtube with the projector. Is it normal?

A: The issue you have on hands of ETOE projector mainly caused by the limitation of iphone system iOS. We have adjusted the software in ETOE projectors to help to mirror content from Youtube or other channels. Please contact us through Amazon for help.

Please notice that due to the limitation of Apple. Copyrighted content from Netflix, Hulu, and similar services CANNOT be mirrored or screencast.

Q: The video cast on the screen is not clear as it showed on the device.

A: Please notice that to let the customer have a fluent viewing experience, most video providers will choose the suitable resolution under the current internet environment. Please adjust the resolution of the video to 1080p manually to get a clear picture with ETOE projector.

Moreover, please adjust the keystone and focus every time you change the distance and direction of the projector.

Q: I can't connect my device to the projector with Bluetooth.

A: Please try to disconnect other devices from your Bluetooth device, as they might influence the connection with the projector.