

# USER MANUAL

## Monochrome Laser Rain

First of all, thank you for purchasing our products, please read this manual carefully before use, and operate according to the regulations, so as to avoid personal safety and lamp damage caused by misuse.

### ● Instructions for use:


After opening the packing box, carefully check whether the lamp is damaged due to transportation, such as whether the screws are loose, whether the lens is broken, etc. Please check before power on. Check whether the position of the lamp is correct and stable, and check whether the voltage of the power supply is the same as that of this product. This equipment belongs to Class 1 protection equipment, so the ground wire of the power supply must be grounded, and this must be done by professionals. Check whether the power supply voltage is normal before use.

### ● Technical Data Sheet

serial number	Rated voltage	AC110-230V $\pm 10\%$ /50Hz $\sim$ 60Hz
1	rated power	10W _
2	laser power	Red: 50 0mw wavelength 638 nm Or blue: 500 mw wavelength 450nm
3	laser color	red or blue
4	working environment	indoor
5	control method	DMX512 mode
6	control channel	2

### ● Function mode setting:

Display panel



MENU main menu switching UP parameter adjustment  
DOWN parameter adjustment ENTER confirm

● **Mode setting**

A001	A512	DMX512 mode, address code setting
PXXX	P1-1~P1-9	Self-propelled mode setting
	P2-1~P2-9	

● **DMX-512 control channel function table**

aisle	channel value	Functional description
CH1	0	Turn off all lights
	1-255	Total dimming, from dark to bright
CH2	0-255	Strobe, from slow to fast

● **Maintenance:**

1. Try to prevent dust, dirt and smoke oil from artificially laying or even flowing into the lamp body, and keep the lamps as clean as possible in the use environment;
2. Please use a professional glass cleaning agent every month and clean the reflective lens with flannelette to ensure the maximum brightness output of the laser and prolong the service life of the light source.