




EVER ADVANCED

INSTRUCTIONS | Camping Chair(FC-143XL)

FOLDING INSTRUCTIONS:



To Fold, place chair on even ground. Place one hand on the upper back side tube and the other hand on the lower seat side tube. Push the seat towards the back while leaning the chair slightly back on the rear feet and raise the front legs off the ground.

**EVER ADVANCED,
EVER FEARLESS**

Warranty

The EA Directors Chair is covered by 12-month quality warranty.

Contact Us

Website:www.everadvanced.com

Email:info@everadvanced.com

 @everadvanced

 @everadvanced

Safety Tips

- This folding chair holds a maximum weight of 500lbs. Do not exceed.
- No leaning on/over the chair's armrest.
- Care should be taken to avoid tipping chair while in the act of sitting or while seated.
- Use folding chair only on level ground.
- To avoid injuries to fingers, use care when folding the chair.