

12x14 cm

vLinker FS USB

Getting Started

FEPS



3Mbps

Getting Started

- 1 Download and install the app(FORScan for Windows)



FORScan: [forscan.app](https://www.forscan.com)

- 2 Connect vLinker FS to the Laptop/PC


Plug in the USB, the red light flashes once and the blue light is always on.

- 3 Plug vLinker FS into the vehicle

Insert the OBD, the blue light and the green light are always on.

- 4 Turn vehicle ignition to "ON" position

For push-button start vehicles, press "start" button twice without pressing the brake.




- 5 Launch FORScan for Windows


In the app, click the connect "  " button. Your vLinker FS is now ready to use.

FORScan Operation Guide

- 1 Download USB driver & FORScan application. Open FTDI official website: <https://ftdichip.com> Choose **DRIVERS**, and then choose **VCP Drivers**. Please select the driver according to your computer system.
- 2 Open FORScan, click "Settings" > "Connection" - Connection type - FTDI > "Baud rate" - 115.2 Kbps Remember to choose **Auto-increase**. Set up as shown in the figure.



- 3 Run the FORScan app and ready to test.



Problem & Solutions

