




Scan the QR code to get multilingual user manual.



## STONE M2 TWS EARBUDS USER MANUAL



### Packing list




Charging Case  
x1



Earbuds  
(with size M caps)  
x2



Earbuds Caps  
(size L & S)  
x4



Charging Cable  
x1



User Manual  
x1



### Specifications

Product model: STONE M2

Wireless Version: 5.3

Distance: 10M

Speaker Impedance:  $32\Omega \pm 10\%$

Frequency: 20Hz-20KHz

Speaker receiving sensitivity:  
106±3dB

Play time: about 8 hours


(60% of the volume)

Stand time: about 200 hours

Charging time: about 2 hours

Charge interface: Type-C

Battery capacity:  
300mAh for charging case



LED indicator

MFB  
Touch panel



Charging  
port



### Please read the instructions before use

- Keep the product away from extremely hot and cold environments, it will damage the battery and circuit.
- Avoid liquid immersion into the product.
- Do not disassemble the product.
- Do not use concentrated chemical products or detergents to clean the product.
- Use only 5V/1A power supply. Connecting the power supply voltage too high may cause serious damage.
- Do not randomly discard or place the product near fire or high temperature to avoid the danger of explosion.



### Problem handling

- Can be connected but there is no sound:  
Click the right earbuds to increase the volume.
- One of earbuds cannot be charge:  
Clean the charging contact of the earbuds and the charging case.
- One of the earbuds cannot be connected:  
Reset the earbuds.
- If the earbuds cannot be charged, please activate the warranty and contact us for after-sales service.



Please clean the charging contacts of the earbuds and charging case frequently to avoid charging failures.

## Method of operation




Power On

1. Take out the earbuds (Earbuds auto power on).

Connect

XINJI STONE M2

2. After open the phone Bluetooth, Click the earbuds name to pairing.



## Operation



Play /Pause



Answer



Voice Assistant



Switch Song



Reject Call



Power on/off



Adjust Volume



Hang up

×1: Click Once  
 ×2: Click 2 times  
 ×3: Click 3 times  
 2s: Press and hold for 2 seconds

## Reset

If earbuds has any connection or function problems, please reset the earbuds.

1.Disconnect the earbuds from the phone.

2.Perform a 4-tap sequence on the L/R earphones, and power off after hearing the prompt.

3.After placing the earphones into the charging case, take them out again, and wait for the earphones to auto-pair.

This manual is for reference only, the actual product may vary. Please refer to the actual product.

## Warranty card

Customer information		Seller information	
Name		Name	
Add.		Add.	
E-mail		Purchase Date	
P.C.		Product model	
Tel		Invoice number	
Date	Malfunction		Process result