


# **USER MANUAL**



# LiFePO<sub>4</sub> BATTERY PACK Model: LFP1220

- Safer
- Lighter Weight

- Longer Life
   Increased Flexibility
- Higher Power
   Wider Temperature Range

# PRODUCT SPECIFICATIONS

$\rightarrow$	F	lectr	ical	S	pecit	ficat	ions

Nominal Voltage 12.8V Nominal Capacity 20Ah (0.2C, 25°C) Energy 256Wh Resistance  $\leq 50 m\Omega$  Cell Type LiFePO4

# ➤ Mechanical Specifications

Dimensions (L x W x H)

Net Weight

Terminal Type

Case Material

About 181\*76.5\*167mm

About 2.8kg

M6

About 2.8kg

About 3.8kg

# ➤ Charge Specifications

Charge Voltage 14.4V (14.6V Max)
Standard Charge Current 4A
Maximum Charge Current 10A

Discharge Specifications
Maximum Continuous Discharge Current 20A
Discharge Cut-Off Voltage About 10V

# ➤ Temperature Specifications

Charge Temperature 0°C to 50°C
Discharge Temperature -20°C to 60°C
Storage Temperature 0°C to 45°C

# ➤ Compliance Specifications


Certifications CE、UN38.3、FCC、UL1642(cells)&IEC62133(cells)
Shipping Classification UN3480, CLASS9

➤ Cycle Life 5000+ (0.2C 25°C 80%DOD)

#### **ATTENTION**


- ⚠ Please ensure that you have read this manual carefully before using this product.
- △ Can not be used as starting battery.
- △ Do not immerse the battery in water.
- ⚠ Do not let children touch or operate this product.
- ⚠ Do not let the product's environment temperature drop suddenly to avoid its internal condensation phenomenon.
- △ Please do not expose this product to fire, heat source, direct sunlight or high temperature over 60°C.

#### DIMENSIONAL SPECIFICATIONS




# DIY BATTERY PACKS

# ➤ Modules in Parallel



# ➤ Modules in Series





- The model can support at most 4 pieces in series and 4 pieces in parallel.
- Before the connection, the voltage difference between the batteries should be ≤0.3V.
- The total working current after series and parallel connection cannot exceed the working current specified by the single battery pack.

#### AFTER-SALES SERVICE

The warranty period is 12 months.

During the warranty period, our company will provide free maintenance and replacement parts for defects in material, technology and damage caused by non-human reasons.

During the warranty period, the following situations can not obtain free maintenance services:

- 1. Disassemble the product without permission.
- 2. Surface damage is not covered by the warranty.
- 3. The user does not use the product according to the instructions.
- 4. Failure or damage caused by accident, human, environmental factors (operation error, collision, unreasonable voltage, damp, etc.)
- 5. Product packaging and accessories are not under warranty.

Get 24/7 Assistance at



Visit: https://goldenmate.afterservice.vip Email: goldenmate@afterservice.vip

Call: +1 (877) 591 5875 (Toll-free)



Shandong Goldencell Power Technology Co., Ltd.