

Instruction manual

Little Bee Smart 100MM Pure Beam

Thank you for choosing our Pure Beam, For your personal safety and better use of this product, Please read the manual carefully before using, Follow the procedure, To avoid misuse of personal safety damage and lamp damage.

一、 Packing list

After unpacking, Please check the product is qualified, Count all accessories. NO, please contact the distributor!

number	Name	Color	Unit	Quantity
1	Lamps and lanterns	Black	Station	1
2	Power Cord	Black	Ordinance	1
3	Handle	Black	PCS	1
4	Hexagon screws	Black	PCS	2
5	Instructions	Black and white	PCS	1

二、 Appearance and LED Function

Switch settings by pressing a button:

*Click “MENU” Key switch function.

*Click “UP/DOWN” Switch function or set address code.

*After switching functions, Click “ENTER” Key save function.



三、 Technical parameters

number	Category	Parameter
1	Power supply	AC95V-245V/50Hz
2	Product power	80W
3	Lamp beads	8 colors
4	Control	1 60W white light lamp bead
5	Mode of operation	international DMX512, 7 channels
6	Dimming mode	DMX512, master/slave, self-propelled, voice control
7	Strobe	0~100% ultra-smooth dimming
8	Heat dissipation	20 times/second

四、DMX Channel function:

This product have 7 channels, Specific controls are as follows:

channels	Function	DMX Value	Description
1	X-axis motor	0-255	0~255 0-540 degree rotation
2	Y-axis motor	0-255	0~255 0-180 degree rotation
3	XY axis motor speed	0-255	0~255 speed from fast to slow
4	dimming	0-255	Linear dimming from dark to light
5	Stroboscopic	0-9	None
		10-255	Slow to fast
6	colour disk	0-255	0-35 (switch one color every 5 intervals),35-127 (the last color), 127-255 (color moves from fast to slow)
7	Macro function control	0-50	Channels 1 to 7 are valid
		51-150	autorun
		150-255	voice
		251-255	3 second reset

menu

addr	A001-A512	Set 512 address
Chnd	15ch	Display the number of channels
Shou(running mode)	d512	DMX512 mode
	auto	Self-propelled mode
	sond	Audio Mode
Sens	0-100	Voice control zero density setting
LED	oFF	Display is always on
	on	Show Hibernate
Disp	OFF	Show Forward
	ON	Show Reverse
rst	Yes/no	Manual reset

五、Other parameters

number	Category	Parameters/details
1	Packaging	Standardized cartons
2	Size of inner box	34*27*24CM
3	Cartons	57*37*52
4	N.W	3.15KG
5	G.W	3.8KG
6	Carton weight	16.2KG
7	Power connection	Power Cord
8	Signal connection	Signal input line/output line
9	Material	Product materials: Ferrous, The shell: ABS