

Product Name: LED 400W strobe  
Voltage: AC110V ~ 240V 50-60Hz  
Power: 400W  
Source: LED COB integrated lamp beads  
Lamp quantity: 4 PCS  
Lamp beads power: 100W / PCS  
Color: white  
Color temperature: 6500 ~ 7200K  
Channels: 12 ch / 6 ch / 1 ch mode  
Control mode: DMX / AUTO / Sound / DETONATOR  
controller control  
Function: Strboe / Lighting / Photography lighting  
Strobe Speed: 0~20/S  
Packing: pearl cotton or flight case  
Protection class: IP20  
Size: 54 \* 32 \* 20.5CM  
Weight: 8.0KG

## RGB LED 400W Colouring Strobe

### menu Manual



12 DMX channels		
CH	VALUE	FUNCTION
CH1	0	dimmer
	1-255	from dark to bright
CH2	0	speed
	1-255	from slow to fast
CH3	0	red color
	1-255	from dark to bright
CH4	0	green color
	1-255	from dark to bright
CH5	0	blue color
	1-255	from dark to bright
CH6	0-15	no effect
	16-255	sound mode
CH7	0-15	no effect
	16-75	RGB color gradual change. Push CH2 can add strobe effect
	76-135	ramp down ramp up down
	136-195	RGB color jump change with strobe effect
	196-255	RGB color pulse change with strobe effect
CH8	4	effect speed
	5-255	color changing effect speed from slow to fast
CH9	0	Color wash effect ( no strobe effect)
	1-255	red color from dark to bright
CH10	0	Color wash effect ( no strobe effect)
	1-255	green color from dark to bright
CH11	0	Color wash effect ( no strobe effect)
	1-255	blue color from dark to bright
CH12	0	no effect
	1-255	RGB full color on from dark to bright ( no strobe effect)
8 DMX channels		
CH1	0	dimmer
	1-255	from dark to bright
CH2	0	red color
	1-255	from dark to bright
CH3	0	green color
	1-255	from dark to bright
CH4	0	blue color
	1-255	from dark to bright
CH5	0	strobe speed
	1-255	from slow to fast
CH6	0-15	no effect
	16-75	RGB color gradual change. Add CH2 can add strobe effect
	76-135	ramp down ramp up down
	136-195	RGB color jump change with strobe effect
	196-255	RGB color pulse change with strobe effect
CH7	0	effect speed
	1-255	color changing effect speed from slow to fast
CH8	0	no effect
	1-255	sound mode(full color on)
2 Channels mode		
CH1	0	dimmer
	1-255	from dark to bright
CH2	0	speed
	1-255	from slow to fast

NO.	Display menu	Features
1	Address	001-512
2	Run Mod	Slve
		Auto
		Sond
3	Chan Mod	02CH
		08CH
		10CH
4	Dmx Clea	Off
		On
5	Display	LigtOff
		Ligh
		1Min
		2Min
		3Min
	MenuBak	Off
		1Min
		2Min
		3Min
		Off
6	Balance	LigtFlh
		Off
		On
7	Manual	Red
		Green
		Blue
		50-255
		Dimmer
		Shutter
		Red
		Green
Blue		
8	DefCfig	0-255
		Sound
9	Version	Case
		CaseSp
		RGB
		Off
		On
		Vxxx

Buttons S1: return to the previous menu interface; (<,>, <Sub>)

Buttons S2: turn on the menu (or value -); (longpress 1S even after reduction)

Buttons S3: turn down menu (or numerical +); (longpress 1S even after adding)

Buttons S4: enter menu settings or save the settings and return to the previous menu

<: Menu selection instruction

>: Function selection instruction

<Sub>: have a summer menu instructions