
Item Number: A03894

WARNING (To reduce the risk of fire, electric shock, or injury to persons):

- 1. We suggest installation by a **licensed electrician**.
- 2. Please read the instruction carefully and save it as you may need it at later time.
- 3. Before you start, **NEVER** attempt any work without shutting off the electricity until the work is done. A). Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "**OFF**" position. B). Place the wall switch in the "**OFF**" position.
- 4. Mounting surface should be clean, dry, flat, strong enough and 1/4" larger than the canopy on all side. Any gaps between the mounting surface and canopy exceeding 3/16" should be corrected as required.
- 5. Make sure that the ceiling or wall can stand the weight of the lamp before fixture.
- 6. Make sure the voltage you are using is **120V**. The maximum wattage is **40W** per bulb.
- 7. Keep the lamp away from acidic and basic objects in case of damaging the surface of the lamp.
- 8. When replacing bulb, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly.
- 9. The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must be understood that common sense, caution and care must be used with any electrical products.

IMAGE FOR FINISHED PRODUCT:



TOOLS REQUIRED (NOT INCLUDED):

Before doing assembly and installation please prepare the needed tools as below picture


				Canada Contraction of the second of the seco
Ladder	Phillips head.flat blade screwdriver	Electrical tape	Pliers	Wire cutter/Stripper
(C) Mounting plate (UTLET BOX	
(D) Green ground screw (1)(E) Canopy (1)		A	C C	
(F) Swivel joint (1)		В—	D	
(G) Knob ball (2)		D	E	
(H) Tube			¦ ¶ - F └ │ └ - G	
(I) Fixture loop (1)			H	
(J) Shorter arm (2)				
(K) Longish arm (2)(L) Screw (12)				
(M) Cover (4)			Тт	
(N) Glss (4)				
ACCESSORIES & (A)Plastic wire conno (B) Mounting screw				— K — L — M — N

ASSEMBLY & INSTALLATION INSTRUCTIONS:

- 1. Carefully remove the fixture from the carton and check that all parts and accessories are included as shown in the above illustration
- 2. Turn off power

Before you start to make installation, NEVER attempt any work without shutting off the electricity until the work is done. A). Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "OFF" position. B). Place the wall switch in the "OFF" position

3. Unscrew the knob ball (G) from canopy (E) then remove the mounting plate (C)



www.ihomeangel.com

Twist plastic wire connector(A) until wires are tightly joined together, then carefully stuff all wires into the outlet box

White Supply Wire to:

*Parallel cord (square & ridged)

Clear, Brown, Gold or Black

with tracer

Insulated wire (other than green)

Neutral Wire

with silver conductor

White

6. Make wire connections

5.

Connect wires as below wires connecting shown. TAKE NOTE OF YOUR COLOR OF FIXTURE ,NEVER **CONNECT**

WIRES TO GROUND WIRES

Connect ground wire according to below chart




Red Supply Wire to:


Clear, Brown, Gold or Black

without tracer

with copper conductor


Black








Attach the mounting plate (C) to outlet box with the mounting screws(B)

5. 1) According your desired hanging heigh to choose and use the tubes (H).










²⁾ Thread the chosen tubes (H) and the canopy (E) with swivel joint(F) together. Hand tighten until snug.



CLEANING

To clean, wipe fixture with a soft cloth. Clean glass with a mild soap. Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

ORDERING PARTS

Keep this sheet for future reference, and in case you need to order replacement parts. All parts for this fixture can be ordered from place of purchase. Be sure to use exact wording from illustration when ordering parts.