

Guide of Riding 3

- Start by moving forward as slowly as possible
- Move the throttle wheel in small increments
- Keep a wide stance on the board
- Keep a low center of gravity
- Lean forward when accelerating
- Lean backwards when braking



Contact us 4

• Go to Meepo facebook page Meepo Electric Skateboard to discuss about Meepo Board and check news video and get to know riding buddies near you.

• Consulting Meepo Board's service department. Should your unit need service, contact at info@meepoboard.com

• Facebook Page: <https://www.facebook.com/meepoboard>

• Webstore: <https://meepoboard.com>


• YoutubeChannel: <https://www.youtube.com/c/kieraneboard>



Join us on Facebook and get to know riding buddies near you

MANUAL

MEEPO V3



MEEPO



Product Introduction

• **YOUR BOARD CAN LOSE POWER AND BRAKES AT ANY MOMENT** due to radio interference a dead remote battery, unintentional release of the Engage Button, downhill overcharging of a full battery, and other factors.


• **BRAKING DOWNHILL ON A FULL BATTERY MAY CAUSE FAILURE OF BRAKE.** Since regenerative braking will overcharge the battery to prevent this from happening, don't do long distance down hill riding at from the beginning of your riding and ride on flats or uphill to drain the battery before attempting downhill again. Don't go downhill when you can't footbrake.

• **ALWAYS WEAR A HELMET.** Other safety gear, like gloves, pads, and long sleeves, is highly recommended.

• **WARNING:** Always wear a helmet when riding. Never ride in water, wet surfaces, in the rain, slippery or uneven surfaces, steep hills, traffic, cracks, train tracks, gravel, rocks or any obstacles that could cause a loss of traction. Avoid night riding, areas with poor visibility, and narrow spaces.

• **WARNING:** Do not ride a Meepo board at speeds where you would not be safely in control of an unpowered skateboard. In the event of wireless interference or battery fault, you may need to rely on skating techniques like footbraking or sliding to stop. So basically, you should learn FOOTBRAKE. Here is a video to learn footbrake. <https://www.youtube.com/watch?v=I3EyJpM2E6s>

M4 REMOTE 1



How to pair?

1. Turn on meepo board, then long press the switch for 7 seconds.
2. Press the power button on remote for 3 seconds to turn it on.
3. Press the power and function buttons on remote at the same time.

MEEPO V3 2

