

GAMESIR • GAMING IS WINNING.™

© 2018 GameSir Inc. All rights reserved.
Product may vary slightly from those pictures.



GameSir R3

Bluetooth Audio Adapter

User Manual ►

PACKAGE CONTENTS

GameSir R3 Bluetooth Audio Adapter
User Manual


REGISTRATION

Register your GameSir ID online at <https://gamesir.hk/> to get real-time information on your product's warranty status and a series of exclusive benefits from GameSir.

YOUR BENEFITS

- * 12-month replacement of the same model from the date you received it.
- * Free online technical support at <https://gamesir.hk/>

DEVICE LAYOUT




A Connection switch & Connection indicators

B Connection socket

C Connection socket cover

D Extended interface

E Microphone component



FIRST CONNECTION

- Turn on bluetooth of the device, make sure it's able to be paired.
- Plug GameSir R3 bluetooth audio adapter into Nintendo Switch.
- Red and blue connection indicators will flash alternately, GameSir R3 bluetooth audio adapter is in the status of searching bluetooth devices automatically.
- When the connection indicators stay at red and blue, the connection is complete.

CONNECT TO THE SECOND DEVICE

- After the first device is connected successfully, please turn on the bluetooth of the second device and make sure it's ready to be paired.
- Press the connection switch, the right connection indicator will flash in blue, GameSir R3 bluetooth audio adapter is in the status of searching bluetooth devices automatically.
- When the connection indicators stay at red and blue, the connection is complete.

RECONNECTION

- GameSir R3 bluetooth audio adapter will reconnect to the last two paired devices automatically.
- When reconnect to the first device, the connection indicator flashes in red, then the left indicator light stays at red after the connection is complete.
- When reconnect to the second device, the connection indicator flashes in blue, then the right indicator light stays at blue after the connection is complete.
- If it fails to reconnect, please press the connection switch, GameSir R3 bluetooth audio adapter will try to reconnect the last two paired devices.

CONNECT TO NEW DEVICE

- When connecting to a new bluetooth device, please press the connection switch for 3 seconds, the red and blue connection indicators will flash alternately, GameSir R3 bluetooth audio adapter is in the status of searching new bluetooth devices automatically.
 - When the connection indicators stay at red and blue, the connection is complete.
- *When connecting to the second new bluetooth device, please repeat the operations.

Connection	Connection indicators	Instruction
First connection	Red and blue indicators flash alternately	Searching bluetooth devices
	Indicator lights stay at red and blue	Connect successfully
	Right indicator light flashes in blue	Searching the second bluetooth device
	Indicator lights stay at red and blue	The second device is connected successfully
Reconnection	Left indicator light flashes in red	Reconnecting
	Left indicator light stays at red	Reconnect successfully
	Right indicator light flashes in blue	Reconnecting the second device
	Indicator lights stay at red and blue	The second device is reconnected successfully

POWER OFF / POWER ON

Press the connection switch for 5 seconds, the LED light will be off, GameSir R3 bluetooth audio adapter is powered off.

Press the connection switch to power on GameSir R3 bluetooth audio adapter and it will reconnect to the bluetooth devices automatically.

RESET

When GameSir R3 bluetooth audio adapter is on, press the connection switch for 10 seconds, the red and blue connection indicators will flash 3 times simultaneously, GameSir R3 bluetooth audio adapter is reset successfully.

⚠ NOTICE: Please read this Precautions carefully.

- CONTAINS SMALL PARTS. Keep out of reach of children under the age of 3. Seek immediate medical attention if swallowed or inhaled.
- DO NOT use the product near fire.
- DO NOT expose to direct sunlight or high temperatures.
- DO NOT leave the product in a humid or dusty environment.
- DO NOT impact the product or cause it to fall due to strong impact.
- DO NOT touch USB port directly or it might cause malfunctions.
- DO NOT strongly bend or pull cable parts.
- Use a soft, dry cloth while cleaning.
- DO NOT use chemicals such as gasoline or thinner.
- DO NOT disassemble, repair or modify.
- DO NOT use for purposes other than its original purpose. We are NOT responsible for accidents or damage when used for non-original purposes.
- DO NOT look directly at the optical light. It might damage your eyes.
- If you have any quality concerns or suggestions, please contact GameSir or your local distributor.

Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

日本語

パッケージ内容

GameSir R3 Bluetooth オーディオアダプタ

取扱説明書

ユーザー登録

<https://gamesir.hk/>にてGameSir IDを作成して、ご購入の製品を登録すると、当製品の品質保証の状態に関するリアルタイム情報と、GameSir会員専用のメリットを得ることができます。

登録による特典

12ヶ月のメーカー限定保証(本体のみ)

<https://gamesir.hk/>でのマニュアルの閲覧と無料オンラインテクニカルサポート(英語/日本語対応)

各部の名称

- A** スイッチ & 接続インジケータライト
- B** 接続ポート
- C** 接続ポート保護キャップ
- D** 拡張ポート
- E** マイクアセンブリ

一つ目のBluetoothデバイスへの接続方法

- お使いのデバイスのBluetoothをオンにして、接続モードに入れます。
- GameSir R3 Bluetooth オーディオアダプタをNintendo Switchに差し込みます。
- GameSir R3 Bluetooth オーディオアダプタは接続インジケータライトがレッドとブルーで交互に点滅し、自動的に接続モードに入れます。
- GameSir R3 Bluetooth オーディオアダプタは接続インジケータライトがレッドとブルーで点灯すると、接続成功です。GameSir R3 Bluetooth オーディオアダプタは正常に使えるようになります。

二つ目のBluetoothデバイスへの接続方法

- 一つ目のBluetoothデバイスが正常に接続されたら、二つ目のデバイスのBluetoothをオンにして接続モードに入れます。
- GameSir R3 Bluetooth オーディオアダプタのスイッチを押すと、接続インジケータライトが右側ブルーに点滅し、自動的に接続モードに入れます。
- GameSir R3 Bluetooth オーディオアダプタは接続インジケータライトがレッドとブルーで点灯すると、接続成功です。GameSir R3 Bluetooth オーディオアダプタは正常に使えるようになります。

再度接続方法

- GameSir R3 Bluetooth オーディオアダプタは自動的に最後にペアリングされた2つのデバイスに接続します。
- 一つ目のBluetoothデバイスが再度接続されると、接続インジケータライトが左側レッドに点滅します。接続に成功する場合、接続インジケータライトが左側レッドに点灯します。
- 二つ目のBluetoothデバイスが再度接続されると、接続インジケータライトが右側ブルー \textcircled{B} に点滅します。接続に成功する場合、接続インジケータライトがレッドとブルー \textcircled{B} で点灯します。
- ペアリングに失敗した場合は、再度スイッチを押すと、GameSir R3 Bluetooth オーディオアダプタは最後にペアリングされた2つのBluetoothデバイスに接続し続けます。

再ペアリング方法

- その他のデバイスに接続する場合は、スイッチを3秒長押しすると、GameSir R3 Bluetooth オーディオアダプタは接続インジケータライトがレッドとブルー \textcircled{B} で交互に速く点滅し、自動的にその他のデバイスを検出します。
 - GameSir R3 Bluetooth オーディオアダプタは接続インジケータライトがレッドとブルー \textcircled{B} で点灯すると、接続成功です。GameSir R3 Bluetooth オーディオアダプタは正常に使えるようになります。
- *2つ目のその他のBluetoothデバイスに接続する場合、a~bを繰り返してください。

状態	接続インジケータライト	説明
初めて接続	レッド+ブルー点滅 	Bluetoothデバイスを検索中
	レッド+ブルー点灯 	接続成功
	右側ブルー点滅 	二つ目のBluetoothデバイスを検索中
	レッド+ブルー点灯 	接続成功
二回目接続	左側レッド点滅 	接続中
	左側レッド点灯 	接続成功
	右側ブルー点滅 	二つ目のBluetoothデバイスに接続中
	レッド+ブルー点灯 	接続成功

オン/オフ

スイッチを5秒長押しすると、GameSir R3 Bluetooth オーディオアダプタはシャットダウンし、接続インジケータライトが消灯します。
スイッチを再度押すと、GameSir R3 Bluetooth オーディオアダプタはオンになり、自動的に接続モードに入ります。

リセット (Reset)

GameSir R3 Bluetooth オーディオアダプタがオンになっている状態で、スイッチを10秒長押しすると、接続インジケータライトがレッドとブルー \textcircled{B} で同時に三回点滅し、リセット成功です。

⚠ ご注意:保護者の方へ必ずお読みください。

- 小さい部品がありますので3歳未満のお子様には絶対に与えないでください。
- 乳幼児の手の届くところに置かないでください。万一飲み込んだ場合は、すぐに医師に相談してください。
- 火気のある場所では絶対に使用しないでください。
- 長時間直射日光当てたり、高温となる場所に置かないでください。
- 本品を湿気やホコリの多いところに置かないでください。
- 本品に物を当てたり、落下させるような強い衝撃を与えないでください。
- 故障の原因になりますので、USB端子を直接手で触らないでください。
- ケーブル部を強く曲げたり引っ張ったりしないでください。
- お手入れの際には、乾いた柔らかい布を使用してください。
- ベンジン、シンナーなどの薬品は使用しないでください。
- 分解や修理、改造は絶対にしないでください。
- 本来の目的以外には使用しないでください。本来の目的以外に使用した場合の事故や損害に対し、弊社は一切その責任を負いません。
- 光学式ライトの光を直接見ないでください。強い光より、目を痛める可能性があります。

* 品質上の問題または提案がある場合に販売元またはアフターサービス担当者に連絡してください。

ラベル要件。

本装置はFCC規則第15部の要求に適合している。操作は次の2つの条件を満たす必要がある。

- 1)本設備は有害な妨害をもたらしてはならない;
- 2)本装置は、不良な動作を引き起こす可能性のある干渉を含む、受信された干渉を受信しなければならない。

ユーザーに提供される情報。

注:FCC規則第15部分の規定に基づき、本装置はB種類のデジタル機器の制限に適合するように試験した。これらの規制は、住宅の設置における有害な干渉を防止するための合理的な保護を提供することを意図している。この装置は、無線周波数エネルギーを生成し、放射する可能性がある。指示に従って設置および使用しないと、無線通信に有害な干渉を引き起こす可能性がある。ただし、特定のインストールで干渉が発生しない保証はない。この機器がラジオやテレビの受信に有害な干渉を引き起こす場合は、機器の電源をオフにしてからオンにすることで判断できます。ユーザーは、次の方法で干渉を修正することをお勧めします。

- 受信アンテナの方向を調整するか、再配置する。
- 装置と受信機の間の距離を増やす。
- 受信機に接続されている回線とは別のコンセントに機器を接続する。
- 販売店または経験豊富なラジオ/テレビ技術者に相談してください。

简体中文

包装内容

GameSir R3 蓝牙音频转换器
说明书
合格证

设备布局

- A 连接开关&连接指示灯
- B 连接插口
- C 连接插口保护盖
- D 拓展接口
- E 麦克风组件

首次连接方法

- a. 打开对应设备的蓝牙，并让其处于可被搜索的状态。
- b. 将GameSir R3 蓝牙音频转换器连接至Nintendo Switch。
- c. 连接指示灯  红蓝灯光交替闪烁，GameSir R3 蓝牙音频转换器自动进入设备搜索状态。
- d. 连接指示灯  常亮红蓝灯光，成功连接对应设备，GameSir R3 蓝牙音频转换器可正常使用。

连接第二台设备

- a. 第一台设备连接成功后，打开第二台设备的蓝牙，并让其处于可被搜索的状态。
- b. 按下连接开关，连接指示灯  右侧闪烁蓝光，GameSir R3 蓝牙音频转换器自动进入设备搜索状态。
- c. 连接指示灯  常亮红蓝灯光，成功连接第二台对应设备，GameSir R3 蓝牙音频转换器可正常使用。

再次连接方法

- GameSir R3 蓝牙音频转换器可自动连接最后配对的2台设备。
- 再次连接第一个设备时，连接指示灯左侧闪烁红光，连接成功，红光常亮。
- 再次连接第二个设备时，连接指示灯右侧闪烁蓝光，连接成功，蓝光常亮。
- 若配对失败，请按下连接开关，GameSir R3 蓝牙音频转换器将继续连接最后配对的2台设备。

重新连接方法

- 当需要连接新蓝牙设备，请长按连接开关3s，连接指示灯：红蓝灯光交替快速闪烁，GameSir R3 蓝牙音频转换器自动进入新设备搜索状态。
 - 连接指示灯常亮红蓝灯光，成功连接对应设备，GameSir R3 蓝牙音频转换器可正常使用。
- *需匹配第二台新蓝牙设备时，请重复此操作。

状态	连接指示灯	说明
初次连接	红蓝闪烁 	设备搜索中
	红蓝常亮 	设备连接成功
	右侧蓝色闪烁 	第二台设备搜索中
	红蓝常亮 	第二台设备连接成功
回连时	左侧红色闪烁 	回连中
	左侧红色常亮 	回连成功
	右侧蓝色闪烁 	第二台设备回连中
	红蓝常亮 	第二台设备回连成功

关机/开机

长按连接开关5秒，LED关闭，GameSir R3 蓝牙音频转换器成功关机。
关机后，按下连接开关即可开机。并自动进入再次连接状态。

复位

开机状态下，长按连接开关10秒，连接指示灯：红蓝灯光同时闪烁3次，成功复位。

注意事项

- 若商品有质量问题，请首先联系我们的客服进行登记。

联系方式：

QQ: 800082537

电话: 400-8828035 (时间: 9: 00-18: 00)

官网: www.xiaoji.com

出品: 广州小鸡快跑网络科技有限公司

地址: 广州市天河区建业路华翠街68号301A-1

- 如需退、换商品，请确保商品完好无损（包括商品外包装、附赠品、说明书、售后卡、标签等），不影响二次销售。
- 如要保修商品，请务必完整填写用户姓名、联系电话、联系地址，正确填选售后要求与详细说明售后原因，将售后卡随货寄回（如不完整填写保修卡信息，恕无法提供任何的售后服务。）

该设备符合联邦通信委员会规则第15部分。操作受以下两种情况：

- 本装置不会造成有害干扰
- 该设备必须接受收到的任何干扰，包括可能导致不希望的操作的干扰

注:该设备已经过测试，符合根据联邦通信委员会规则第15部分，B类数字设备。这些限制是旨在针对中的有害干扰提供合理的保护住宅安装。这种设备产生效用，并能辐射无线电频率能量，如果没有按照安装和使用说明，可能会对无线电通信造成有害干扰。然而，不能保证在特定的情况下不会发生干扰安装。如果该设备确实对无线电造成有害干扰或电视接收，可以通过关闭设备来确定在上，鼓励用户尝试通过以下一项或多项来纠正干扰以下措施。-重新定向或重新定位接收天线。-增加设备和接收器之间的距离。-将设备连接到不同电路的插座上接收器已连接。-向经销商或有经验的无线电/电视技术人员寻求帮助。

保修卡

(售后政策：非人为损坏，3个月包换、1年保修)

用户姓名			
联系电话			
联系地址			
售后要求	<input type="checkbox"/> 退	<input type="checkbox"/> 换	<input type="checkbox"/> 保修
售后原因			
订单编号			

(注：非小鸡官网途径购买的产品，售后问题请直接与购买商家联系)

