

Gaming is winning.™



# GameSir X2

Type-C Mobile Gaming Controller

User Manual ►

## SYSTEM REQUIREMENT

### HARDWARE REQUIREMENTS



- Android phones that are less than 173mm long.
- Has a Type-C interface.

### SOFTWARE REQUIREMENTS

- System version is above Android 9.0.
- Need to turn on the OTG data exchange function of the phone

Note: Huawei, Xiaomi, Samsung, Google phones are turned on by default, and for other mobile phones, system - additional settings - enable OTG data exchange.

## EQUIPMENT LAYOUT




- |                       |                               |                          |                           |
|-----------------------|-------------------------------|--------------------------|---------------------------|
| ● A Left joystick     | ● F HOME button               | ● K L2 button            | ● P Type-C data connector |
| ● B D-Pad             | ● G ABXY button               | ● L L1 button            |                           |
| ● C G button          | ● H Right joystick            | ● M R2 button            |                           |
| ● D Screenshot button | ● I Connection mode indicator | ● N R1 button            |                           |
| ● E S button          | ● J Charge indicator          | ● O Type-C charging port |                           |

## HOW TO INSTALL

1. Align the Type-C port on the bottom of the phone with the Type-C data connector on the left side of the gamepad and plug it in.
2. Pull the right side of the gamepad away and install the phone into the fixed position of the gamepad. When the connection is successful, the connection mode indicator will be lit in blue, indicating that the gamepad is ready.

(If the connection mode indicator does not light up, make sure your phone has enabled OTG data exchange by going to System - Additional Settings - Enable OTG Data Exchange), (If the connection mode indicator continues to flash blue, please take out and install you phone again.)



Connection mode indicator	Description
Blue light stays on	The gamepad is ready
Blue light blinks	Connecting

## TAKE OFF THE PHONE

To remove the phone from the gamepad, grip the right side of the gamepad and then gently pull the left side of the gamepad to release the phone from the gamepad.

## CHARGING YOUR PHONE THROUGH THE GAMEPAD

Using a charging cable, connect the Type-C port on the bottom of the controller to the USB charging port.

## BATTERY STATUS

Charging status indicator	Description
White light stays on	Charging
White light blinks	Not connected



Scan the QR code to see the list of mobile phone models that support charging and playing

## GAMES THAT SUPPORT GAMEPADS

Means that the game itself supports controller, and it can be operated normally when the controller is connected.

To explore the list of games that support gamepads and how to configure and use GameSir X2, scan the following QR code or refer directly to the online User Guide.



### **▲ NOTICE Please read this Precautions carefully.**

- CONTAINS SMALL PARTS. Keep out of reach of children under the age of 3. Seek immediate medical attention if swallowed or inhaled.
- DO NOT use the product near fire.
- DO NOT expose to direct sunlight or high temperatures.
- DO NOT leave the product in a humid or dusty environment.
- DO NOT impact the product or cause it to fall due to strong impact.
- DO NOT touch USB port directly or it might cause malfunctions.
- DO NOT strongly bend or pull cable parts.
- Use a soft, dry cloth while cleaning.
- DO NOT use chemicals such as gasoline or thinner.
- DO NOT disassemble, repair or modify.
- DO NOT use for purposes other than its original purpose. We are NOT responsible for accidents or damage when used for non-original purposes.
- DO NOT look directly at the optical light. It might damage your eyes.
- If you have any quality concerns or suggestions, please contact GameSir or your local distributor.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## システム要件

### ハードウェア要件


- 本体は長さ173mm以内のアンドロイド携帯に対応
- Type-Cポートあり

### ソフトウェア要件

- Android9.0以降
- スマホのOTGデータ交換機能をオンにする必要があります

注:Huawei, Xiaomi, Samsung, Google、スマホはデフォルトでオンになっています。その他のスマホのセットアップ手順、システム→詳細設定→オープンOTGデータ交換

## 設備レイアウト




- |                  |                   |                 |                   |
|------------------|-------------------|-----------------|-------------------|
| ● A 左スティック       | ● F HOMEボタン       | ● R L2ボタン       | ● P Type-Cデータコネクタ |
| ● B 十字ボタン        | ● G ABXYボタン       | ● L L1ボタン       |                   |
| ● C Gボタン         | ● H 右スティック        | ● M R2ボタン       |                   |
| ● D スクリーンショットボタン | ● I 接続モードパイロットランプ | ● N R1ボタン       |                   |
| ● E Sボタン         | ● J 充電パイロットランプ    | ● O Type-C充電ポート |                   |

## スマホを取り付ける

1. スマホのtype-cポートをゲームパッド左側のtype-cデータ端子に合わせて斜めに挿入
2. ゲームパッドの右側を引き離し、スマホをゲームパッドの固定位置に取付けます  
接続が成功すると、パイロットランプが青色に点灯し、ゲームパッドの準備ができていることを示します。

(接続モードのパイロットランプがオンにしないと、スマホがOTGデータ交換が有効になっているかどうかを確認してください。[システム]-[詳細設定]-[OTGデータ交換を有効にする]に移動してください)、(接続モードパイロットランプが青色に点滅し続ける場合は、再度スマホを取り付けてください。)



接続モードインジケータ	説明
青く点灯	ゲームパッドは準備ができています
青く点滅	接続中

## スマホを取り外す

スマホをゲームパッドから取り外すには、ゲームパッドの右側をしっかりと持ち、ゲームパッドの左側を軽く引いて、スマホをゲームパッドから簡単に外します

## ゲームパッド経由でスマホを充電する

1. 充電ケーブルを使用して、ゲームパッドのType-CポートとUSB充電ポートを接続する

## 充電ヒント

充電状態パイロットランプ	説明
白く点灯	充電中
白く点滅	スマホが接続されていない



QRコードをスキャンして、充電しながらプレイすることができるのゲームリストを確認してください

## ゲームパッドをサポートするゲーム

ゲーム自体がゲームパッドをサポートしていることを指し、ゲームパッドは接続後に正常に操作できます。GameSir X2の使用法、及び対応したゲームには、次のQRコードをスキャンしてください。



### ▲ご注意:保護者の方へ必ずお読みください。

- 小さいな部品がありますので3歳未満のお子様には絶対に与えない ください。
- 乳幼児の手の届くところに置かない ください。万一飲み込んだ場合は、すぐに医師に相談してください。
- 火気のある場所では絶対に使用しないで ください。
- 長時間直射日光当てたり、高温となる場所に置かない ください。
- 本品を湿気やホコリの多いところに置かない ください。
- 本品に物を当てたり、落下させるような強い衝撃を与えない ください。
- 故障の原因になりますので、USB端子を直接手で触ない ください。
- ケーブル部を強く曲げたり引っ張ったりしないで ください。
- お手入れの際には、乾いた柔らかい布を使用してください。
- ベンジン、シンナーなどの薬品は使用しないで ください。
- 分解や修理、改造は絶対にしないで ください。
- 本来の目的以外には使用しないで ください。本来の目的以外に使用した場合の事故や損害に対し、弊社は一切その責任を負いません。
- 光学式ライトの光を直接見ない ください。強い光より、目を痛める可能性があります。

## システム 要求

### ハードウェア 要求



- 휴대폰 본체 길이가 173mm 미만인 안드로이드 휴대폰.
- 1개Type-C포트를 제공

### 소프트웨어 要求

- 시스템 버전은Android9.0이상
- 휴대폰OTG데이터 교환 기능을 개설 필요

주: 화웨이, 샤오미, 삼성, 구글, 휴대폰은 디폴트로 개설되며 기타 휴대폰 설정 절차는, 시스템 - 더많은 설정 - OTG 데이터 교환 개설

## 설비 배치




- A 좌 조이스틱
- B D-패드
- C G버튼
- D 스크린샷 버튼
- E S버튼
- F HOME버튼
- G ABXY버튼
- H 우 조이스틱
- I 연결 모식 표시등
- J 충전 표시등
- K L2버튼
- L L1버튼
- M R2버튼
- N R1버튼
- O Type-C충전 포트
- P Type-C데이터 커넥터

## 휴대폰 설치

- 휴대폰 하부의Type-C 포트와 컨트롤러 좌측의 Type-C 데이터 커넥터를 대응시키고 경사지게 삽입합니다.
- 컨트롤러 우측을 당기고 휴대폰을 컨트롤러 고정 위치에 설치합니다.\*연결 성공후 연결 모식 표시등은 남색으로 켜지면○ 컨트롤러의 준비 대기를 표시합니다.

( 연결 모식 상태 표시등이 켜지지않으면 휴대폰의OTG 데이터 교환이 켜짐 여부를 확보하고 시스템—더많은 설정—OTG데이터 교환 개선을 방문하십시오 ), ( 연결 모드 상태 표시등이 남색 깜박으로 지속하는 경우, 휴대폰을 다시 연결하십시오)



연결 모식 표시등	설명
남색 켜짐	컨트롤러 준비 대기중
남색 깜박	연결중



## 휴대폰 꺼내기

휴대폰을 컨트롤러로 부터 꺼내는 경우, 컨트롤러 우측을 튼튼히 잡고 컨트롤러 좌측을 가볍게 당겨 휴대폰을 컨트롤러로 부터 가볍게 이탈 시킵니다.

## 컨트롤러로 휴대폰 충전

충전 케이블을 이용하여 컨트롤러 하부의Type-C 포트를USB충전 포트와 연결합니다.

## 충전 제시

충전 상태 표시등	설명
흰색 켜짐	충전중
흰색 깜박	휴대폰 연결전



충전중 게임 가능한 휴대폰 모델 목록을 스캔 열람

## 게임 패드를 지원하는 게임

게임 자체가 컨트롤러를 지원하며 컨트롤러를 연결한 후 정상으로 작동 가능함을 뜻합니다. 게임 패드를 지원하는 게임 및 GameSir X2 구성과 사용법을 탐색할 경우, 이하QR코드를 스캔 또는 온라인 사용자 안내를 열람하십시오.



## ▲ 한국KC 경고문구:

- 1.감열한 진동을 피하고 사사로이 해체,개조,수리를 하지 마십시오.
- 2.습한곳,고온,오일과 연기가 있는 장소를 피하여 보관하십시오.
- 3.물 혹은 기타 액체가 컨트롤러 내부로 들어가면 컨트롤러 기능에 영향을줄수 있습니다.
- 4.배터리가 내장되었기에 컨트롤러를 불속에 넣지 마십시오,폭박할 수 있습니다.
- 5.본 제품충전 전압은 USB3.7-5.5V, 직류전원(보통 안드로이드 휴대폰충전전원이면 바로 사용할 수 있음)이고, 아닐 경우 충전에실패하거나,제품 훼손을 초래할 수 있습니다.
- 6.어린이는 성인의 보호하에 본 제품을 사용하십시오.
- 7.임의의 품질 문제거나 건의 사항은 판매업체거나 소비자 상담실에연락하십시오,연락처는 제품 겉면 포장에 있습니다.

## 系统要求

### 硬件要求


- 手机机身长度小于173mm的安卓手机。
- 具有一个Type-C接口

### 软件要求

- 系统版本在Android9.0以上
- 需要打开手机OTG数据交换功能

注：华为、小米、三星、谷歌等手机默认打开，其他手机设置步骤，系统—更多设置—开启OTG数据交换

## 设备布局



- A 左摇杆
- B 十字键
- C G键
- D 截图键
- E S键

- F Home键
- G ABXY键
- H 右摇杆
- I 连接模式指示灯
- J 充电指示灯


- K L2键
- L L1键
- M R2键
- N R1键
- O Type-C充电接口

- P Type-C数据接头

## 安装手机

- 1.将手机底部的Type接口对准手柄左侧的Type-C数据接头并倾斜插入。
- 2.将手柄右侧拉开,将手机安装至手柄的固定位中,连接成功后,连接模式状态指示灯将蓝色常亮,表示手柄已准备就绪。

(若连接模式状态指示灯无法点亮,请确保您的手机是否开启OTG数据交换,请前往 系统—更多设置—开启OTG数据交换)(若连接模式状态指示灯持续蓝色闪烁,请重新插拔手机。)



连接模式状态指示灯	说明
蓝色常亮	手柄已经准备就绪
蓝色闪烁	正在连接

## 取下手机

若要将手机从手柄上取下,请紧握手柄右侧,然后轻轻拉动手柄左侧,使手机轻松脱离手柄

## 通过手柄为手机充电

- 1.使用充电线缆,将手柄底部的Type-C接口连接到USB充电端口

## 了解充电提示

充电状态指示灯	说明
白色常亮	充电中
白色闪烁	未连接手机



(扫码查看支持边充边玩的手机型号列表)

## 原生手柄游戏及官方合作游戏

指游戏本身支持手柄,手柄连接后即可正常操作

探索原生手柄游戏及官方合作游戏列表及如何配置和使用GameSir X2, 请扫描以下二维码或直接参阅在线高级用户指南(位于doc.xiaoji.com)



## ⚠ 注意事项

1. 若商品有质量问题,请首先联系我们的客服进行登记。

联系方式:

QQ:800082537

电话:400-8828035(时间:9:00-18:00)

官网:www.xiaoji.com

出品:广州小鸡快跑网络科技有限公司

地址:广州市天河区建业路华翠街68号301A-1

2. 如需退、换商品,请确保商品完好无损(包括商品外包装、附赠品、说明书、售后卡、标签等),不影响二次销售。

3. 如要保修商品,请务必完整填写用户姓名、联系电话、联系地址,正确填写售后要求与详细说明售后原因,将售后卡随货寄回(如不完整填写保修卡信息,恕无法提供任何的后服务)。

## 保修卡

(售后政策: 非人为损坏, 3个月包换、1年保修)

用户姓名	
联系电话	
联系地址	
售后要求	<input type="checkbox"/> 退 <input type="checkbox"/> 换 <input type="checkbox"/> 保修
售后原因	
订单编号	
(注: 非小鸡官网途径购买的产品, 售后问题请直接与购买商家联系)	