


名称: A5电视声霸说明书
 材质: 铜板纸
 尺寸: 展开135*540 折叠135*90 mm
 印刷: 彩色
 装裱: 折页
 注: 成品没有黑色边框

正面 ▶



Fosi Audio
BRING THE SOUND TO YOUR HEART
User Manual

Model: A5

Foreword

Thank you very much for purchasing the A5 home soundbar.


Please read the instructions carefully before using this product.

If you have any problems or suggestions for the product, please contact us via support@fosiaudio.com.

Packing list

- A5 Soundbar x1
- Power Adapter x1
- User manual x1
- 3.5mm to RCA cable x1
- Wall mount brackets x1
- Remote control x1

Overview




1. HDMI(ARC) input (Some TV brands are not supported)
2. Optical input
3. USB Playback
4. AUX 3.5mm line in
5. DC in
6. Power
7. M input mode switch button
8. Play/Pause
9. Volume-/Previous track
10. Volume/Next track

Remote control installation


Insert 2 pieces of AA batteries to activate the remote control. (batteries not included).

Note: 1) The remote control works within the range of 6 meters.
 2) TV remote control or other universal remote controls are not compatible with the soundbar.



1. Short press: Power on / Short press: Power off
2. EQ Switching Setting: Music—Movie—New—Bass
3. Mute
4. Player Control
5. Audio source: Aux in
6. Audio source: USB
7. Audio source: Optical
8. Audio source: HDMI(ARC) (Some TV models are not supported)
9. Audio source: Bluetooth


Optical in source



1. Ensure that the soundbar is connected to the TV or other audio devices via an optical cable.
2. Press the "OPTIC" on the remote control to enter the Optical input mode. You can also short press the "M" source button on the soundbar to choose the Optical source.


Note: The playback is controlled by your device and the button on the remote control.

Before use, you need to unplug the cover.



反面 ▶


Line in source



1. Ensure that the soundbar is connected to the TV or other audio devices via a 3.5mm/RCA audio cable.
2. Press the "AUX" button on the remote control to enter the mode. You can also short press the "M" source button on the soundbar to choose the LINE IN source.


Note: The playback is controlled by your device or buttons on the remote control.

USB playback



1. Plug your USB flash drive into the USB port and the soundbar will play the music in your USB flash drive.


HDMI(ARC) source



Ensure that the soundbar is connected to the TV or other audio devices via an HDMI(ARC) cable. Press the HDMI button on the remote and play.

Note: 1) The device can synchronize the volume with the TV and also with the switch.
 2) Some TV brands may not be compatible with this interface Protocol.

Wall mounting guide



Mark the position points on the wall

1. **Mark the position points on the wall:** Choose the mounting height and Mark A1; Mark A2 on the right of A1 on the same horizontal line; The distance between the 2 points should be 300mm exactly.
2. **Drill the holes:** Drill holes in the marked position.

3. Hang up the soundbar: Insert the wall plugs into the holes; Tighten the screws into the plugs through the foam pads; Hang the soundbar on the screws.

QA

Q1. Pairing connection via Bluetooth cannot be completed.

- Once you connect a device to the soundbar, the connection will be stored. When you turn on the soundbar, the Bluetooth connection will be activated automatically. To connect another device to the soundbar, you need to disconnect the former connection first: turning off Bluetooth on your former device, or clearing the former connection by pressing and holding the Bluetooth button on the remote control for 2 seconds. After that, you can find and connect the other devices.

Q2. Why is there no sound output from the soundbar when I connect it to my TV set?

- Please make sure that the TV has a audio output interface
- Please set the TV to digital audio output and select PCM output.

Q3. The Bluetooth connection is not stable.

- There should be some obstructions between the soundbar and your Bluetooth devices which interfere with the connection. Please remove them. The supported range for the Bluetooth connection is around 10 meters indoors. Please do not exceed that range.

Q4. Silent play after connection via Bluetooth.

- After connections with mobile devices, Bluetooth device audio is off. Turn on the mobile's output volume.

Q5. No sound when connected to TV via HDMI (ARC) cable.

- Some TV brands may not be compatible with the HDMI (ARC) interface protocol, it is recommended to use other Audio source .

Specifications

Product name	2.0 Soundbar
Output power	20W*2
Adapter	15V/2A
Speaker frequency	70Hz-20KHz
Bluetooth version	5.0, A2DP, AVRCP
Bluetooth range	Up to 10m
Dimensions	470mm x 95mm x 70mm

About Fosi Audio

Fosi Audio designs and builds innovative audio products with all your music in mind. Great sound, simple but elegant designs, high-quality materials, and truly useful features are what Fosi Audio is about. We sincerely hope you get as much enjoyment from our products as we've had to create them!

Our website: www.fosiaudio.com
 Amazon store: www.amazon.com/fosiaudio
 Our Youtube channel: Fosi Audio
 Our Facebook page: Fosi Audio

After-sale Service and Technical Support Email: support@fosiaudio.com

Fosi Audio