

Current Transmitter

sub-plate indtallation, Detect AC current. High insulation between primary and secondary circuits.






Product features


- ·Light weight
- •Low power consumption
- Good linearity
- No insertion loss
- Fast response time
- •Good anti-interference ability

Product application

- Railway
- Metallurgical
- ·Welding machine
- Robot
- Motor
- •Inverter power supply
- Variable frequency governor
- •Uninterrupted power supply and communication power supply

Installation diagram







Electrical parameters: (The following parameters are typical values and actual values will be subject to product testing)						Remarks	
Rated input	50A	100A	200A	300A	400A	500A	Standard input
Input measurement range	60A	120A	240A	360A	480A	600A	Default is 1.2 times the input rating
Rated output	0-	$0-20\mathrm{mA}/4-20\mathrm{mA}/0-5\mathrm{V}/1-5\mathrm{V}/0-10\mathrm{V}$					Output one of five 0-10V output +24V power supply
Accuracy		1 %					
Linearity			0.5	5%			
Supply voltage (\pm 5%)	+12V / +24V					Supply voltage range ±5%	
Current consumption		≤48mA+Io					Reference will be subject to the measured
Load impedance	Curi 2509	Current type output: Voltage type output: $250\Omega(Typification)$ $\geq 10K\Omega$					
Zero offset voltage	Curr	Current type output: ±0.08mA			ge type ou V	tput:	TA=25℃
Response time		≤350mS					Reference will be subject to the measured
weight		101g					Reference will be subject to the measured
Operating temperature		-10 \sim $+70$ $^{\circ}$ C					
Storage temperature		-25 ∼ + 70 °C					
Band width		50Hz-400Hz					

Instruction for use:

Delectric strength

- 1. Correct wiring as indicated
- 2. Full scale measurement, response time and following the speed for the best

2.5KV 50Hz 1min

3. Faulty wiring can lead to product damage and output uncertainty

Safe operation:


- *Please read this specification carefully before use.
- *When you need to move the product, please be sure to disconnect the power and all the connected cables.
- *If found shell, devices attached to the fixed parts, wire, or have any damaged, please immediately deal with hidden dangers.
- *If there is any doubt about the safe operation of the equipment, the equipment and the corresponding accessories should be closed immediately, and the fastest time for troubleshooting.


Proclamations:


As our products are constantly being improved and updated, we reserve the right to modify the content of this specification at any time without prior notice.



Dimensions(in $mm\pm0.5$):








Connector Illustration





Cold pressing terminal quick connection plug, Spacing 2.5 mm

Wiring diagram:



Terminal definition:

1: +V

2: GND

3: out

4: GND

- ‰①The auxiliary power supply with ripple small (≤20mV) is selected
 - 2 Switch on auxiliary power
- ③Auxiliary power is connected to the transmitter
- 4 Transmitter detects the primary current
- ⑤Both GND internals are not isolated