OS-GD21Std-RK Gaming desk

MOUNTING INSTRUCTIONS

1200mm/47.2"
600mm/23.6"
733mm/28.9"

kg
LB
≤80kg
(≤176.4lbs)

CAUTION : DO NOT EXCEED MAXIMUM LISTED WEIGHT CAPACITY. SERIOUS INJURY OR PROPERTY DAMAGE MAY OCCUR.

PARTS LIST

① Tabletop
③ Right leg
⑧ Hand Pad(Right)
⑦ Hand Pad(Left)
④ Cross-bar
⑤ Plug board holder
② Left leg
⑥ Baffle

PARTS LIST

A) Adjustable pad ×4

B) Knob ×2

C) M6×12mm ×4

D) M5×12mm ×3

E) M5×12mm ×4

F) M6×8mm ×6

G) M6×1mm ×6

H) Hook ×2

I) Decorative cover ×4

J) Controller

K) Power cord

L) Controller bracket

M) Cables manager cup ×2

N) Cable clamp ×4

O) Connection cable

P) Cable hole ×4

Q) Cable management ×2

Tools

INSTALLATION STEPS

1

P ×4

Put cable hole P (x4) into the hole
Swirl adjustable pad A (x4) into base

A ×4

P

×4

A

×4

2

C ×4

④

③

②

C

×4

Tools

Tighten the screws on the cross-bar with an allen key

3

Connect either wire interfaces on the upper leg

Lock I(x2) on both leg

I
⚡
×2

4

⑧
⑦
①

G×6

F
⚙
×6

G
⊙
×6

Tools

Fix ⑦and⑧ by
F(×6)&G(×6)

F×6

5

Connect wire interfaces between tabletop① and both legs

①

Slightly lift the frame to assembly N (x4) and⑤

⑤
④
N ×4

N
×4

6

Firstly, gently press the pins to lock, the desktop can be installed

Secondly, tighten B (x2) to fix the cross bars and the tabletop

Connect wire interfaces

B ×2

Lock I (x2) on both leg

I

⚡

×2

B

×2

7

L

E×2

D×3

J

E

×2

J

L

D

×3

Tools

Not included

8

M ×2

① ⑥

Press

Fix ⑥

H ×2
E ×2

H ×2
E ×2

H ×2

E ×2

M ×2

Not included

9

Connect I to the connector, turn on the power

K

Socket

K

Tips

Uncover the back glue of Q and stick it under the desktop, Q can be used to arrange cables

Cables

Q

×2

Manual controller instruction

Front view

M C SK

Headphone port   Microphone port

Power button： Press for 3 seconds to turn on the light;
Press for 3 seconds to turn off the light.

M(Mode button)： 3 modes:1)Single color mode
2)RGB color mode
3)Music mode
Press the button for cycle mode switching.

C(Color button)： Press to change the color with 8 options;
Long press to adjust the brightness of light.

Music mode： The light would flash with the sound of music.
Better to adjust the volume of the computer to
30-60 for the best experience.

Back view

① ② ③

Power port   USB Port
Only for 5V/2.5A

1 for single color light
2&3 for RGB light

Audio port

Connection cable： Green for headphone port of computer;
Red for microphone port of computer