# ZiiLock

## Caution

Please read the following instructions to make sure to use ZiiLock safely and correctly.

- 1. Do not disassemble, adjust or repair this product arbitrarily.
- 2. Do not hit the product with hard objects (hammers etc.).
- Do not insert foreign objects into the keyhole.
- Do not use corrosive or volatile liquids during cleaning, e.g. alcohol, chemical thinners etc.
- Make sure the key is under proper storage to unlock the product in emergency such as running out of battery or abnormal circuit.
- 6. Please pay attention to the battery level, and recharge the lock in time to ensure normal use.

#### Product Diagram



#### Product List:

ZiiLock x 1 ZiiLock Bracket x 1 Key x 2 Charging Cable x 1 Product Manual x 1 Straps X 4 Waterproof Cap x 1

## Specification

Size	195×75×45 mm
Net weight	1.60kg
Battery capacity	3.7V/640mAh
Connection mode	Low power consumption Bluetooth
Encryptio	ASE 128 encryption
Charging Port	USB Type-C
Unlocking Methods	Fingerprint / APP / Mechanical key
Extended Length	101cm

#### App Instruction



Scan the QR code to download the App Note: Support iOS 10 /Android 6.0 or above.

#### Log in/Sign Up



- 1 Enter email account. Then enter/set the login password.
- ② Use Facebook/Google/Apple account to sign up or log in.

#### **Bluetooth Settings**



Long press the fingerprint board for about 5 seconds to turn on/off the Bluetooth of ZiiLock. When the lock beeps with a red light, the Bluetooth of the lock is turned off.

When the lock beeps with a green light, the Bluetooth of the lock is turned on.

## Bind a new ZiiLock:



- (1) Click " $\bigoplus$ " to initiate Bluetooth search.
- ② Click "connect" and enter the authorization code "12345678"
- Binding completed.
- Note: Ensure the lock is nearby and the Bluetooth is enabled for binding.

#### Set your ZiiLock

15:01 <del>7</del>	15:05
≡ (1)—@	< My ZiiLock
	ZiLock Name ZiiLock-32B9
ZiiLock-32B9	Bluetooth ZiiLock-32B9
	SN Code 3863
	Firmware version 001C >
Unlock	Fingerprints Management
	Bound User Management >
	Turn off Bluetooth
Connected	Alert Settings
Find and 700 and	Theft Alert Level
Last unlocked position	Low Medium High
Vibration alarm	Lock Alert Sound
	Delete Lock
	(2)
Zillock	

- ① Select the lock to enter the lock setting page.
- ② Rename the lock and set the alert settings of the lock.

Note: Ensure the lock is nearby and is connected with the App for setting.

15:05		al 46 🗈 🗋	15:08	
<	My ZiiLock		<	Add Fingerprints
ZiLock Name	ZiiLock-32B9	1		Constant Collection
Bluetooth	ZiiLock-32B9		Touch	your finger on the board of Z
5N Code	3863		then re 7 time	move it, please do the above as to fully collect your fingerp
irmware version	001C	>		
Fingerprints Mana	gement	>		
Bound User Mana	gement	>		illi
Turn off Bluetooth		>		` <i>יוון;,,וי</i> יי
Alert Settings	2			Collection Progress: 0/7
Theft Alert Level			'	
Low	Medium	High		
Lock Alert Sound				3
Delete Lock		Û		

- 1 Enter the setting page.
- (2) Click "Fingerprints Management".
- ③ Click "Add a Fingerprint" for the fingerprint collection,

please try to input your fingerprint for 7 times to fully collect the fingerprint.

Note: Ensure the lock is nearby and is connected with the App for setting.

#### Share Authorization Code

15:05		all 46 🗈
<	My ZiiLock	
ZiLock Name	ZiiLock-32B9	1
Bluetooth	ZiiLock-32B9	
SN Code	3863	
Firmware version	001C	>
Fingerprints Manag	gement	>
Bound User Manag	gement	>
Turn off Bluetooth		>
Alert Settings Theft Alert Level	1	
Low	Medium	High
Lock Alert Sound		
Delete Lock		Û
		- /

 Enter the setting page. Click "Bound User Management".
Click "Share Authorization Code" to generate the authorization code.

#### Share Authorization Code

15:16		.dl 46 💽	3:1:	3			.u ? =
<	Share Authorization Code		<		Detected Devic	es	C
Your friend ZiiLock		bind your	Conne	ctable Blu	etooth		_
	Authorization Code.		ZiiLock	-3289			Connect
	A421		ZiiLock	-EC18			Connect
	Сору						
				Please	enter the authori	zation co	de
(	Regenerate		A	121			
			c	Cancel		ок	
		J					

③ Your friends can bind the shared lock with the authorization code via ZiiLock App and use the lock.

#### Authorization Management



- ① Enter authorization management page.
- View the authorized users.
- ③ Unbind your users' authorization.

## **Emergency Unlock**



ZiiLock is equipped with two mechanical keys to unlock

even if you forget to charge it.

#### Quality Assurance

6 months warranty: lock only (not including accessories)

ZiiLock is warrantied to be free from manufacturer defects in materials and/or workmanship for 6 months from the date of original purchase. This warranty does not cover normal wear&tear and any unauthorized modifications done to ZiiLock and /or its components.

Please send failure videos or photos to our official email (support@ziilock.com) to contact us when there is a product failure. We will spare no efforts to provide you good services.

## ZiiLock

#### ZiiLock Product Manual

Please read this manual before using ZiiLock and keep this manual for future reference