

The printer parameter Settings of lychee slicer are inconsistent with the original printer Settings or the format of slice export is incorrect. We only provide a few newly listed printers whose parameter Settings are consistent with the original production and will not affect the printing results. If you don't find the printer parameter Settings you need here, please download the CHITUBOX slicer parameters we provided.

Once you have downloaded the lychee resin file, you can follow the following steps to import the resin file.

The screenshot shows the Lychee Slicer Resin & Filament Beta interface. The top section is titled "3D Printer" and contains a grid of printer icons. The "Elegoo Saturn 2" printer is highlighted with a red box. Below the grid is a navigation bar with buttons for "Add", "Import", "Export", and "Edit". A red arrow points to the "Add" button with the text "1-Add printer".

The bottom section is titled "Resin - Printing Settings" and contains a table with columns for "Printer", "Brand", "Name", and "Thickness". The "Elegoo Saturn 2" printer is selected in the "Printer" column. A red arrow points to the "Add New Resin" button at the bottom of the table with the text "2-Add resin file".

Printer	Brand	Name	Thickness
Elegoo Saturn 2	Default	Default	50um (official)
Anycubic Photon M3 Plus			
Anycubic Photon M3 Premium			
Anycubic Photon Mono X			
Anycubic Photon Mono X 6K			
Creality Halot One			
Elegoo Jupiter			
Elegoo Mars Pro			

### COMMUNITY RESIN PROFILES Beta

Find the different resin profiles according to your printer, extracted from the prints made by the community. Warning! These profiles are only a basis, it may be necessary to adapt them according to your usage and environment (size of the support points, ambient temperature, etc) [Read more...](#)



#### Community resin profile filters:

Printer Brand: Elegoo | Printer Model: Saturn 2 | Resin Brand: Default | Resin Name: Default | Resin Color: Default | Filter: All

#### Resin profiles created by the community:

Resolution	Time	Speed	Lift	Used by	Prints	Validated by
50 um	2.5 s	65 mm/m	3 mm	1000+ users	53 % 1000+ prints	68+ users Details
50 um	3 s	65 mm/m	3 mm	100+ users	61 % 10+ prints	3+ users Details
50 um	2.5 s	65 mm/m	3 mm	100+ users	73 % 50+ prints	3+ users Details
50 um	3.5 s	65 mm/m	3 mm	10+ users	40 % 10+ prints	2+ users Details
30 um	3 s	65 mm/m	3 mm	5+ users	0 % 0+ prints	2+ users Details
30 um	2.5 s	240 mm/m	6 mm	5+ users	0 % 1+ prints	2+ users Details
300 um	3 s	65 mm/m	3 mm	5+ users	100 % 5+ prints	2+ users Details
50 um	8 s	100 mm/m	5 mm	1+ users	0 % 0+ prints	2+ users Details
50 um	2.9 s	60 mm/m	4 mm	10+ users	75 % 3+ prints	2+ users Details
50 um	2.5 s	65 mm/m	mm	1+ users	0 % 1+ prints	2+ users Details

3-Click here to add resin file

< Previous 1 2 3 4 5 Next >

#### Import or Create New Resins

Import From File | Add New Resin

Close

### COMMUNITY RESIN PROFILES Beta

Find the different resin profiles according to your printer, extracted from the prints made by the community. Warning! These profiles are only a basis, it may be necessary to adapt them according to your usage and environment (size of the support points, ambient temperature, etc.) [Read more...](#)

#### Community resin profile filters

Printer Brand: Elegoo | Printer Model: Saturn 2 | Resin Brand: Default | Resin Name: Default | Resin Color: Default | Filter: All

#### Resin profiles created by the community

Resolution	Time	Speed	Lift	Used by	Prints	Validated by
50 um	2					69+ users Details
50 um	3					2+ users Details
50 um	2					2+ users Details
50 um	3					2+ users Details
30 um	3					2+ users Details
30 um	2					2+ users Details
300 um	3 s	65 mm/m	3 mm	5+ users	100% 57 prints	2+ users Details
50 um	8 s	100 mm/m	5 mm	1+ users	0% 0 prints	2+ users Details
50 um	2.9 s	60 mm/m	4 mm	2+ users	75% 15 prints	2+ users Details
50 um	2.5 s	65 mm/m	mm	1+ users	0% 1 prints	2+ users Details

### Import resin for "Elegoo Saturn 2" printer

Import resin profiles from Lychee Slicer, or from other supported slicer software, or from exported sliced files (ctb, pwm, pwx, pw0, pwmo, pwms, pws, kmz, km).

Cancel

Add files


4-Click here to add resin file

#### Import or Create New Resins

Import From File

Add New Resin

Close



5-Find the downloaded lychee resin file and select the printer Settings you need

Deselect All



### Import resin for "Elegoo Saturn 2" printer

Profile(s) in the "Elegoo Saturn 2 Resin.lyr" file

- LITLIQ LITLIQ EC51 Fast Standard Resin Gray 150um gray 150um
- LITLIQ LITLIQ FX60 Flexible Resin Black 75um black 75um
- LITLIQ LITLIQ TH50 Tough Resin Transparent Blue 50um transparent blue 50um
- RESIONE RESIONE Anti-Impact Resin White Gray 50um White Gray 50um
- RESIONE RESIONE C01 Dental Castable Resin Transparent Green 50um transparent green 50um
- RESIONE RESIONE D01 Dental Model Resin Yellow-orange 50um yellow-orange 50um
- RESIONE RESIONE D01S Dental Model Resin Seashell color 50um seashell 50um
- RESIONE RESIONE F39/F39T Flexible Resin White/Transparent 90um White/Transparent 90um
- RESIONE RESIONE F69 Flexible Resin Black 90um Black 90um
- RESIONE RESIONE F80 Elastic Resin Black/Gum Color 100um Black/Gum 100um
- RESIONE RESIONE G217 Tough Resin Clear 75um Clear 75um
- RESIONE RESIONE HT100 Heat-Resistant Resin Transparent yellow 50um transparent yellow 50um
- RESIONE RESIONE K Tough Resin Black 50um black 50um
- RESIONE RESIONE M58 Gray/M68 White Tough Resin 50um Gray/ White 50um
- RESIONE RESIONE M70 High Precision Resin Salmon 50um salmon 50um
- RESIONE RESIONE TH72 Long-Lasting Resin Gray 50um Gray 50um
- RESIONE RESIONE W90B Water-Washable Resin Transparent/Blue/White/Gray 50um Transparent/Blue/White/Gray 50um

Cancel

Import



#### COMMUNITY RESIN P

Find the different resin profiles according to your printer. These profiles are only a basis, it may be necessary to adjust them (e.g. ambient temperature, etc.) Read more...

#### Community resin profile fil

Printer Brand Printer Model

Elegoo Saturn 2

#### Resin profiles created by fil

Resolution	Printer Model
50 um	2
50 um	3
50 um	2
50 um	3
50 um	3
30 um	3
30 um	2
30 um	2
300 um	3
50 um	8
50 um	2
50 um	2

#### Import or Create New Resin

Import or Create New Resin

### COMMUNITY RESIN PROFILES Beta

Find the different resin profiles according to your printer, extracted from the prints made by the community. Warning! These profiles are only a basis, it may be necessary to adapt them according to your usage and environment (size of the support points, ambient temperature, etc) [Read more...](#)



#### Community resin profile filters:

Printer Brand: Elegoo | Printer Model: Saturn 2 | Resin Brand: Default | Resin Name: Default | Resin Color: Default | Filter: All

#### Resin profiles created by the community:

Resolution	Time	Speed	Lift	Used by	Prints	Validated by
50 um	2.5 s	65 mm/m	3 mm	1000+ users	53% 1000+ prints	60+ users
50 um	3 s	65 mm/m	3 mm	100+ users	61% 10+ prints	3+ users
50 um	2.5 s	65 mm/m	3 mm	100+ users	73% 50+ prints	3+ users
50 um	3.5 s	65 mm/m	3 mm	10+ users	40% 10+ prints	2+ users
30 um	3 s	65 mm/m	3 mm	5+ users	0% 0+ prints	2+ users
30 um	2.5 s	240 mm/m	6 mm	5+ users	0% 1+ prints	2+ users
300 um	3 s	65 mm/m	3 mm	5+ users	100% 5+ prints	2+ users
50 um	8 s	100 mm/m	5 mm	1+ users	0% 0+ prints	2+ users
50 um	2.9 s	60 mm/m	4 mm	10+ users	75% 5+ prints	2+ users
50 um	2.5 s	65 mm/m	mm	1+ users	0% 1+ prints	2+ users

< Previous 1 2 3 4 5 Next >

#### Import or Create New Resins

Import From File | Add New Resin

Close



### 3D Printer

Add and / or select your 3D printer. Each 3D printer is associated with its own profile parameters.

Anycubic Photon M3 Plus	Anycubic Photon M3 Premium	Anycubic Photon Mono X	Anycubic Photon Mono X 6K	Creality Halot One	EPAX E10 8K	EPAX X10 5K	EPAX X10 8K
Elegoo Jupiter	Elegoo Mars Pro	Elegoo Saturn	Elegoo Saturn 2	Phrozen Sonic Mini 8K	UniFormation GKtwo		

[Add](#) [Import](#) [Export](#) [Edit](#)

Finally, the corresponding resin setting can be selected for slicing

### Resin - Printing Settings

Set your resin and 3D printing settings: layer thickness, speed and more

Printer	Brand	Name	Thickness	
<b>Elegoo Saturn 2</b>	Default	<b>RESIONE Anti-Impact Resin White Gray 50um White Gray</b>	<b>50um</b>	<b>Edit</b>
Anycubic Photon M3 Plus	LITLIQ			
Anycubic Photon M3 Premium	<b>RESIONE</b>	RESIONE C01 Dental Castable Resin		
Anycubic Photon Mono X		Transparent Green 50um transparent green		
Anycubic Photon Mono X 6K		RESIONE D01 Dental Model Resin		
Creality Halot One		Yellow-orange 50um yellow-orange		
Elegoo Jupiter		RESIONE D01S Dental Model Resin		
Elegoo Mars Pro		Seashell color 50um seashell		
		RESIONE F39/F39T Flexible Resin		
		White/Transparent 90um		
		White/Transparent		

[Add New Resin](#) [Export](#)