



Smart Light Bulb User Manual

Read this user manual carefully before you use the appliance and save it for future reference.

Part 1: Quick Start Guide


1. Scan the QR code or download the "PlusMinus" APP at www.plusminus.ai/app



2. Register an account with your email in and login App.
3. Add device and select the Device Type;



4. Switch the light bulb on-off-on-off-on, it should be noticeably breathing.



Follow the in-app instructions to complete the installation.

Warnings :

Do not install the led bulb with wet hand or when standing on wet or damp surfaces.

Do not modify the the smart led bulb hardware or software.

This may cause injury or property damage, and will void the warranty.


Only use indoors, in a dry location with ambient temperature controls.

To avoid fire, shock, or death, TURN OFF POWER before installing, by locking the appropriate circuit breaker in the OFF position or removing the led bulb.

Part 2: How to connect to Alexa


Method 1: App to App

1. Add devices in "PlusMinus" App and keep them online;
2. Login your Amazon account in "Amazon Alexa" App;




3. Open the PlusMinus app and then Click the "Smart integrations" button on the right upper corner.

Afterward, choose link to "Amazon Alexa";




4. Click " Sign in with Amazon" and then follow the instruction to link the skill.



Method 2

1. Add devices in "PlusMinus" app;
2. Launch "Amazon Alexa" choose "Skills" from menu;



3. Search "PlusMinus" skill and click "ENABLE";
4. Enter your "PlusMinus" Account and Password, then click "Link Now";
5. Control devices by voice.
"Alexa, turn off the light."
"Alexa, turn on the living room lights."

Part 3: How to connect to Google Home

Method 1: APP to APP

1. Login your Google account in Google Home.
2. Open PlusMinus app and click the "Smart Integrations" button on the right upper corner. Afterward, choose link to "Google Assistant".



3. Click "Link with Google Assistant" and it will take you to an authorization page. Click "Agree and Link" .




4. Now your smart devices should be listed in the Home Control page and you can control them with your voice via the Google Home devices.


Method 2: Google Flip

1. Launch "Google Home" and click "+Add" button, then choose "+ Set up device";

2. Then at the bottom of the list, click "Have something already set



3. Search and choose "PlusMinus" in the list, it will take you to the authorization page, click "Agree and Link";



4. Now your smart devices should be listed in the Home Control page and you can control them with your voice via the Google Home devices.

Part 4: Customer service and FAQ

If you have any more questions contact us inside the PlusMinus App



FAQs

1.How do I connect multiple devices one time?

You can put all devices in configuration mode, and connect them to the APP simultaneously. You can also connect one bulb in the APP and then use the "Search device" to connect other devices.

2.How to divide my Wi-Fi to 2.4Ghz and 5Ghz?

LUMIMAN light bulb support most of dual-band Wi-Fi routers, if the device failed

to connect the APP, please log in to your Wi-Fi router's setting page, uncheck "Keep a common network name (SSID) and password for both 2.4 and 5.0 GHz bands." or edit the name of the 5.0 GHz band to differ it from the 2.4GHz band.

3.What can I do when my device(s) fail to connect to the APP by EZ and AP mode?

Switch off the Wi-Fi router. Find another phone and set up a personal hotspot as a Wi-Fi network. The Wi-Fi SSID and password for that hotspot should be the same as the ones set for your Wi-Fi router. After the device has connected successfully, you can switch off the personal hotspot and switch on the Wi-Fi router. The light bulb should connect to the Wi-Fi router automatically.

4.Why my app need allow my location permission?

IOS 13 and Android 6.0 or higher needs your permission to access location, so that the APP can scan your Wi-Fi list.

5. One device connected successfully but the other fails.

It may be that your Wi-Fi router has reached the maximum number of devices allowed to connect to it therefore the other device is not allowed to connect. Most Wi-Fi routers only support 15-20 devices. You can check the Wi-Fi router settings or try using "Search device" to connect the other device.

Warranty

2 year warranty	Tech Support Email: support@lumiman.com
----------------------------	---

