F00089
Cabinet



PART LIST

A 	B 	C 	D 	E 
Top Panel 1 PC	Bottom Panel 1 PC	Side Panel 2 PCS	Left Door Panel 2 PCS	Right Door Panel 2 PCS
F 	G 	H 	I 	J 
Partition Panel 1 PC	Adjustable Shelf Panel 2 PCS	Back Panel 1 1 PC	Back Panel 2 1 PC	Back Panel 3 1 PC
K 	L 	M 	N 	
Back Panel 4 1 PC	Metal Leg 2 PCS	Metal Strip 2 PCS	Middle Metal Leg 2 PCS	

HARDWARE LIST

1 Φ1/4″*3/8″	2  Φ1/4″*1-3/8″	3 Φ8*30mm	4 	5 Φ3.5*12mm
Short Bolt 12 PCS (Extra 1)	Long Bolt 8 PCS (Extra 1)	Wood Dowel 12 PCS (Extra 1)	Hinge 8 PCS	Hinge Screw 48 PCS (Extra 1)
6	7 Φ5/32″*3/4″	8 	9 Φ3*14mm	10 Φ3*12mm
Knob 8 PCS	Round Head Bolt 8 PCS	Magnet Latch 2 PC	Latch Screw 4 PCS	Round Head Screw 30 PCS (Extra 2)
11 	12			
Allen Wrench 1 PC	Shelf Holder 8 PCS (Extra 1)			

ADDITIONAL TOOLS (Not Provided)

Note: It is not recommended to use power tools during assembly.



Phillips Head Screwdriver

STEP 1



Part 1 12 PCS

Part 11 1 PC

STEP 2



Part 4 8 PCS

Part 5 16 PCS

Part 6 8 PCS

Part 7 8 PCS

STEP 3



Part 8  2 PCS

Part 9 4 PCS

STEP 4



Part 3  12 PCS

STEP 5



Part 10 30 PCS

STEP 6



Part 2 8 PCS

Part 11 1 PC

STEP 7



Part 5 32 PCS

STEP 8



Part 12 8 PCS

STEP 9





#A	#B	#C	#D	#E
1-1/2"xØ4xD8		5/8"xØ3xD8		
Long Screw 1 PC	Wall Anchor 1 PC	Short Screw 1 PC	Safety Wall Strap 1 PC	Flat Washer 2 PCS

SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) through flat washer (E) and safety wall strap (D) and then fix them to top panel (part A) using phillips head screwdriver.
2. Drill a 11/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in top panel (part A) where safety wall strap (D) is attached. Tap wall anchor (B) into the hole.
3. Insert long screw (A) through flat washer (E) and safety wall strap (D) into wall anchor (B) using phillips head screwdriver.

   Note: This item is not intended for clothing storage use.



ADJUST YOUR DOORS TO MAKE THE GAPS MORE EVEN (OPTIONAL).

STEP 1

Open the door



STEP 2

Adjust the gap between door panel and side panel



Loosen the screw indicated a little, adjust the hinge to right position (see step 2a & 2b), then tighten the screw.

STEP 2a MOVE DOOR IN



Push the hinge back a little.

STEP 2b MOVE DOOR OUT



Pull the hinge forward a little.

STEP 3

To adjust the gap between two door



Loosen or tighten the screw indicated a little to adjust the gap between doors panels (see step 3a & step 3b)

STEP 3a MOVE DOOR RIGHT



Turn the screw clockwise a little as shown to make the gap small.

STEP 3b MOVE DOOR LEFT



Turn the screw counterclockwise a little as shown to make the gap big.