

# ZUMIMALL®

Get Smarter About Your Security

USER MANUAL



**ZM-6S** OUTDOOR SECURITY CAMERA  
WIRED | WIFI | WATERPROOF | 24/7 LIVE

[cam6s@zumimall.com](mailto:cam6s@zumimall.com)



# Warranty Service

Thanks for your purchase and support.

We have been optimizing our products and improving lifetime customer services to offer you a better shopping experience. If you have any questions or problems when using the product, feel free to contact us by E-mail and we will reply to you within 24 hours. We will also appreciate any valuable suggestions.

Register via link below to get 3 Years Warranty Extension.

<http://bit.ly/zuReg>

## **Product Services**

Email: [cam6s@zumimall.com](mailto:cam6s@zumimall.com)

Distributor: [distributor@zumimall.com](mailto:distributor@zumimall.com)

Cell/iMessage/SMS/Whatsapp/Wechat: [+86 18938687483](tel:+8618938687483)

## **More About Us**

Official Web: [www.zumimall.com](http://www.zumimall.com)

Facebook: [www.facebook.com/zumimalloffice](http://www.facebook.com/zumimalloffice)

Amazon Office Store: [www.amazon.com/zumimall](http://www.amazon.com/zumimall)

# INDEX

# PAGE

---

1. What's in the Box -----	P1
2. Camera Diagram -----	P2
3. Download & Install App -----	P3.4
4. Account Registration -----	P5
5. Add Camera to App -----	P5
5.1 Preparations Before Connection -----	P5
5.2 Connect Camera to App -----	P6
6. Camera Installation -----	P7
6.1 Installation Tips -----	P7
6.2 Installation Steps -----	P7
7. Device Menu -----	P8
7.1 Device Page -----	P8
7.2 Live Page -----	P9
7.3 History Page -----	P10.11.12
7.4 Cloud Page -----	P13
8. Camera Settings -----	P13
8.1 Multi-User Sharing -----	P14.15
8.2 Basis Function -----	P16.17
8.3 Alert Settings -----	P18
8.4 SD Card Management -----	P19
8.5 Cloud Storage Service -----	P19
8.6 Delete the Device -----	P20






# **INDEX**

# **PAGE**

---

9. Message Menu -----	P20
9.1 Records Playback/Delete -----	P20.21
10. Homepage -----	P21.22
10.1 Share Pictures & Videos -----	P22
10.2 Send Your Feedback -----	P23
11. IR Body Detection -----	P23
12. Two-Way Audio -----	P24
13. Reset -----	P25
14. Multi-Device Management -----	P25
15. Product Specification -----	P26.27
16. Firmware Upgrade -----	P27
17. Other Support -----	P27
18. Trouble Shooting -----	P27.28.29

## 1. What's in the Box:



1 ZM-6S Camera

1 Power Adapter (DC 12V 1A)


1 User Manual

1 Screw Set

1 Hex Key

1 11.5ft Charging Cable

## 2. Camera Diagram :



Status Light	Camera Status
Solid in red	Malfunctional
Flashing red	Waiting Wi-Fi connection
Flashing blue	Connecting
Solid blue	Wi-Fi connected, camera working normally

### 3. Download & Install App:

Download the ZUMIMALL App from Google Play™ or App Store™. The camera supports Android and iOS systems.

OR scan the QR code below using the QR scanner on your phone.

**NOTE:** Google Play™ is the trademark of Google Inc.  
App Store™ is the service mark of Apple Inc.



IOS



ZUMIMALL





Android




\* Turn on both of the following permissions.

1. **Allow** ZUMIMALL to access mobile cellular data and wireless LAN. Otherwise, it will fail to connect the camera.
2. **Allow** ZUMIMALL to receive notifications. Otherwise, the phone will not receive alerts when motion is detected.



## 4. Account Registration:

New user needs to sign up "ZUMIMALL" App with email. Click "Sign up" to create a New Account and follow the steps to complete registration.



## 5. Add Camera to App:

### 5.1 Preparations Before Connection

5.1.1 Insert a **Mirco** SD Card into the camera to save video clips(Card **not included**; Up to 128G)or you can start the 7-day free cloud service. Without an SD Card or cloud service, no video will be saved.

5.1.2 Plug camera into your AC outlet using the included DC power adapter.

5.1.3 The camera **only works with 2.4G Wi-Fi**, it is not compatible with 5G.

5.1.4 While connecting, stay close to the router.



**2.4G ONLY**


5




## 5.2 Connect Camera to App




Tap '+' to Add Device



Select 'Camera'




Tap 'Next'



Reset Camera and Tap 'Next'




Input Wi-Fi Password



Prepare Scanning



Scan QR code when Indicator Flashing Slowly in Red



Connection is Complete at 100%

## 6. Camera Installation:

### 6.1 Installation Tips


- Make sure the camera is within Wi-Fi range.
- **Avoid aiming camera towards strong lights/mirror/window/swimming pool.**
- Recommend a distance within 39ft (12m) between camera and motion objects.
- Keep the camera at least 3ft/1meter away from electronic/electric devices such as microwave, refrigerator, oven, etc. to avoid interference.

### 6.2 Installation Steps

Step 1: Choose a dry, clean, flat surface (Recommend attaching directly on a wooden wall; avoid uneven wooden and stucco walls).

Step 2: Drill holes in the wall and fasten the camera with screws.


Step 3: Rotate the camera to a proper angle.



## 7. Device Menu:


### 7.1 Device Page

After installing the camera, set up the camera on the ZUMIMALL App. Begin by becoming familiar with the device page first.




## 7.2 Live Page

Click triangle button on the picture to enter a live view, where you can screenshot a live page, have live talk, record live videos, turn on/off Motion Detection.



## 7.3 History Page

After entering live page, you can easily switch to the history page.



### 7.3.1 SD Card


An SD Card or cloud service is essential for storing videos or alert videos won't be saved and cannot be accessed. When the SD Card is full, the video clips recorded in the past will be automatically overwritten. You don't need to delete them manually.

Requirements for SD Card :

- The card must be a Class 10 Micro SD card, reaching at least 10MB/S.
- The camera supports up to a 128G Micro SD Card.

If SD card is not detected:

- Confirm the SD card has been fully inserted and locked in place.
- Use a card reader to test the SD card; try to format it to check if the SD card works well on PC.
- Try another SD card to check if it works well with the camera.





## 7.3.2 Replay Video Restored in SD Card


To replay the video, enter the History Column and follow the steps as below.  
(For example, to check events around 9 pm on September 14,2020)

Step 1 - Click Calendar and choose the 14,Sept

Step 2 - Tap Alert button

Step 3 - Click event on 20:59, move red axis to 21:00 to replay the video

**Notes:** Blue bar is 24/7 recording, red bar refers to motion detection clips



## 7.4 Cloud Page :

### 7.4.1 About Cloud Service


After 7-day free trial for new users, you can decide whether to subscribe to the cloud storage plan. The subscription fee will be shown on the App when you click on Cloud Storage service.

### 7.4.2 Replay Video Restored in Cloud

To check history in cloud, please refer to the same steps in the History Page.

## 8. Camera Settings:

Enter live view from device page, click '...' button to enter camera settings. You can set most camera functions on this page using the icon at the top right corner on Live View.





## 8.1 Multi-User Sharing

You can share your device up to 6 users by selecting 'Device Share' on camera settings interface. Steps are as below:


1. Tap 'Add'
2. Scan QR code of other user's account or manually enter other's email account
3. Allow sharing on your phone
4. Accept sharing request on other user's phone

**Note:** Other user need to register on ZUMIMALL App first





Tap 'Share'



Select 'Accept'

## 8.2 Basic Function

### 8.2.1 Status Light

Status light is default to be ON, showing blue when the camera is working. If you want to hide the light, you can turn it off.


Night vision light (red) will automatically show up in darkness. When night vision is turned off, light will go out.

### 8.2.2 Rotate View

In case your camera is installed incorrectly leading to the live view being upside down, you can turn on/off Rotate View to rotate upside-down view.

### 8.2.3 Night Vision


Night vision default is Automatic. Video will turn to black-and-white from color when it's dark at night. If you set Night Vision to ON, the video will stay in black-and-white both day and night.



## 8.2.4 Sleep Mode


There are several camera modes:

- a. **Lens ON:** Camera will keep working and recording
- b. **Lens OFF:** Camera will be turned off
- c. **Privacy Schedule:** Camera will work only during a specified time period. You can create an alarm plan to set working hours for the camera. When setting the plan: Start time should be earlier than End time.  
(for example, if you want to set working times as 8:00PM- 07:00AM, it must be divided into two pieces: 8:00PM-12:00AM, & 12:00AM-07:00AM)
- d. **Geofence:** Camera will be turned off when phone and camera are on the same WiFi network.



### 8.3 Alert Settings


The camera supports both motion detection and noise detection. You can turn on/off detection or adjust sensitivity(3 levels, low to high). Make sure motion detection is turned on if you need to receive motion alerts. (For more details about sensitivity, please refer to IR Body Detection)



## 8.4 SD Card Management


The camera supports **Full-Day Recording** and **Event Recording**. Make sure camera mode is LENS ON.

- In Full-Day Recording mode, the camera will record videos all the day and alert you when motion is detected. If you change to other mode or set alarm plan, full-day recording will be automatically disabled.
- In Event Recording mode, you can set recording time as 1,2,3 minutes.



## 8.5 Cloud Storage Service

There is 7-day free trial to allow you to try cloud storage before subscription. Cloud service is offered in Alarm Recording/All-day Recording, with 3-day/7-day/30-day overwriting storage plans. This means all recorded videos in the cloud will disappear after 3, 7 or 30 days depending on your service plan.





## 8.6 Delete the Device


If the camera goes offline, delete the device from the App, reset the camera and reconnect it.

## 9. Message Menu:

### 9.1 Records Playback/Delete


Enter **Alarm Messages** to check or delete alarm records. You can also enter alarm messages from device menu.





## 10. Homepage :

In your homepage, just click the QR code to enter your profile where you can easily change your account name or password.



## 10.1 Share Pictures & Videos

All screenshots or manually recorded videos on live/history/cloud page will be saved in Pictures & Videos. Files here can be saved in your phone Album or shared to others directly.

**Notes:** Recorded files on the SD card/Cloud are specially encrypted and cannot be saved or shared directly with other devices. However, you can manually record videos and share them to others from Pictures & Videos. Or you could also contact us for file converter package by which you can transfer the file to preferred format and share with others freely. (for SD card only)

## 10.2 Send Your Feedback

- If you like the product, welcome to share your comment.
- If you have any questions, please feel free to contact us by email : [cam6s@zumimall.com](mailto:cam6s@zumimall.com) or phone number: [+86 18938687483](tel:+8618938687483)

## 11. IR Body Detection :

IR body detection level is adjustable, you can set motion detection level to Low, Medium or High.

<b>Sensitivity</b>	<b>Day Detection Distance</b>	<b>Night Detecting Distance</b>	<b>Noise Detection</b>
Low	Up to 4 meters (13ft )	Up to 5 meters (16ft )	85db
Medium	Up to 6 meters (19ft )	Up to 7 meters (23ft)	75db
High	Up to 12 meters (39ft )	Up to 8 meters (26ft)	65db

\* **Tips:** Higher motion detection sensitivity offers longer detecting distance(for moving and living objects), higher noise detection can detect lower level noises. You can easily change the sensitivity to LOW in case of false/frequent alarms or change to HIGH if you need more sensitive detection.


## 12. Two-Way Audio:

Step 1: Activate the audio option.

Step 2: Press and hold the intercom button to speak.

Step 3: Release the button to listen.

**Tips:** To activate audio function, please allow App to activate the microphone.




## 13. Reset:

Step 1: Delete the device from App. (If the camera was added to App)

Step 2: Keep pressing reset button for 3-5s until you hear a "Boogu" sound and status light flashes slowly in red.

Step 3: Reconnect the camera.

## 14. Multi-Device Management:



Click "+" to Add More Devices

## 15. Product Specification :

Camera	Specification
Camera Lens	3.0mm@F2.0, Field of view: 130°
Image sensor	1/2.9" 2Megapixel CMOS
Effective pixels	1920(H)*1080(V)
IR distance	Night visibility up to 49ft(15m)

Video&Audio	
Compression	H.264
Video resolution	360P,1080P for option
Video bit rate	32Kbps~2Mbps
Audio input/output	Built-in Mic/Speaker
Alarm trigger	Intelligent motion detection

Network	
Communication Protocol	TCP/IP, HTTP, DHCP, DNS, RTSP
Wi-Fi	2.4G Wi-Fi only(IEEE802.11b/g/n)
Supported OS system	iOS 8 or later,Android 4.2 or later
Max. user access	6 users

General	
Operating temperature	-20 °C to 50 °C (-68°F-122°F)
Power supply	DC 12V/1A
Storage method	SD card(Max.128G) Cloud storage
Ingress protection	IP65 Waterproof

## 16. Firmware Upgrade :

When your camera is connected on ZUMIMALL App, it will prompt you when the latest firmware is available.

You can also manually check the firmware upgrade in Device Version of the App.

**Do not turn off the power supply during upgrade!**

## 17. Other Support :

You could email us for video tutorial on how to use the camera.

You could email us for file converter (program package) if you need to download, save, read videos on PC.

## 18. Trouble Shooting :



NO.	Description	Solution
1	Unable to Register Account	Make sure you select correct country and enter correct email address
2	Unable to Connect Camera	Check your Wi-Fi name and password Ensure your Wi-Fi is 2.4G. Not support 5G Confirm your camera and phone close to router for set up
3	Reset	Keep pressing the reset button for 3-5 seconds Hear "Boogu" sound Status light flashes slowly in Red
4	Change to New Network	Remove the camera in ZUMIMALL App Press the reset button to factory setting Re-connect the camera
5	No Motion Detection	Ensure you have turned on motion detection and camera lens on App Ensure the status light is blue when motion detected
6	Frequent Alarm	Adjust the installation angle to detect only the main zone you wanna detect (Camera triggered frequently) Adjust the motion detection sensitivity to "Low" Turn off noise detection
7	Why Someone Crossed without Alarm	Make sure motion detection is turned on Confirm camera is within the range of IR monitoring area
8	No Alarm Push	Make sure you have allowed notifications on ZUMIMALL App and phone

9	No Alarm Video	Make sure Micro SD card inserted/Cloud Storage activated
10	Device Offline	Check if the camera is powered off Check if the camera is connected Make sure network is steady
11	App Flashback	Phone system version is too low Update the phone system version and camera firmware version
12	Unable to Add Friend to Share Device	Your friend's account must be in the same country as yours. For example, accounts in Europe and America cannot share with each other

Please Email us for Better Solution  
before returning any unqualified product to Amazon

[cam6s@zumimall.com](mailto:cam6s@zumimall.com)

# THANK YOU







尺寸宽度140MM\*高度140MM

128G 铜版纸 双铜