

# ZUMIMALL<sup>®</sup>

Get Smarter about your Security

QUICK START GUIDE



**GX1K** BATTERY POWERED CAMERA  
WIRELESS | WIFI | OUTDOOR | SECURITY

[gx1k@zumimall.com](mailto:gx1k@zumimall.com)



# Warranty Service

Thanks for your shopping and trust.

We are keeping to optimize product and improve our **lifetime customer service** to offer you a better shopping experience. If you have any problems, please feel free to **send us an E-mail**. We will solve your problems **within 24 hours**. Besides, your advice or suggestions will be much appreciated and welcomed.

Register via link below to get **3 Years Warranty** Extension.

<http://bit.ly/zuReg>

## **Product Service**

Email: [gx1k@zumimall.com](mailto:gx1k@zumimall.com)

Distributor: [distributor@zumimall.com](mailto:distributor@zumimall.com)

Cell/iMessage/SMS/Whatsapp/Wechat: [+86 18938687483](tel:+8618938687483)

## **More About Us**

Official Web: [www.zumimall.com](http://www.zumimall.com)

Facebook: [www.facebook.com/zumimalloffic](http://www.facebook.com/zumimalloffic)

Amazon Office Store: [www.amazon.com/zumimalls](http://www.amazon.com/zumimalls)





# INDEX

# PAGE

---

1. What's in the Box -----	P1
2. Product Diagram -----	P2
3. Download & Install App -----	P3
4. Account Registration -----	P4
5. Camera Setup -----	P4.5
5.1 Preparations for connection -----	P4
5.2 Connect Camera to App -----	P5
6. Camera Installation. -----	P6
7. Monitoring Area -----	P6
8. Important Notes -----	P7
9. App Menu -----	P8
10. Camera Settings -----	P9
11. PIR Body Detection -----	P9.10
11.1 Body Detection Alarm Setting -----	P9
11.2 Alarm Notifications -----	P10
11.3 Records Playback & Delete -----	P10
12. Two-Way Audio -----	P11
13. Battery Management -----	P11
14. Solar Panel -----	P12-14
15. Multi Device Management -----	P15
15.1 Multi Camera Management -----	P15
15.2 Multi User Sharing -----	P15
16. Reset -----	P16
17. Trouble Shooting -----	P17.18



## 1. What's in the Box:



ZUMIMALL Battery Camera \* 1  
Outdoor Metal Mount \* 1  
Quick User Guide \* 1  
Screws Set \* 2(1-Camera/1-Solar Panel)

Solar Panel with Cable \* 1  
Solar Panel Metal Mount \* 1  
USB Cable \* 1

## 2. Product Diagram:



- ① Camera Lens
- ② IR
- ③ PIR Sensor
- ④ Antenna
- ⑤ Camera Mode Indicator
- ⑥ Microphone
- ⑦ Reset Button
- ⑧ LED Indicator
- ⑨ Speaker
- ⑩ Power Button
- ⑪ SD Card Slot
- ⑫ USB Port

Power Button	Keep pressing for 5-10 seconds to power on/power off
Reset Button	Keep pressing for 5-10 seconds to reset and restart
Blink Slowly in Red	Awaiting Wi-Fi connection, ready for adding devices
Blink Fast in Red	Wi-Fi connecting
Solid in Red	Network problem
Solid in Blue	Wi-Fi connected, camera running normally
Blink Slowly in Blue	AP mode/hardware updating

## 3. Download & Install App :

Download ZUMIMALL App from Google Play™ or App Store™.

Or scan the QR codes as below, with QR code scanner in your smart phone.

**NOTE:** Google Play™ is a trademark of Google Inc.

App Store™ is a service mark of Apple Inc.



iOS




ZUMIMALL



Android


**\* Tips:** Please turn on both of the following permissions.

1. Allow ZUMIMALL to access mobile cellular data and wireless LAN, otherwise it will fail to connect the camera.
2. Allow ZUMIMALL to receive pushed messages, otherwise the phone will not receive alarms when motion is detected.



## 4. Account Registration :

New user needs to sign up 'ZUMIMALL' App with email. Click 'Sign up' to create a New Account and follow the steps to complete registration.



## 5. Camera Setup :

### 5.1 Preparations for connection

5.1.1 Insert Mirco SD card (NOT included) when the camera is off, for saving videos caused by motion detection automatically. (Supports up to 128GB)


5.1.2 Camera only works with 2.4G Wi-Fi, not support 5G.



## 5.2 Connect Camera to App



Tap '+' to Add Device



Select 'Battery Camera'



Tap 'Next'



Reset it and Tap 'Next'



Input Wi-Fi Password



Prepare the Scanning



Scan QR Code When Indicator Flashing Slowly in Red




Finished Installation When Reaches 100%

## 6. Camera Installation :

6.1 For wooden wall, it's recommended to screw the bracket on.


6.2 For cement or ceramic tile wall, it's recommended to drill holes in the wall and fasten with provided explosion screws.



Rotate the button counterclockwise to take off the camera.

## 7. Monitoring Area :

Ajust an angle greater than 10 degrees between the camera PIR lens and the moving objects




## 8. Important Notes for Reducing False Alarms:

- ⚠ To reduce false alarms, please note that:
- Do not install the camera in a position facing strong lights/mirror/window/swimming pool.
  - Do not place the camera too close to any angel with busy traffic.
  - Recommended distance between the camera and motion objects is within 10M (32ft).
  - Stay away from the outlets, including air conditioner vents, humidifier outlets, the heat transfer vents of the projectors, etc.
  - Keep the camera at least 1 meter away from any wireless devices to avoid interference, such as microwave stove, Wi-Fi routers and etc.




## 9. Device Menu:



1	Device List	15	Volume On/Off
2	Add Camera	16	Full Screen
3	Real Time	17	Preview
4	Live View Button	18	Screenshot Button
5	Camera Name	19	Body Detection On/Off
6	History Playback	20	Recording in SD Card
7	Cloud Storage	21	Cloud Storage
8	Messages	22	Record Video to Phone
9	My Device List	23	Two-Way Talk
10	Personal Homepage	24	Zoom
11	Quit Live Viewing	25	Time Bar
12	Camera Setting	26	History Screenshot
13	Battery Status	27	Alarm Record Album
14	HD/SD Switch	28	Date of History Record


## 10. Camera Settings :



## 11. PIR Body Detection :

### 11.1 Body Detection Alarm Setting

PIR 'Body Detection' is default to be on 'High' level. But it is adjustable. Please refer to the pictures below.



Sensitivity	Detecting Distance (For moving and living objects)
Low	Up to 5 meters (16ft)
High	Up to 10 meters (32ft)

\*Tips: Higher sensitivity offers longer detection distance and more alarms.

## 11.2 Alarm Notification

This camera is not designed for 7x24 full day recording. It is only triggered when body motion is detected. Here are system's reactions:


11.2.1 Alarm notifications with sounds from APP.

11.2.2 Pictures/videos automatically stored in SD Card or Cloud.

## 11.3 Records/Playback/Delete

11.3.1 On 'MESSAGES' page, click 'Alarm Messages', you can view all the records listed.

11.3.2 Click the following buttons to playback or delete.



## 12. Two - Way Audio :

Step 1: Activate the audio option.

Step 2: Press and hold the intercom button to speak.

Step 3: Release the button to listen.



## 13. Battery Management :


13.1 The camera comes with built-in Large Capacity battery. Assuming the camera wakes up 15 times/day, the battery can last 3-6 months after fully charged.

13.2 Charger Standard: DC 5V 1/2A (not included). Camera will be fully charged after **8-16 hours**.

13.3 When the battery level is less than 20%, the APP will send you prompt message to charge in time.



## 14. Solar Panel:



### Step 1:

Please find a place which has sunlight for most of a day and adjust the angle to make sure maximum exposure.

The ZUMIMALL solar panel needs few hours of direct sunlight to convert solar energy into electricity. The conversion efficiency is affected by weather conditions, seasonal changes, geographic locations, etc.




### Step 2:

Mount the bracket with the mounting template and the screws provided in the package



### Step 3:

Slot the solar panel into the bracket and make sure it's secure



### Step 4:

Loosen the adjusting control on the bracket and adjust the angle of the solar panel to make it receive direct sunlight, and then retighten the adjusting control to secure your setting

**Step 5:**


Connect the solar panel to the ZUMIMALL Camera with the micro USB cable.

**Important Notes:**

1. Make sure that there is NO blocking on the solar panel. The energy harvesting efficiency drops drastically even when a small portion of the solar panel is blocked.
2. Please don't install the solar panel completely horizontally. Otherwise your solar panel might accumulate dust and other debris easily. It's advised to install the solar panel angularly to make it receive direct sunlight.
3. Wipe the solar panel regularly to remove the dust or debris.

## 15. Multi Device Management :

### 15.1 Multi Camera Management



### 15.2 Multi-User Sharing

Notice: One App account (A) can't login on multiple devices at the same time.

One camera can't be connected to multiple App accounts either.

But camera can be shared form A to B account.

Step 1: Create another new APP account (B) and login on another Phone.

Step 2: Click 'share' on the main phone (A account phone)

Step 3: Use A to scan QR code or Input account ID of B.

Step 4: Accept sharing on B account and refresh page to check



Refer to the Video

## 16. Reset:

Step 1: Keep pressing to remove device

Step 2: Press the reset button for 5-10s until hear the 'Boogu' sound

Step 3: Reconnect as a new camera



尺寸宽度140MM\*高度140MM

128G 铜版纸 双铜

## 17. Trouble Shooting:

NO.	Description	Solution
1	Unable to Connect	Check your Wi-Fi name and password Ensure your Wi-Fi is 2.4G. Not support 5G Ensure your camera and phone close to router for set up
2	Reset	Keep pressing the reset button for 3~5 seconds Hear 'Boogu' LED blink slowly in Red
3	Change to a New Network	Remove the camera in ZUMIMALL APP Press the reset button to factory setting Re-connection
4	No person on Alarm Videos	Adjust camera sensitivity to 'HIGH'. The moving objects may appear from the corner of camera coverage, please adjust the lens angle.
5	Frequent Alarm	Adjust the camera alarm sensitivity to 'Low'
6	No Alarm when someone passes by	Make sure motion detection is turned on. Ensure motion happens beyond the range of PIR monitoring area
7	No Alarm Push	Make sure Notification is turned on from ZUMIMALL and phone
8	No Alarm Video	Make sure insert a SD Card or activate Cloud Service. Click triangle button to play videos.
9	Device Offline	Charge the camera and reconnect it. Ensure the Wifi signal strength is good as above 75%.
10	Battery Durability	Reduce frequency of Motion Detection, Two-way talk, and frequency of viewing Live Feeds

11	Unable to Charge	Charge at least 8-16 hours with a 5V 1A/2A phone charger. LED turns to be red means your camera is charging correctly. Make sure USB power cable and the phone charger both work well.
12	ZUMIMALL APP Flashback	Phone system version is too low or too high.
13	Unable to Register Account	Make sure to select correct country.
14	Unable to Add Friend	Your account and friend's account must be in the same country. For example, accounts in Europe and America cannot share with each other.

Please Email us for Better Solution  
before returning any unqualified product to Amazon

[gx1k@zumimall.com](mailto:gx1k@zumimall.com)

**THANK YOU**



