

ZUMIMALL[®]

Get Smarter about your Security

QUICK START GUIDE



GX1S BATTERY POWERED CAMERA
WIRELESS | WIFI | OUTDOOR | SECURITY

tech@zumimall.com

More Products from ZUMIMALL

Search zumimall on amazon to reach us or find us by <https://www.amazon.com/zumimall>

Indoor/Outdoor Camera:



Outdoor Camera
Wireless



Battery Camera



Battery Powered
Camera



Wireless Solar
Camera



Outdoor Wifi
Camera



24/7 Surveillance
Camera

Smart Doorbell:



Wifi Video Doorbell

Accessories:



Solar Panel For X1 Camera

Warranty Service

Thanks for your shopping and trust.

We are keeping to optimize product and improve our **lifetime customer service** to offer you a better shopping experience. If you have any problems, please feel free to **send us an E-mail**. We will solve your problems **within 24 hours**. Besides, your advice or suggestions will be much appreciated and welcomed.

Register via link below to get **3 Years Warranty** Extension.

<http://bit.ly/zuReg>

Product Service

Email: tech@zumimall.com

Distributor: distributor@zumimall.com

Cell/iMessage/SMS/Whatsapp/Wechat: [+86 18938687483](tel:+8618938687483)

More About Us

Official Web: www.zumimall.com

Facebook: www.facebook.com/zumimalloffice



Amazon Office Store: www.amazon.com/zumimall

INDEX

PAGE

1. What's in the Box -----	P1
2. Product Diagram -----	P2
3. Download & Install App -----	P3
4. Account Registration -----	P4
5. Camera Setup -----	P4.5
5.1 Preparations for connection -----	P4
5.2 Connect Camera to App -----	P5
6. Camera Installation -----	P6
7. Monitoring Area -----	P6
8. Important Notes -----	P7
9. Device Menu -----	P8
10. Camera Settings -----	P9
11. PIR Body Detection -----	P9
11.1 Body Detection Alarm Setting -----	P9.10
11.2 Alarm Notifications -----	P10
11.3 Records Playback & Delete -----	P10
12. Two-Way Audio -----	P11
13. Battery Management -----	P11
14. Multi Device Management -----	P12
15. Reset -----	P13
16. Storage Methods -----	P14
17. Trouble Shooting -----	P15.16

1. What's in the Box:



ZUMIMALL Battery Camera*1



Quick User Guide*1

USB Cable*1

Outdoor Metal Mount*1

Screws Set*1

2. Product Diagram:



- ① Camera Lens
- ② IR
- ③ PIR Sensor
- ④ Antenna
- ⑤ Camera Mode Indicator
- ⑥ Microphone
- ⑦ Reset Button
- ⑧ Charging Indicator
- ⑨ Speaker
- ⑩ Power Button
- ⑪ SD Card Slot
- ⑫ USB Port

Power Button	Keep pressing for 5-10 seconds to power on/power off
Reset Button	Keep pressing for 5-10 seconds to reset and restart
Mode Indicator Blink Slowly in Red	Awaiting Wi-Fi connection, ready for adding devices
Mode Indicator Blink Fast in Red	Wi-Fi connecting
Mode Indicator Solid in Red	Network problem
Mode Indicator Solid in Blue	Wi-Fi connected, camera running normally
Mode Indicator Blink Slowly in Blue	AP mode/hardware updating

3. Download & Install App:

Download ZUMIMALL App from Google Play™ or App Store™.

Or scan the QR codes as below, with QR code scanner in your smart phone.

NOTE: Google Play™ is a trademark of Google Inc.

App Store™ is a service mark of Apple Inc.



iOS




ZUMIMALL



Android


***Tips:** Please turn on both of the following permissions.

1. Allow ZUMIMALL to access mobile cellular data and wireless LAN. Otherwise, it will fail to connect the camera.
2. Allow ZUMIMALL to receive pushed messages. Otherwise, the phone will not receive alarms when motion is detected.



4. Account Registration :

New user needs to sign up 'ZUMIMALL' App with email. Click 'Sign up' to create a New Account and follow the steps to complete registration.



5. Camera Setup :

5.1 Preparations for connection

5.1.1 Insert a **Mirco** SD Card into the camera to save video clips (Card **not included**; **Up to 128G**) or you can start the 7-day free cloud service. Without an SD Card or cloud service, no video will be saved.

5.1.2 Fully charge the camera before first use.

5.1.3 Connect your phone with the same 2.4 G Wi-Fi network you are to connect your camera to. The camera **only works with 2.4G Wi-Fi**, does not support 5G.




5.2 Connect Camera to App



Tap '+' to Add Device



Select 'Battery Camera'



Tap 'Next'



Reset it and Tap 'Next'



Input Wi-Fi Password



Prepare the Scanning



Scan QR Code When Mode Indicator Flashing Slowly in Red




Finished Installation When Reaches 100%

6. Camera Installation :

6.1 For wooden wall, it's recommended to screw the bracket on.


6.2 For cement or ceramic tile wall, it's recommended to drill holes in the wall and fasten with provided explosion screws; Rotate the button counterclockwise to take off the camera.

6.3 It's suggested to test Wifi signal strength (at least 80-85%) before you choose the place to install the camera to ensure camera functions normally.



7. Monitoring Area :

Adjust an angle greater than 10 degrees between the camera PIR lens and the moving objects




8. Important Notes for Reducing False Alarms:

- ⚠ To reduce false alarms, please note that:
- Do not install the camera in a position facing strong lights/mirror/window/swimming pool.
 - Do not place the camera too close to any angle with busy traffic.
 - Recommended distance between the camera and motion objects is within 10M (32ft).
 - Stay away from the outlets, including air conditioner vents, humidifier outlets, the heat transfer vents of the projectors, etc.
 - Keep the camera at least 1 meter away from any wireless devices to avoid interference, such as microwave stove, Wi-Fi routers and etc.



9. Device Menu:



1	Device List	15	Volume On/Off
2	Add Camera	16	Full Screen
3	Real Time	17	Preview
4	Live View Button	18	Screenshot Button
5	Camera Name	19	Body Detection On/Off
6	History Playback	20	Recording in SD Card
7	Cloud Storage	21	Cloud Storage
8	Messages	22	Record Video to Phone
9	My Device List	23	Two-Way Talk
10	Personal Homepage	24	Zoom
11	Quit Live Viewing	25	Time Bar
12	Camera Setting	26	History Screenshot
13	Battery Status	27	Alarm Record Album
14	HD/SD Switch	28	Date of History Record


10. Camera Settings:



11. PIR Body Detection:

11.1 Body Detection Alarm Setting

PIR 'Body Detection' is default to be on 'High' level. But it is adjustable. Please refer to the pictures below.



Sensitivity	Detecting Distance (For moving and living objects)
Low	Up to 5 meters (16ft)
High	Up to 10 meters (32ft)

*Tips: Higher sensitivity offers longer detection distance and more alarms.

11.2 Alarm Notification

This camera is not designed for 7x24 full day recording. It is only triggered when body motion is detected. Here are system's reactions:

11.2.1 Alarm notifications with sounds from App.

11.2.2 Pictures/videos automatically stored in SD Card or Cloud.

11.3 Records/Playback/Delete

11.3.1 On 'MESSAGES' page, click 'Alarm Messages', you can view all the records listed.

11.3.2 Click the following buttons to playback or delete.



12. Two - Way Audio:

Step 1: Activate the audio option.

Step 2: Press and hold the intercom button to speak.

Step 3: Release the button to listen.



13. Battery Management:

13.1 The camera comes with built-in Large Capacity battery. Assuming the camera wakes up 15 times/day, the battery can last 3-6 months after fully charged.


13.2 Charger Standard: DC 5V 1/2A (not included). Camera will be fully charged after **8-16 hours**.

13.3 When the battery level is less than 20%, the App will send you prompt message to charge in time.



14. Multi Device Management :

14.1 Multi Camera Management



14.2 Multi-User Sharing

Notice: One App account (A) can't login on multiple devices at the same time.

One camera can't be connected to multiple App accounts either.

But camera can be shared form A to B account.

Step 1: Create another new App account (B) and login on another Phone.

Step 2: Click 'share' on the main phone (A account phone)

Step 3: Use A to scan QR code or Input account ID of B.

Step 4: Accept sharing on B account and refresh page to check



Refer to the Video

15. Reset:

Step 1: Keep pressing to remove device

Step 2: Press the reset button for 5-10s until hear the 'Boogu' sound

Step 3: Reconnect as a new camera



16. Storage Methods:

16.1 Micro SD Card

If you choose a Micro SD Card to save videos, please kindly check:

A, It must be Micro SD Card, reaching at least 10MB/S to transfer. (class 10)

B, The camera can support up to a 128G Micro SD Card.

C, It needs to be inserted when the camera is off, otherwise the camera can't detect the SD Card.

D, It can be recycling used, meaning the newest video will be saved automatically to replace the oldest one when it is full.

16.2 Cloud Storage

A, Each camera has 7 days' free trail for Cloud service, then you can decide to whether to continue using it or not. If yes, you need to pay for the subscription. Attached table for subscription fee.

B, The subscription is based on camera ID, not refers to App account. If you have multiple cameras, it requests to subscribe for each one separately .

Cloud Storage Subscription Fee		
	For One Month	For One Year
3 Days Loop Recording	\$2.99	\$30
7 Days Loop Recording	\$4.99	\$50
30 Days Loop Recording	\$15.99	\$160

17. Trouble Shooting:

NO.	Description	Solution
1	Cannot Turn on Camera	Is camera fully charged? Did you press the POWER button without release long enough or have you tried several times more?
2	Cannot Reset	Did you press the RESET button without release long enough or tried several times more? Is the camera mode indicator flashing red slowly? Did you hear a noise (boogu sound) after you reset?
3	Cannot Connect	Have you connected your phone to the same 2.4 GHz wifi network as your camera do? Did you double check if your wifi password is correct? Is your network steady enough or close to your router?
4	No Notifications	Is Motion Detection turned on? Is mode indicator showing blue when motion is detected? Did you get alarm messages for motion detection? Did you allow notifications on App and phone notification settings? Or contact Tech Support by email.
5	No Detection	Ensure Motion Detection turned on. Camera mode indicator shows blue when motion is detected. Signal strength is high. Set detection sensitivity to HIGH. Install camera max.32ft from moving object. No alarm interval or alarm plan set.
6	Change to a New Network	Remove the camera in ZUMIMALL App Press the reset button to factory setting Re-conencion.
7	No person on Alarm Videos	Adjust camera sensitivity to 'HIGH'. The moving objects may appear from the corner of camera coverage, please adjust the lens angle.
8	Frequent Alarm	Adjust the camera alarm sensitivity to 'Low' Check whether camera's monitoring range is in large traffic areas, and set alarm plan to reduce false alarms.
9	No Alarm when someone passes by	Make sure motion detection is turned on. Ensure motion happens beyond the range of PIR monitoring area.

尺寸宽度140MM*高度140MM

128G 铜版纸 双铜

10	No Alarm Video	Make sure insert an SD Card or activate Cloud Service. Click triangle button to play videos.
11	Device Offline	Charge the camera and reconnect it. Ensure the Wifi signal strength is good as above 75%.
12	Battery Durability	Reduce frequency of Motion Detection, Two-way talk, and frequency of viewing Live Feeds.
13	ZUMIMALL App Flashback	Phone system version is too low or too high.
14	Unable to Charge	Charge at least 8-16 hours with a 5V 1A/2A phone charger. LED turns to be red means your camera is charging correctly. Make sure USB power cable and the phone charger both work well.
15	Unable to Register Account	Make sure to select correct country.
16	Unable to Add Friend	Your account and friend's account must be in the same country. For example, accounts in Europe and America cannot share with each other.
17	App Crash	Uninstall, reinstall the App and reconnect camera; Contact Tech support.

Please Email us for Better Solution
Before Returning any Unqualified Product to Amazon

tech@zumimall.com

THANK YOU

