

HIBOY

The manufacturer reserves the right to make changes to the product, and update this manual at any time.

Visit www.hiboy.com to download the latest user manual.

www.hiboy.com

HIBOY

T1 Kick Scooter

USER MANUAL



Contents

1	Package Contents	01
2	Product Overview	02
3	Before You Begin	03
4	Assembly	04
5	Adjustable Height	05
6	Folding and Carrying	06
7	Riding Basic	07
8	Starting out	08
9	Maintenance	09
10	Warranty	10
11	Contact Us	11

1. Package Contents



Carefully check package contents, if anything is missing or damaged, please contact Hiboy customer service for support: us.support@hiboy.com




2×Allen Wrench



1×Quick Start Guide

2. Product Overview



3. Before You Begin

BEFORE USING THE KICK SCOOTER, PLEASE READ ALL INSTRUCTIONS AND SAFETY NOTICES. CONSIDER ALL POTENTIAL RISKS.

Ensure that the steering rod is fully engaged and all screws are tight. Check that the wheels are secure and turn smoothly. Always ride defensively, and watch out for potential obstacles that may catch your wheel or cause you to swerve suddenly. Always check any local laws or regulations which may affect where the Hiboy scooter may be used.

Ride at your own risk and use common sense. Any rider that is unable to fit comfortably on the product should not attempt to ride it. All decisions on who is allowed to ride the kick scooter should be made based on their maturity, skill, and ability to follow the rules.

The Hiboy scooter is designed for one rider. Never carry passengers, and do not attach the scooter to other objects.

This product was manufactured for performance and durability but is not impervious to damage.

Jumping and aggressive riding should be avoided under all circumstances. The rider assumes all responsibility and risk associated with the high-stress activity.

Keep your fingers and other body parts away from all other moving components when operating the Hiboy kick scooter.

Keep your hands on the handlebars at all times.

Do not wear headphones or use a cell phone while operating the Hiboy kick scooter.


Avoid excessive speeds when riding downhill, as it increases the risk of accidents and injury. Avoid wet, slick, bumpy, uneven or rough surfaces while using the Hiboy kick scooter. Never risk damaging surfaces such as carpet and flooring by using the product indoors.

Do not ride at night, or when visibility is limited.


4. Assembly

To open, pull the folding machine while holding the handlebar, and push the stem until you hear a CLEAR click. Please make sure that you hear a click, otherwise, the folding machine will not lock into place. Then unfold the kickstand to support the scooter. (Visual instruction 1,2)

1.Open the cover, and take out two handles off the carrier and slide them onto the T-piece. Please make sure the handles must snap into the fixed holes. And then, turn off the cover. (Visual instruction 3)




4



5. Adjustable Height

Open the quick-release lock and pull out the handlebar stem until it clicks and suits the height of the rider, then close the quick-release lock again. The clamp tension of the quick-release lock can also be adjusted by tightening or loosening the securing nut(Visual instruction 4,5)



5

6. Folding and Carrying

To unfold the scooter


To open, pull the folding machine while holding the handlebar, and push the stem until you hear a CLEAR click. Please make sure that you hear a click, otherwise, the folding machine will not lock into place. Then unfold the kickstand to support the scooter.

To fold the scooter:

Pull the folding machine while pushing the handlebar forward with great force, then fold the handlebar down.

If you still have questions with folding the scooter, please kindly go to www.hiboy.com for tutorial videos, thank you.

When your scooter is folded up, simply lift it by the stem to carry.



7. Riding Basics

All beginnings are difficult, you therefore first have to master the basics of scooter-riding, and then progress with time. Be extremely cautious and not rush anything.

1. Always wear safety equipment such as helmet, knee pads, and elbow pads. Always wear a helmet when riding your scooter and keep the chinstrap securely buckled.
2. Always wear complete closed shoes and make sure that laces are properly tied up.
3. Ride on smooth, paved surfaces away from motor vehicles.
4. Avoid strong bumps, drain grating, and sudden changes in the riding surface. The scooter could stop abruptly.
5. Do not exercise any sharp or short turning maneuvers when you ride the scooter.
6. Turn the handlebar to the right and left to ensure that it works correctly and smoothly. Also, check whether the handlebar stem is tightened before riding the scooter.
7. NEVER steer the scooter with one hand, but always with both hands. You have to grip riding. Keep away from motor vehicles and watch out for pedestrians. This scooter is not the handlebar firmly with both hands.
8. Avoid excessive speed associated with downhill rides. The faster the scooter is, the longer it takes to stop. On a smooth surface, the scooter may slip, lose balance, and even result in a fall. Thus it is crucial that you use caution, keep proper speed and distance, especially so when you're unfamiliar with the place.
9. Adults must assist children in the initial adjustment procedures to unfold scooter, adjust handlebar and steering to height, and finally to fold scooter.
10. Obey all local traffic and scootering laws and regulations.
11. Watch out for pedestrians.
12. Do not exceed 220 pounds (100 kilograms).

13. For your own safety, check the scooter before every use. When you note loosen parts, excessive wear, strange sounds, and other abnormal conditions stop riding.
14. The scooter is not suitable for jumps.
15. The scooter is suitable for the use of one person only.
16. Immediately replace worn and/or damaged parts.
17. Closely follow the safety instructions in the manual. Hiboy shall not be liable for any financial losses, physical injuries, accidents, legal disputes, and other interest conflicts resulted from actions that violate user instructions.

8. Starting Out

FOOT POSITION

Before riding, put your foot as close as possible to the front of the deck, and the other foot on the ground. Make sure that your driving route is clear. To start riding, boost yourself forward with your foot that is on the ground. Keep one foot behind the other, (it's more comfortable to place one foot forward and the other one turned backward at 70-90°, like on skate/surfboard). It will help you gain more stability.

HOW TO APPLY THE BRAKE

The scooter is ridden by regularly pushing the foot against the ground. To brake, simply step on the brake plate of the rear wheel. The braking force can be dosed by a light firm step. Before you ride at higher speeds, you should practice riding at a slower speed and try to safely come to a helmet. You should basically never ride faster than you can run!

9. Maintenance

DAILY CARE AND MAINTENANCE

Check the product for any damage or signs of wear, before and after use. For your own safety, you should not perform any structural changes and should exclusively use original spare parts that you can purchase from a www.Hiboy.com. The product should no longer be used if any parts are damaged or sharp corners and edges have emerged. If you see stains on the scooter's body, wipe them off with a damp cloth. If the stains won't scrub off, put on some toothpaste, and brush them with a toothbrush, then wipe them off with a damp cloth. Notes: do not clean the scooter with alcohol, gasoline, kerosene, or other corrosive and volatile chemical solvents to prevent dire damage.

ROLLER-BEARING CHANGE

Replacement rollers and bearings should be replaced if they are worn out or else abraded. Both are available as an accessory from www.Hiboy.com. To change the rollers, loosen the axle screw with the provided Allen wrench and remove the roller from the axle. You can also use the Allen wrench to press the ball bearing out of the wheel, in order to use it again (we however recommend that rollers and bearings are replaced together). Insert the bearing with the spacer back into the new roller and use the axle screw to mount both on the scooter. Ensure that the axle is again securely screwed on before using the scooter. Please tighten the screws regularly.

MAINTENANCE AND STORAGE

When the scooter not in use, keep it indoors where it is dry and cool. Do not put it outdoors for a long time. The ball bearing is maintenance-free and does not need to be oiled.

DISPOSAL INSTRUCTIONS

In the event of wear and expiry of the service life, please dispose of the product at the available return and collection systems. Questions can be answered on-site by the disposal of the company.

10. Warranty

30 DAY SATISFACTION GUARANTEED RETURN POLICY

If you are unsatisfied with your purchase, the return policy allows you to return the product purchased on the Authorization channel within 30 days counting from the date of receipt of shipment, and request a refund from the Authorization channel for any reason. For the return request, the seller is not responsible for lost packages due to the carrier, or products received that cannot be verified. Received products that have damage determined to have been caused by the end-user may be subject to denial of the return request.

TO QUALIFY FOR A REFUND, ALL THE FOLLOWING CONDITIONS MUST BE MET: 30 DAY SATISFACTION GUARANTEED RETURN POLICY

1. A Return Merchandise Authorization (RMA) must be requested from Hiboy within 30 days from the date of receipt of shipment. To request an RMA, contact the customer service center at us.support@hiboy.com
2. The cost of return shipping will be borne by the customer.
3. For warranty service, please keep your receipt and/or invoice to validate proof of purchase.
4. Returned products must be in good physical condition (not physically broken or damaged).
5. All accessories originally included with your purchase must be included with your return.
6. If you return a product to the seller, (a) without an RMA from the seller (b) without all parts included in the original package, the seller retains the right to refuse delivery of such return.

DURING THE AUTHORIZED WARRANTY PERIOD, HIBOY WILL REPAIR OR REPLACE DEFECTIVE PRODUCTS OR PARTS THEREOF, AT ITS OPTION, WITHOUT CHARGE, WITH SIMILAR AND AVAILABLE MODELS. LIMITED PRODUCT WARRANTY

This warranty does not cover damage due to negligence (misuse, failure to comply with the instructions for use, normal wear, inadequate maintenance of or alterations to the product, failure to comply with the conditions of safety and/or precautions for use, etc.) or for damage caused by repairs, replacement of single parts or maintenance carried out by other than authorized personnel. Hiboy is not responsible for damage arising from failure to follow instructions relating to the product's usage.

11. Contact Us

Contact us if you experience issues relating to riding, maintenance, or safety with your Hiboy T1 kick scooter.

HIBOY LIMITED

1460 S Archibald Ave.,, ONTARIO, CA 91761 US

E-mail Service: us.support@hiboy.com



@Hiboy_Official



hiboyus



@HiboyUS



HiboyUS



www.hiboy.com