


Fiido T1 Cargo Electric Bike



Dear users! Be sure to pead this manual carefully befor riding, do understand the operations and seep this manual and other material for further using.

WARNING: DO NOT USE THE BIKE BEFORE YOU KNOE HOW TO USE.

Dear user:

In this manual,we will introduce the specification,installation,usage,precautions,and maintenance of FIIDO T1.Be sure you know everything you need to know about the bike that introduced in this manual. Any questions,please contact Fiido After-sales Team or our Local Service Center,and a prompt and feasible solution will be provided.

Safety precautions

1. Please follow the precautions in this instruction to effectively reduce risks. When you enter public areas, please obey national and local regulations, remain vigilant while riding, and maintain a reasonable safe distance from other people and vehicles.

2. Please operate by the instruction of the user manual, the loss caused by not following the instructions shall be borne by oneself.

3. This product is not professional off-road vehicle, do not use this product according to off-road vehicle standards.

4. For the first time riding, please do not choose the area with many children, pedestrians, pets, vehicles, or other obstacles and potential hazards. Please be familiar with the bike before riding on public road.

5. Before each ride, please carefully check whether fasteners are loose or parts are damaged. If there's any unusual noise, please stop riding immediately, and contact after-sales team for assist.

6. To reduce the injury risk, please read and follow all "Caution", "Danger" and "warning" instructions in this user manual. No speeding, and do not ride in motorized road under any circumstances.

7. For safety consideration, user must be over 16 years old. Users under the following circumstances are strongly not recommended to use this product:

- People affected by alcohol or drugs.
- People who are unable to engage in strenuous physical activity due to illness.
- People who are unable to maintain balance or whose balance is impaired by motor skills.
- People whose weight exceeds the max load limit (max load is 120KG/265lb).
- Pregnant woman.

8. Please ride carefully in snow, rain, wet road, ice and other bad weather. Do not ride over too high or too large obstacles, otherwise it's very likely to lose balance or grip and cause injuries.

9. Do not attempt to charge while the charger or power supply is wet, please follow the local safety regulations if you need to charge the bike in public area.

10. For effective protection and as convenient as possible for yourself, please be sure to use Fiido specific parts.

11. If you need to retrofit your bike,Please follow the local laws and regulations, after consulting with Fiido after-sales team, then proceed with caution. Serious injury and/or damage caused by unauthorized modification will result in the void of warranty.

CONTENTS

1.Product introduction 2. Using guide

1.1 Bike overview 1.2 Packing list 1.3 Bike diagrams 1.4 Function DESC 2.1 Installation guide 2.2 First time using 2.3 Charging instructions

3. Maintenance precautions

3.1 Using precautions

3.2 Bike maintenance & repair 3.3 Motor maintenance & repair

3.4 Battery maintenance & repair

- 3.5 Reflex reflector cautions
- 4. Service directory
- 4.1 Troubleshooting methods
- 4.2 Specifications
- 4.3 Warranty coverage
- 4.4 Repair record

* All pictures are for reference only.

1.Product introduction

- 1.1 Bike overview
- 1.2 Packing list
- 1.3 Bike diagrams
- **1.4 Function DESC**

1.1 Bike overview


THE FUTURE STARTS HERE

As Fiido's first multi-functional electric cargo bike, T1 was designed to met different useing needs such as carry cargo, short distance riding, commuting and pick up the child, providing users with the best cycling tool for more effective and interesting travel. T1 can load 441lbs (maximum 265lbs for people, maximum 176lbs for cargo). With the 48V 20Ah large capacity lithiumbattery, it can easily achieve a greater mileage of 60+ miles. The 750W motor supports the max speed up to 28mph. Equipped with front fork shock absorption with locking system to ensure more comfort. The 20-inch integrated wheel has better quality assurance than the ordinary spoke wheel. The large headlight can be switched between lower beam and upper beam, to ownthe control of night riding vision

T1 has three riding modes, three electric assisted gear and seven-speed system, which can be rided by users of different heights from 5 'to 6.5', to extend more nice life scenes.


1.2 Packing list

Bike parts



*Please carefully check whether all items are complete and intact. If there is any problem such as missing or damaged, please contact the official after-sales team asap.


1.3 Bike Diagrams




*Non professionals are forbidden to disassemble and assemble the battery. Please contact after-sales team for assist.

1.4 Function DESC

Handlebar



Battery




2.Using Guide

- 2.1 Installation guide
- 2.2 First time using
- 2.3 Charging instructions

2.1 Installation guide

The basic installation of the bike has been completed before out ofr the factory. When you receive the bike, you only need to install the handlebar, baskets, headlight, front wheel, pedals and lock the aeat saddle.


Install the handlebar



① First unscrew and open the handlebar clamp




② Lift the handlebar upward to the right position



③Adjust the handlebar to the right position, should be in a parallel with the fork; close the handlebar clamp and tighten the screw.


(Caution:The screws should be tighten in case safety problems)

Install the front wheel



- ① First take out the nut and collar on the wheel
- ② Then put the fork on the wheel axle,put in the collar and tighten the nut

Install the Fender




Put the front fender through the gap of the tire and fork, then screw tightenly.

Lnstall the front basket




Align the four holes of the front basket with the four holes of the bike head, and tighten screws

Install the front light



Align the headlights with the front basket hole, put into screws and nuts then tighten, and then insert the the red line and blue line of the headlights in accordance with the direction of the arrow

Install pendals



Use the open spanner of the tools bag, screw the pedal shaft into the threaded hole and tighten it in the direction of the arrow.

Caution: While installing the pendal, pay attention to the left / right pendal corresponding to the left / right crank, the pendal screw and the inside of the crank are respectively marked L(left) / R(right). Please install the pendal correctly to prevent it from sliding out of the crank.

2.2 First time using

Before riding, please follow the installation guide to install components properly, check whether the firmware is loose, ensure sufficient power, and take appropriate protection for riding.


Step 1: Adjust the seat

Please adjust the seat to the appropriate riding height according to your height. (the recommended height is when the saddle is level with the user's pelvis when standing naturally. The height of the adjustment can NOT exceed the safety line)



Step 2: Turn on the power and adjust the suspension fork


- ① Unlock the battery to the "ON" position
- ② Press the "M" button for 3 seconds, when the display lights it start working, same instruction for turning off the power
- ③ Adjust the front shock absorption according to riding requirements: rotate the left button of the front fork to the direction of "+" to harden the front fork (faster rebound speed). Rotate to the direction of "-" to soften the front fork(slower rebound speed);



Step 3: Adjust the power assisted gear


Adjust the power gear according to the cycling road conditions.

(Equipped with 3 power assisted gears, the 1st gear is suitable for relatively flat road conditions, the more/higher the road slope, the larger gear can be adjusted accordingly.)




Step 4: Start riding

Please take corresponding protection before starting riding.





Step 5: Braking introduction

The left side is front brake, the right side is rear brake. While riding, it's recommended to use the rear brake first, then the front brake to slow down the speed to stop, in order to avoid falling accident caused by balance problems from urgent front wheel brake.




Step 6: How to draw out the battery





- ① Press and switch the key to "UNLOCK" position
- ② Press the bar and lift the saddle




③ Grip the handle and draw out the battery

2.3 Charging instructions

The battery comes with a small amount of electricity, before the first time use, please make sure to charge it to full power before riding.

Charging



- 1. Charging connection: Connect the charging interface of the charger to the charging port, then connect the power plug of the charger to the power socket.
- 2. Fully charged: When the indicator light of the charger is red, means it's normal charging. When the light is green, means it's fully charged.
- 3. Charging hour: Charging hour is around 7-9 hours, The duration depends on the situation.
- 4. Disconnect charging: When the indicator light turns green, means it's fully charged. Unplug the power plug first, then remove the charging interface from the battery. Close the battery dust cover.
- 5. Charging mode: The bike supports two charging modes: vehicle charging and disassembly battery charging. Please see P13 for how to remove the battery.
- Caution: Charger has high voltage device, DO NOT repair without permission. In order to avoid danger, battery and charger should be placed away from children. There should be no inflammable and explosive objects around the batteries (such as car seat cushions, sofas, etc.). Keep the battery in a ventilated and dry place, and make sure NOT to charge in open-air place, to avoid electrical short circuit fire and other accidents caused by rain and other factors, and to prevent liquid and metal particles into the electrical parts.
- Danger: Charging can be allowed on public charging equipment, but the matching between the bettery and the charging equipment should be fully considered.
- Warning: If there's any odor or high temperature during charging, please stop charging immediately and contact after-sales team for assist.

3.Maintenance precautions

- 3.1 Using precautions
- 3.2 Bike maintenance & repair
- 3.3 Motor maintenance & repair
- 3.4 Battery maintenance & repair
- 3.5 Reflex reflector cautions

3.1 Using precautions

(I) Users should pay attention to the safety of bicycle use

- 1. No parking in building foyers, evacuation stairs, walkways and safety exits.
- 2. No charging in residential buildings. Charging should be far away from combustible, and no longer than 9 hours.
- 3. Prevent water from entering electrical parts. When cleaning the bike, avoid water impact on charging port, wiring harness connectors, fuse and other electrical parts.
- 4. When adjusting the height of the saddle, the safety line mark of the seatpost should not be exposed.
- 5. Users and dealers must not wiring and modifying structure and performance without permission. Such as: change the battery configuration, the circuit, increase the lamp power, increase the sound and other modification.
- 6. Do not touch the live part of the bike with wet hands or metal conductors. Such as: charging port, charger plug etc.
- 7. When replacing circuit breakers or fuses, use circuit breakers or fuses of the specified models and specifications. Do not short-fuse wires. The circuit breaker or fuse card slot should be in good contact, or may cause the accidents.
- Please do not disassemble electrical parts without authorization to prevent liquid and metal particles from infiltrating into electrical parts.
- 9. Do not ride on bad weathers, or place the bike in a long-term exposure to the sun/rain to avoid parts aging.
- 10. If scrub the bike is needed, please wipe the body with a neutral lotion mixed with tap water. Do not remove and wash internal parts to avoid short circuit.
- Caution: Non-professionals are strictly prohibited to repair. In case of failure, please contact the after-sales team or authorized professional maintenance station for maintenance.

(II) Riding safety: please follow the national and local traffic laws and regulations, pay attention to riding safety.

- 1. User must be over 16 years old. Do not lend to people who can not operate the bike to avoid the harm.
- 2. Please ride in Non-Motor Vehicle Lane, with the max speed no more than 25km/h.
- 3. Please carry persons or goods in accordance with local laws and regulations while riding.
- 4. Please be sure to wear a suitable safety helmet and fasten the helmet wind strap while riding.
- 5. The braking distance will be extended in rainy and snowy days, please pay attention to slow down, and try to avoid to ride on bad weathers. Inner short circuit and electrical parts damage may be caused if the water level reaches the center of the hub of the rear wheel motor, please noticed.
- 6. Please follow the local traffic rules carefully. No riding after drinking, and make sure to always ride with both hands.
- 7. Bright colors, relaxed, and comfortable suit are suggested for riding, and wear low-heeled shoes for riding is necessary.

(III) Examination before riding: please repair in time or go to the local maintenance point for repair, if there's any abnormality.

- 1. Please confirm the normal power use when using the kickstand and the rear wheel is off the ground.
- 2. Turn on the power, check whether the indicator light is normal, and the power supply is sufficient.
- 3. Check whether the mechanical bell and front/rear light are in good condition.
- 4. Confirm whether the handlebar and seatpost are adjusted to the appropriate position, that fastening screws and quick release are fastened. Be attention that the safety line should not be exposed.
- 5. Check the front/rear brake handle, brake adjustment should make the brake reliable and flexible reset.
- 6. Check whether the tire pressure is normal, no cracking, abnormal wear, nails, stones, glass and other sharp objects.
- 7. Check whether the front/rear wheel screws are locked, the side, rear and pedal reflectors are in good condition.
- 8. Check whether the front /rear lighting is normal and ensure that lights can be good used while riding.
- 9. Check the fastening state of each axle to ensure the front/rear axles are in a reliable state.
- 10. Check whether the frame clamp is locked before riding.

Caution: abnormal tire pressure, tire cracking damage and abnormal wear are the main causes of steering failure and tire burst.

(IV) Attentions on the road

- 1. For your safety and the safety of others, please obey the local traffic rules consciously.
- 2. Before riding, be sure to wear a safety helmet, take safety precautions and maintain a natural posture.
- 3. At the beginning of riding, please slowly accelerated, to avoid the energy waste or accidents.
- 4. For a longer service life of the battery and motor, when start riding or climbing, please try to use power assisted mode.
- 5. To ensure safety, economic speed should be used as far as possible, and reduce frequent braking, frequent start as far as possible, to save electricity.
- 6. avoid the phenomenon of tightening the speed control handle after braking.
- 7. Riding on muddy areas or uneven roads should use pendal mode as far as possible.
- 8. Braking distance should be appropriately increased on bad weathers, please be concentrated and careful while riding.
- 9. Equipped with overcurrent protection. The circuit may be overcurrent under the condition of higher uphill Angle and higher headwind speed. It's better to use pendal mode, otherwise, power consumption may be too fast to affect the range, motor and electrical appliances burn. The body and electrical parts should not be electriferous, the insulation resistance value shall not be less than 2M w.
- 10. Controller has undervoltage protection, the power will be cut off automatically if the voltage is lower than the undervoltage value, to maintain the service life of the battery.

(V) Attentions of pushing and parking

- 1. The power should be off when pushing the bike, to avoid the accidents.
- 2. Parking should be on the level ground, and maintain the bike as power off status.
- 3. For your safety, please maintain and clean your bike regularly to keep it in the best condition.

3.2 Bike maintenance & repair

- 1. The bicycle has been checked and adjusted before out of factory, any problems please contact Fiido After Sales Team for support.
- 2. Normally the spokes of the wheel should be adjusted once after half a month of riding to ensure the best use.
- 3. Make sure to check the storage capacity of the tire regularly to keep it in normal use.
- 4. Make sure to check the main parts like handlebar, stem. saddle, seatpost, front/rear and centre axle, flywheel and chain, wheels, to keep it in normal use, nut and screw loose should be tightened in time if it loose.
- 5. In use, it's recommended to add 3# calcium base lubricating oil (butter) every six months to the parts that need lubrication (such as front/middle/rear axle bearing, front fork bowl group, foot pedal bearing, etc.). Add 30# oil to the chain, brake cable, support and other parts every two months
- 6. If the vulnerable parts are damaged, such as: brake line, brake skin, brake pad, bulb, fuse, etc. Please find the local maintenance center to replace, but be sure to replace with the same model specifications of the parts.
- Cautions: Handlebar core screw fastening torque, combined handlebar joint screw fastening torque, saddle clamp screw fastening torque, front wheel fastening torque recommended torque is not less than 18NM; The recommended torque for fastening the central shaft lock mother and rear wheel is not less than 30NM. Handlebar and saddle tube safety line should not be exposed outside the body.

3.3 Motor maintenance & repair

- 1. Equipped with rare earth permanent magnet DC brushless, external rotor hub motor, without any deceleration mechanism and carbon brush, which is basically maintenance-free.
- 2. Do not open the motor base and end cover after sealing.
- 3. Keep the motor clean, no foreign matter, corrosive liquid, gas into the motor, do not knock and bake the motor shell, so as not to damage the motor.

Caution: If the fault cannot be removed, please consult after-sales team.

3.4 Battery maintenance & repair

- Lithium battery has the characteristics of large capacity, long life, maintenance-free, light weight, pollution-free etc. Its service life is closely related to using mode. Do not store chronically, please form the habit of frequent charging.
- 2. It is recommended to charge for 7 9 hours each time, and the longest time is not more than 1 day. Lithium battery has no memory effect, can be used with the charge.
- 3. Make sure to charge for more than two hours every month under chronically store condition. Do not store the battery at a loss of power. Once the battery voltage reaches the discharge state, will cause unrecoverable damage.

Danger: Do not dismantle old battery without authorization, it should be collected according to regulations. Warning: Do not near the fire or high temperature source, or throw it into the fire, or expose it to the sun.

3.5 Reflex reflector cautions

- 1. Reflex reflector device must not be missing, if it's missing, please immediately contact after-sales team for replacement, and the installation position should be consistent with the original bike.
- 2. Fiido reflex reflector has been fixed on the vehicle, please do not change the position, modify, disassemble, etc.
- 3. Make sure to check the normal function of reflex reflector before each use, and keep the surface clean.
- 4. The reflector device must not be covered by luggage, children's chairs, clothing and other objects, otherwise it may cause safety hazard.

4.Service directory

- 4.1Troubleshooting methods
- 4.2 Specifications
- 4.3 Warranty coverage
- 4.4 Repair record

4.1 Troubleshooting methods

Fault code description

| Fault code | Fault phenomenon | |
|------------|----------------------|--|
| E1 | Communication issues | |
| E2 | Throttle issues | |
| E3 | Brake lever issues | |
| E4 | Motor hall issues | |
| E5 | Motor issues | |
| E6 | Controller issues | |

General fault

| Fault phenomenon | Fault cause | Rule out way |
|--|--|--|
| Through-supply motor failure | Poor contact of regulating handlebar Poor contact of brake cut-off switch Motor damage Controller damage Loosened connector | Change regularing handlebar Change brake cut-off switch Change motor Change controller or get repair Check the connector |
| Lack of range | Tire pressure deficiency Undercharged or faulted charger Aging battery or damaged battery More uphill, gale, frequent braking, overload, etc | Blow up the tire Fully charged, check charger Change battery Using pendal mode |
| Difficulty in charging | Loosened plug Disconnected battery cable Damaged charger | Tighten socket and connector Welded connector Change charger |
| Speed failure or low speed than 10KM/h | Poor contact of regulating handlebar Loosened connector Battery overvoltage | Change regulating handlebar Check the connector Fully charged |

4.2 Specifications

| Property index | ltem | T 1 | |
|--------------------|--|--|--|
| Product size | Before folding: Length*Width*Height (mm) | 1780*690*1200 | |
| Tires (Inch) | | 20*4.0 | |
| Product weight | Net weight (kg) 35.6kg | | |
| | Maximum load (kg) | 120kg | |
| Riding requirement | Applicable age | 16+ | |
| | Applicable height | 160cm(4.9') - 200cm(6.5') | |
| | Serial numbe Location | Under the frame | |
| | Maximum speed | 15.5MPH (25km/h) | |
| | Maximum climb | 25% | |
| | Center distance between wheels (mm) | 1210 | |
| | Transmission | SHIMANO 7S | |
| Main spec | Power assisted system | 3 gears | |
| | Transmission ratio | 52T: 14 - 28T | |
| Applicable road | | Urban asphalt pavement/flat pavement | |
| | Operating temperature | -10° ~50° | |
| | Waterproof rate | IP54 | |
| | Rated voltage (V) | 48 | |
| Detter | Battery type | Lithium battery | |
| Battery | Rated capacity (Wh) | 960 | |
| | Battery management system | Overheat/short circuit/ overcurrent and overcharge protection | |

| | Rated power (W) | 750 |
|---------|-----------------------------|--------------------------------|
| | Rated speed(r/min) | 410 |
| Motor | Moter type | Brushless geared motor |
| | Undervoltage protection (V) | 39±1 |
| | Overcurrent protection (A) | 25±1 |
| | Input voltage (V) | 100-240 |
| | Output voltage (V) | 54.6 |
| Charger | Output current (A) | 3 |
| | Charging hours (h) | 7 |
| | Front light | LED |
| Others | Tail light | LED |
| | Riding mode | Power assisted mode+Pedal mode |

Caution:

* The above data allow for 5% manufacturing tolerances.

* After receiving the bike, there may be some differences between individual accessories and display drawings, which are different due to the different batches, and do not affect the use.

4.3 Warranty coverage

(I) Warranty principle

- 1. Users should operate correctly according to this user manual. In case of performance failure caused by production quality, according to relevant laws and national provisions of the three guarantees, the company shall uniformly perform the obligations of the three guarantees.
- 2. The faults beyond the warranty scope and the main parts after the warranty period shall be repaired by the company but shall be charged at the discretion.
- 3. Regards the battery replacement after the warranty period, will be charged with the factory price, but the old battery must be returned to the manufacturer, to ensure safety and avoid environmental pollution.

(II) Warranty scope and period

| Item | Parts | Guarantee time | Service | |
|----------------|---|----------------|--|--|
| | Frame | 36 months | Natural deformation, open welding, desoldering fracture | |
| | Fork, Handlebar, Stem, Seatpost | 12 months | phenomenon, quality problems caused by poor manufacturing can be replaced. Self-modification, collision damage, etc. are not warranted. | |
| Basic parts | Kickstand, Tires, Saddles, Fenders, Safety hook, Seat clamp, Stem clamp, Frame clamp, Pedals, Brakes, Brake discs, Brake levers | 3 months | Tire puncture by sharp objects, collision damage of spare parts, etc. are not warranted. | |
| | Crank chain disc, Front arm set, Hub, Wheel hub, Spokes, Shift finger dial, Derailleur, Flywheel, Chian, Bottom bracket, Shock absorber | 6 months | Man-made damage, self-modification, collision damage of parts and accessories are not warranted. | |
| | Controller | 12 months | | |
| | Charger, Main wiring harness | 12 months | Short circuit, burnout, performance failure due to poor | |
| Electric parts | Display instrument, Speed control knob, Booster, Controller cover plate | 6 months | manufacturing can be replaced. Water, disconnection, and man-made damage are not warranted. | |
| | Headlights, Taillights, Power-off brake levers, Switches | 3 months | | |
| Motor parts | Motor, Hall, Bearing, Clutch | 12 months | Phase loss, Hall element burnout, demagnetization, abnormal bearing noise can be replaced. Breakage, water ingress are not warranted | |
| Motor parts | Lithium battery | 12 months | Replace the battery due to faults such as broken grids, no power storage, and less than 70% capacity. No warranty for water ingress or man-made damage | |

(III) The scope and content exceed warranty

- 1. Failure caused by user's failure to use, maintain and adjust according to the User Manual".
- 2. Failure caused by private modification.
- 3. Failure caused by improper use or storage by users or accidents.
- 4. No warranty card, or card and bike do not match.
- 5. Vulnerable parts and consumables, including plastic parts, spokes, rim, brake line, scratching surface etc.
- 6. The expenses for self-repair without the consent of the specially contracted maintenance unit.
- 7. After accessories leaving the factory, shell scratches or shell damage will not enjoy warranty.
- 8. Lead scratches or breaks.

Warranty notification

- 1. Accessories will be guaranteed in strict accordance with the warranty period.
- 2. The warranty period shall be calculated from the date of delivery.
- 3. No warranty will be provided if the charger, battery and motor are disassembled without permission.
- 4. For other parts of the bike, the quality issues will be provided three months warranty , others will not be warranty.
- 5. When other parts of the bike has issues, maintenance must be carried out in a professional maintenance centre, not private disassembly. Controllers, batteries, chargers must be ensured that all labeling integrity.
- 6. maintenance must comes with the warranty card, invoice, certificate of quality and other relevant documents.
- 7. The battery warranty method is 1:1. In case of battery problems, the battery should be returned to the manufacturer to determine whether the battery is covered by warranty according to battery testing standards.

4.4 Repair record

Warranty card

| User | Company | |
|---------------|---------|----------|
| | Name | Phone |
| Addre | Address | |
| Purchase date | | Color |
| Model | | Order No |
| Frame No | | Motor No |

Repair record

| Date | Maintenance | Remarks |
|------|-------------|---------|
| | | |
| | | |

Shenzhen Fiido Technology Ltd Address: Shenzhen, Guangdong, China. Website: www.fiido.com If you have any questions or suggestions about this user manual, please contact us via following mailaddress Contact us: support@fiido.com



Scan for video instruction



Made in China



6971957790525