



Security Camera

Operating Instructions

<https://www.cococamtech.com>

Claim Your Lifetime Warranty



Thank you for choosing COCOCAM products.
We are committed to providing the best service to all our customer.
If anything has happened to your product, please contact us for a lifetime warranty.



 cococam



 cococam

E-mail: service@cococamtech.com

Website: www.cococamtech.com

Contents

1.Camera light	01
2.Install the CocoCam APP	01
3.Add camera	03
4.Device menu	07
5.Intelligent Tracking	09
6.Alarm management	10
7.Alert notifications and video playback	12
8.Device share	14
9.FAQ	15

1.Camera light

LED status	Description
Flashing green	The device is connected to the network and operating normally
Red light flashes slowly	Waiting to be connected
Red light flashes quickly	Connecting status
Camera button	Description
Reset	Long press the button for 5 seconds to reset the device

2.Install the CocoCam APP

Search for "CocoCam" APP in the App Store(for iOS) or Google Play(for Android), or scan the QR code to download and install it on your mobile phone.





*Note :

Please enable the following 2 permissions when using the APP for the first time:

1.Allow "CocoCam" to access mobile cellular data and wireless LAN, otherwise you will not be able to add a camera through it.

2.Allow "CocoCam" to receive notifications, otherwise the phone will not receive push notifications when motion detection or sound alarms are triggered.



2.1 Register an account: New users need to register via email --> click "register" --> follow the steps to complete the account registration --> then log in.

2.2 For any help or product issues, please send us an email to service@cococamtech.com. We'll reply to you within 24 hours.

3.Add camera

Before use:

1. If using sd card Before power-on, please insert the Micro - SD card (2-128GB). If the Micro - SD card is inserted after power-on, detection may fail and the product will need to be powered on again.
2. In WiFi connection, make the product and your mobile phone 1ft to 3ft (30cm to 100cm) from the router.
3. Before product adding, enable the Bluetooth function on your mobile phone. The product supports networking through Bluetooth.You can scan the QR code below or visit the link to watch the added video

You can scan the QR code below or visit the link to watch the added video

1.Through Bluetooth



2.Through scan QR codes




https://youtu.be/jMp-9_RbV0o


<https://youtu.be/LdoKkjX0j2o>

Product adding method 1: Through Bluetooth


- ① Connect the power supply and wait for flash of the red LED indicator.
- ② Click "+" at upper right of home page of the APP to add the product. On the product adding page, a list of the nearby cameras that can be connected through Bluetooth will appear automatically.
- ③ Choose your camera, search the wanted nearby WiFi, enter the WiFi password and wait for product adding.



Click "Add Device"



Choose the Bluetooth device.




Choose the wanted nearby WiFi and enter the WiFi password.

China Unicom 01:29




Wait for connection.

China Unicom 01:30



Connection successful.


China Unicom 01:30




Product adding succeeded.

Product adding method 2: Through scan QR codes


- ① Click "+" at upper right of home page of the APP and choose Smart Camera(2.4G&5G Wi-Fi)
- ② Connect the power supply. When the red LED indicator is flashing, choose the wanted WiFi and generate a QR code (the product needs to be reset in its second adding rather than in its first adding).
- ③ Use the lens to scan the QR code and wait for completion of product adding.



Click "Add Device"



Choose Smart Camera



Please power on the device.

Please place the camera & phone close to your router for the best signal.



Connect the power supply.



Please reset the device.

- Hold the RESET button on your device for 4-5 seconds (please refer to the user manual for more on this).
- Wait for a flashing RED indicator light.
- Tap Next.



Reset the product.




Choose the wanted nearby WiFi and enter the WiFi password.



Scan the QR code.






Wait for connection.



Product adding succeeded.

4. Device menu





- 1.Add camera
- 2.Camera time
- 3.Real-time view button
- 4.Multi-screen
- 5.Camera name
- 6.Open & hide view
- 7.Replay
- 8.Setting menu
- 9.My device list
- 10.Messages


- 20.Screenshot button
- 21.Record
- 22.Lens switch
- 23.Intercom option,
long press to talk
- 24.Motion Detection
- 25.PTZ control
- 26.Photo Album
- 27.Video Replay
- 28.Playback Alarm Records

- | | |
|-----------------------|-------------------------|
| 11.My profile | 29.Alarm Date Selection |
| 12.Camera settings | 30.Alarm Points |
| 13.SD and HD options | Selection |
| 14.Full screen option | 31.screenshots |
| 15.Speaker | 32.videorecord |
| 16.Bit Rate | 33.Download Videos |
| 17.Cloud playback | 34.Delete the day's |
| 18.Preview | Replay |
| 19.Local play | |

5.Intelligent Tracking

When you need to turn on the camera tracking function, turn on the corresponding tracking button according to the tracking mode supported by the camera.

*Note: If the tracking is triggered too sensitively, you can reduce the detection sensitivity of the device, or set the range of the detection area.



6. Alarm management

"Alarm Management" is enabled by default, and the default detection sensitivity is "Medium". This can be adjusted in "Device"—"Settings"—"Alarm Management".

1. Detection sensitivity


The detection sensitivity supports "Low-Medium-High", the higher the sensitivity is selected, the easier it is to trigger the alarm.

2. Alarm area

In order to reduce false alarms, it is recommended to set .

up area detection alarms: select the yellow area as the alarm detection area, and the blank area does not detect the alarm. When detecting, please try to avoid some objects that are easy to move, such as flowering grass and trees to avoid unnecessary false alarms

***Note:** When the yellow detection area has not been set for the first connection, all the blank areas are detectable by default. Once the yellow detection area is set, the blank area will not be detected and alarmed anymore.



7.Alert notifications and video playback

The camera supports 24-hour all day video recording. It can also push alert notifications to the APP and record the video to a micro SD card or cloud storage(payment is required)when the device detects moving objects.

You can play the recorded videos anytime and anywhere through the CocoCam APP.

When the device detects a moving object, the status of the camera:

1. The alarm sounds in the APP (turn on the notification permission of the CocoCam APP in the phone settings and turn on the phone volume)
2. Push notification of alarm information (activate the notification through the CocoCam APP in the phone settings).
3. The Micro SD card/cloud storage starts to capture alarm snapshots and record videos (make sure a TF card is inserted.)

Alarm record

Click to view alarm screenshots

Click to play alarm video

A list of alarm records with the following entries:

- 10:45:28 AM: Noise Detection 76db
- 10:44:27 AM: Motion Detection
- 10:44:25 AM: Noise Detection 65db
- 10:43:21 AM: Noise Detection 77db
- 10:42:08 AM: Noise Detection 65db
- 10:41:05 AM: Noise Detection 70db




Settings screen showing:

- 113514321
- WIFI: 100%
- Timezone: Asia/Shanghai
- Receive Alert Notifications (toggle is on)
- Alarm Management
- Image Settings
- Device Share

8.Device share

Each camera can only be added to one administrator account. If other family members want to view the camera, they must sign up for an account separately.

1. Let your family register a CocoCam account first; make sure to use a new email account and phone number.
2. Click "Device Share". There are two sharing methods for you to choose: QR code sharing or account sharing.
3. Choose QR code to share: Allow your family to show their account QR code, and then you can share the camera with your family after you scan it.
4. Select account to share: Enter the account name registered by your family, and then share the camera with your family.



9.FAQ

1.Why can't my device connect to WiFi?

(1)Check to make sure your Wi-Fi name and password are normal. The password cannot exceed 31 digits, no special characters, preferably numbers and English letters, and please pay attention to capitalization.

(2)Make sure your camera supports the corresponding wifi band.

(3)Make sure your camera and mobile phone are close to the router.

(4)If the above suggestions do not solve the problem, please contact us via email. We'll reply to you within 24

2.How do I reset the camera?

(1)Please press and hold the reset button for 5 seconds.

(2)When the device makes a chime, the red light starts to flash slowly. This means that the camera has been successfully reset.

3.How do I connect the camera to a new WiFi?

(1)Long press the reset button for 5 seconds to restore the factory settings.

(2)Remove the camera in the CocoCam APP.

(3)Reconnect to the new WiFi.

4.Why can't I receive any alert notifications?

(1)Enable notification permission in the CocoCam APP background.

(2)Turn on the alert notifications option on the device's setting interface.

5.Why is there no alarm recording?

Check to see if the TF card has been inserted or the cloud storage recording is turned on.

6.My camera is always offline.

Please make sure the router network is normal. It may be that the location of the camera is too far away from the router, causing the WiFi to fail to cover the camera.

7.Why is the recorded video delayed in time?

Please check the speed of the WiFi bandwidth and the strength of the WiFi signal; the distance between the camera and the router should not be too long.

8.Why can't I add a camera after scanning the QR code?

Try to scan the mobile phone QR code at multiple angles 15cm away from the camera, or try to reset the camera; place it next to the router, reconnect and add it.

9.Can the video files in the SD card of the device be played by other programs?

The camera's internal video files do not support playing on other browsers or software, they are privately encrypted and must be viewed on the phone via your own account or

the account of a shared family member. However, you can record and save the video to your phone while watching.

10. Why can't the device recognize the TF card?

First, please check whether the TF card is 2-128 GB. To ensure the recognition rate and the life of the TF card, it is recommended to use Class 10 Speed FAT2 or EXFAT32 format Micro SD card, Samsung, SanDisk, Kingston Micro SD card.

After formatting the TF card, reinsert it and power the camera on again to see if it can be recognized and recorded.

11. Why can't the device detect the movement of objects under night vision?

Check to make sure the alarm management is enabled, and set the detection sensitivity to "High". Then check whether there is an object in front of the lens that is very close to the lens causing infrared light reflection and image exposure, which will affect the effect of the night vision picture.

12. Why is the camera still in the device list after reset?

The reset option of the camera can only reset the network configuration of the camera; it cannot modify the configuration on the APP. If you want to delete the camera, you must log in to the APP to delete it.

13. What should I do if there is a false alarm in the equipment detection video?

First, you need to set the detection sensitivity in motion detection to "Low", and then accurately set the detection area according to the area you want to monitor. In addition, please try to avoid areas with a large number of animals, people, flowers or trees to avoid unnecessary false alarms.