






# Wardrobe






### **IMPORTANT INFORMATION!**

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.




### **AVOID SCRATCHES!**

In order to avoid scratching this furniture should be assembled on a soft layer- could be a rug.



### **IMPROVE EFFICIENCY !**

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



### **ANTI-TOPPLE WARNING !**


Overturnd furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

### **IMPORTANT !**




It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.




Please prepare the following tools



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

<p>A x 47</p>  <p>∅6 x 34 mm</p>	<p>B x 8</p>  <p>∅6 x 28 mm</p>	<p>C x 55</p>  <p>∅15 x 10 mm</p>	<p>D x 48</p>  <p>∅8 x 30 mm</p>	<p>E x 12</p>  <p>∅4 x 40 mm</p>
<p>F x 16</p>  <p>∅4 x 30 mm</p>	<p>G x 38</p>  <p>∅3 x 12 mm</p>	<p>H x 15</p>  <p>15.5 x 10 x 1.2 mm</p>	<p>J x 15</p>  <p>∅3 x 16 mm</p>	<p>K x 4</p>  <p>∅35mm</p>
<p>L x 4</p>  <p>∅35 mm</p>	<p>M x 48</p>  <p>∅4 x 16 mm</p>	<p>N x 8</p>  <p>150 x 34 mm</p>	<p>P x 16</p>  <p>∅4 x 18 mm</p>	<p>Q x 8</p>  <p>35 x 400mm</p>
<p>R x 32</p>  <p>∅3 x 12 mm</p>	<p>S x 2</p>  <p>53 x 24 x 12 mm</p>	<p>T x 1</p>  <p>770 mm</p>	<p>U x 4</p>  <p>∅4 x 14 mm</p>	<p>V x 1</p> 



**⚠ WARNING**

**Children have died from furniture tipover. To reduce the risk of furniture tipover:**


- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is a permanent label.  
Do not remove!*


**Slides Must Be Separated Before Assembly.  
After Separated, Set Aside Until Needed for Assembly.**

Las diapositivas deben separarse antes del montaje.  
Después de la separación, déjelo a un lado hasta que sea necesario.


Les glissières doivent être séparées avant l'assemblage.  
Après la séparation, mettez de côté jusqu'au moment de l'assemblage.




**STEP 1: Extend Slide**  
Extender la diapositiva  
Extendre la diapositive






**STEP 2: Push Lever UP**  
Empujar hacia arriba  
Lever le levier




**STEP 3: Remove Runner**  
Quitar el corredor  
Enlever le coureur






1



Insert quickfit screw(A) into corresponding holes in plate 11 with a screwdriver as shown.





2



Attach plate 13 to plate 11 with wooden dowel(D) at first.



Put cam lock(C) into holes in plate 13 and turn clockwise to tighten as shown.





The holes are facing down








3



Insert quickfit screw(A) into corresponding holes in plate 10 with a screwdriver as shown.





4





Attach plate 10 to plate 13 with wooden dowel(D) at first.  
 Put cam lock(C) into holes in plate 13 and turn clockwise to tighten as shown.




5





Insert quickfit screw(A) into corresponding holes in plate 12 with a screwdriver as shown.





6





Attach plate 12 to plate 10, 11 and 9 with wooden dowel(D), then fix using screw(E) as shown.





7





Attach plate 1 to plate 10,11 and 9 with wooden dowel(D), then fix using screw(E) as shown.





8



Insert quickfit screw(A) into plate 2 and 3 with a screwdriver as shown.






# 9





Attach plate 2 to plate 14 with wooden dowel(D); put cam lock(C) into holes in plate 14 and turn clockwise to tighten as shown.





Attach plate 3 to plate 15 with wooden dowel(D); put cam lock(C) into holes in plate 15 and turn clockwise to tighten as shown.






# 10







Separate glide into two parts at first(Page 5). Fix slide rail(Q) to plate 6 and 7 using screw(R) as shown.





11





Fix slide rail(Q) to plate 8 using screw(R) at first.  
Flip the plate, and fix slide rail(Q) as shown.



12



Insert quickfit screw(A) into plate 7 as shown.




# 13

C x 1






Ø15 x 10 mm

D x 2



Ø8 x 30 mm



Attach plate 3 and 15 to plate 7 with wooden dowel(D) at first. Put cam lock(C) into holes in plate 3 and turn clockwise to tighten as shown.


# 14

C x 1






Ø15 x 10 mm

D x 1





Ø8 x 30 mm





Attach plate 5 to plate 7 with wooden dowel(D) at first. Put cam lock(C) into holes in plate 5 and turn clockwise to tighten as shown.



# 15





Insert quickfit screw(A) into plate 8 at first.  
Flip the plate, insert quickfit screw(A) as well.







# 16



Attach plate 8 to plate 5,3 and 15 with wooden dowel(D) at first.  
Put cam lock(C) into holes in plate 3,5 and turn clockwise to tighten as shown.







# 17





Attach plate 2 and 14 to plate 8 with wooden dowel(D) at first. Put cam lock(C) into holes in plate 2 and turn clockwise to tighten as shown.

# 18





Attach plate 4 to plate 8 with wooden dowel(D) at first. Put cam lock(C) into holes in plate 4 and turn clockwise to tighten as shown.




# 19





Insert quickfit screw(A) into plate 6 as shown.





# 20









Attach plate 6 to plate 4, 2 and 14 with wooden dowel(D) at first.  
Put cam lock(C) into holes in plate 2, 4 and turn clockwise to tighten as shown.



# 21


<p>C x 6</p>  <p>Ø 15 x 10 mm</p>	<p>D x 6</p>  <p>Ø 8 x 30 mm</p>	
--	---	---





Connect the two components with wooden dowel(D) at first. Put cam lock(C) into holes in plate 7,8,6 and turn clockwise to tighten as shown.

# 22



<p>G x 38</p>  <p>Ø 3 x 12 mm</p>	<p>H x 15</p>  <p>15.5 x 10 x 1.2 mm</p>	<p>J x 15</p>  <p>Ø 3 x 16 mm</p>	
--	---	--	---

	<p>J</p>  <p>Ø 3 x 16 mm</p>	<p>R</p>  <p>Ø 3 x 12 mm</p>
---	---	---





Fix back plate 21,22,23,24,25 and 26 using screw(G) at first. Fix each plate together using iron sheet(H) with screw(J) as shown.




# 23



Insert quickfit screw(A) into plate 32 as shown.




# 24






Attach plate 32 to plate 1 at first.  
Put cam lock(C) into holes in plate 1 and turn clockwise to tighten as shown.

# 25


<p>S x 2</p>  <p>53 x 24 x 12 mm</p>	<p>T x 1</p>  <p>770 mm</p>	<p>U x 4</p>  <p>∅ 4 x 18 mm</p>	
---	--	---	---

	<p>M</p>  <p>∅ 4 x 16 mm</p>	<p>U</p>  <p>∅ 4 x 14 mm</p>
---	---	---





Fix part(S) to plate 9 and 11 using screw(U) as shown.  
Place clothing rod(T) as shown.

# 26


<p>K x 4</p>  <p>∅ 35 mm</p>	<p>M x 8</p>  <p>∅ 4 x 16 mm</p>	
---	---	---

Fix hinge(K) to plate 27 and 29 respectively using screw(M) as shown.


	<p>M</p>  <p>∅ 4 x 16 mm</p>	<p>U</p>  <p>∅ 4 x 14 mm</p>
	<p>K</p> 	<p>L</p> 



27

L x 4  Ø 35 mm	M x 8  Ø 4 x 16 mm	
---	---	---

Fix hinge(L) to another plate 27 and 28 respectively using screw(M) as shown.




	M  Ø 4 x 16 mm	U  Ø 4 x 14 mm
	<del>K</del> 	L 

28


M x 16  Ø 4 x 16 mm	N x 2  150 x 34 mm	P x 4  Ø 4 x 18 mm	
--	--	---	--

	M  Ø 4 x 16 mm	U  Ø 4 x 14 mm
---	---	---




Attach plate 27(with hinge K) to left side plate 9 using screw(M) as shown.  
 Attach another plate 27(with hinge L) to middle plate 11 using screw(M) as shown.  
 Fix handle(N) to both door plates using screw(P) as shown.

# 29


M x 16  Ø 4 x 16 mm	N x 2  150 x 34 mm	P x 4  Ø 4 x 18 mm	
--	---	---	---

	M  Ø 4 x 16 mm	U  Ø 4 x 14 mm
---	---	---





Attach plate 29 (with hinge K) to right side plate 10 using screw (M) as shown.  
 Attach plate 28 (with hinge L) to middle plate 11 using screw (M) as shown.  
 Fix handle (N) to both door plates using screw (P) as shown.

# 30

Q x 8  35 x 400 mm	R x 16  Ø 3 x 12 mm	
---	--	---





Fix runner (Q) to plate 16 and 17 using screw (R) as shown.

	J  Ø 3 x 16 mm	R  Ø 3 x 12 mm
---	---	---



# x4





31



x4

Insert quickfit screw(B) into plate 18 as shown.


32



x4

Fix plate 16 and 17 to plate 18 using screw(F) as shown.

33





x4

Slide plate 19 along grooves as shown.

34





Attach plate 20 to plate 18 with wooden dowel(D) at first.  
 Put cam lock(C) into holes in plate 20 and turn clockwise to tighten as shown.





x4

# 35







Insert quickfit screw(A) and (B) into plate 30 and 31 as shown.



x2



# 36




x2

Attach plate 30 to plate 20 with wooden dowel(D) at first. Put cam lock(C) into holes in plate 16,17,20 and turn clockwise to tighten as shown.

37







Fix handle(N) to plate 30 using screw(P) as shown.



x2


38




x2

Attach plate 31 to plate 20 with wooden dowel(D) at first. Put cam lock(C) into holes in plate 16,17,20 and turn clockwise to tighten as shown.


39

N x 2  150 x 34 mm	P x 4  Ø 4 x 18 mm	
---	---	---


Fix handle(N) to plate 31 using screw(P) as shown.



40




--

Align rails, slide all drawers.















41

V x 1



42



# WARRANTY

## WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

## Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

## Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

## The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

# RETURNS

## CHANGED YOUR MIND AND NEED TO RETURN YOU ITEM?

### PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

### DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

### DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.  
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.